

优惠供应 气胎油壬|大口径气胎油壬|碳钢气胎油壬

产品名称	优惠供应 气胎油壬 大口径气胎油壬 碳钢气胎油壬
公司名称	景县华泰液压橡塑制品有限公司
价格	面议
规格参数	加工定制:是 品牌:华泰 型号:各种
公司地址	景 县城西工业区二中北路
联系电话	0318-4227376 13315828891

产品详情

技术参数：1、工作介质：泥浆、油、水 2、介质温度：0 ~90

3、环境温度：-30 ~50 4、介质压力：0.5mpa 5、气胎充气压力：0.4~0.8mpa 6、气胎放气后复位时间：1~4秒

technical parameters1. working medium: mud, oil and water;2. medium temperature: 0 ~90 3. environment temperature: -30 ~50 4. medium pressure: 0.5mpa5. charge pressure of pneumatic tyre: 0.4~0.8mpa6. reset time of pneumatic tyre after discharge: 1~4 s

特点：1、安装对中要求低，实现不对中快速安装和密封。2、密封可靠，不泄漏。3、气胎充气即抱抱紧中心管，实现快速联接和密封。4、气胎放气即放松中心管，实现快速拆卸。5、安装拆卸无联接件，无需手工具。6、适应性强，维护简便。 features:1. low requirements for centering, and rapid installation and sealing of un-centering.2. reliable sealing without leakage.3. after charge, the pneumatic tyre will touch tightly around the central pipe for rapid connection and sealing.4. after discharge, the pneumatic tyre will loose the central pipe for rapid un-installation.5. there are no connecting parts for installation parts or un-installation, it is unnecessary to use hand or tool to operate.6. high adaptability and easy to maintain.

安装1、气胎由壬的钢壳与容器或泥浆罐出口孔相焊接，或将钢壳焊接于相应直径的钢管端口上，并使气嘴孔朝上。2、焊接完成后将气胎装入钢壳内。3、将中心管两端分别插入左右两个气胎由壬的气胎孔内。4、从气嘴向气胎由壬内胎充气至规定压力。 installation 1. the steel casing of pneumatic tyre unions is weld with the outlet of container or mud tank, or weld the steel casing on the end of steel pipes with relevant diameter, and enable the air nozzle hole upward.2. after welding, install the pneumatic tyre into the steel casing.3.

insert two ends of central pipes into two holes of pneumatic tyre unions.4. charge from the air nozzle to the pneumatic tyre till the required pressure. 规格及安装尺寸 (mm) : specification and installation size (mm)

	a	b	c	d	e	f
4	213	114	148	168	50	110
6	267	168	199	219	50	110
8	318	219	253	273	50	110
10	372	273	305	325	50	110
12	424	325	357	377	50	110
14	476	377	406	426	50	110
16	528	426	425	465	50	110

注意事项：1、充气用带增压缸的双管打气筒,配充气嘴即可使用。在有配套压缩气源时也可用压缩空气充气。本公司为用户备有加长胶管打气筒。2、气胎充气或放气后，应将气嘴护帽戴上，防止气嘴损伤。3、气胎取出或装入钢壳时应注意保护气嘴，以防影响使用。4、为使密封可靠，气胎充气压力可大于管线压力0.3mpa。5、拆卸管线时可先取下气嘴护帽，用细棍放气卸压，卸压后1~4秒气胎可恢复到原来的通径尺寸，以便中心管从气胎内自由取出。6、为保护气胎，钢管两端应有15。的倒角，钢管表面应光滑无毛刺和凹坑。7、钢管插入气胎前，应使气胎彻底放气，否则中心管无法插入内胎。8、两个气胎由壬之间的中心管可以是钢管，但最好是两端带钢接头的胶管中心管。 attentions1. use double-pipe inflator with pressuring cylinder for charge, prepare a charging connector for operation, meanwhile, compressed air can be used to charge, the company prepares lengthened hose inflator.2. after charge or discharge of the pneumatic tyre, make the charging connector wear protecting cap from damaging the connector.3. when take out or install the steel casing, protect the connector from preventing normal use.4. in order keep reliable sealing, the charge pressure of pneumatic tyre can exceed 0.3mpa of pipe pressure.5. when uninstalling the pipelines, firstly take down the charge connector protecting cap, use a thin stick to discharge and release pressure, after pressure discharge 1-4 s, the pneumatic tyre may restore to original diameter, so that the central pipe can be easily taken out of the pneumatic tyre.6. in order to protect the pneumatic tyre, two ends of the steel pipe shall have a chamfering of 15o, and the surface of the steel pipe shall be smooth without burrs or recess.7. before the steel pipe is inserted into the pneumatic tyre, the pneumatic tyre shall be completely discharged, otherwise, the central pipe will be unable to insert into the tyre.8. the central pipes between two pneumatic tyre unions can be steel pipes, yet the perfect pipes shall be hose central pipes with two ends equipped with steel joints.

联系人: 赵俊娥 销售经理

联系手机：13315828891

联系电话：0318-4396387

传真号码：0318-7768318

腾讯 qq：508060980

qq邮箱：508060980@qq.com

联系地址：河北省衡水市景县城西工业园

本产品的加工定制是是，品牌是华泰，型号是各种，别名是接头，钻孔直径是170（mm），钻孔深度是20（m），钻孔角度是1（°），外形尺寸是160（mm），重量是1（t）