

TA238 可设报警温度计

产品名称	TA238 可设报警温度计
公司名称	管小宝(个体经营)
价格	24.00/台
规格参数	品牌:ktj 型号:TA238 类型:非接触式
公司地址	中国 浙江 金华市 义乌国际商贸城G3-18052
联系电话	086 0579 85198052

产品详情

品牌	ktj	型号	TA238
类型	非接触式	测量范围	0-50 ()
尺寸	79*75*17 (mm) (mm)		
类型多种型式			0-50 ()
示值误差1		测量范围	79*75*17 (mm)
		外形尺寸	

温度计和计时器，可用于厨房、实验室、工厂。它有 alarm 报警功能。

温度计的使用范围：-50 ~ 300 。 1：装上一节7号电池。(aaa1.5vdc) 2：拨动 timer-thermo 开关至thermo位置。显示当前温度和显示设定报警温度。 2.5 当前温度 5.0 设定模式 3：内置报警温度为50 ，使用up-down按键设定适合温度。

按up键上调温度值，按down键下调温度值，按住up键或down键可快速上调或下调温度值。

4：如设定了一个错误的温度，可通过同时按up各down键重新设定。

注意：当温度计已设定了温度，不要拨动time—thermo键，否则会取消已设定的温度，

5：按start键1次，报警预备模式会取代设定模式。

6：当目前的温度到达设定的温度值时，报警声会响，按stop键1次，报警声会停止。计时器的使用：

此计时器可设定、分、秒。最大设定为99：59：59 1：拨动time键到time位置，设定模式会显示为：00：00 00 设定模式

2：同时按下min与sec可重新设定计时器值（重复以上操作，可停止设定或重新设定）

3：用min与sec键设定。按min设定分钟及小时，按sec设定秒。

按住sec或min不放，则相应位值快速增加，当分钟位值到60时，小时位自动增加1。

4：当你设定了一个错误时间，复位可重新设定，（参考步骤2）。

5：当你设定了正确时间，按start键1次。

注意：当计时器已设定，不要拨动timer—thermo键，否则会取消已设定时间。 6：当报警预备模式

取代设定模式，计时器开始倒计时。 7：当倒计时到 00：00 00 时，开始报警。 8：此时按stop

1次，停止报警。 9：按下复位，计时器回到初始的设定模式。 10：附带1.1米传感线。（请勿用本品测试

超过300 以上的物体。)

thermometer & timer

this device provides you with an easy to use the thermometer & timer with alarm function in kitchen, factory or bbq.

using the thermometer

2.push the timerthermo to thermo

3.the thermo-temp. and set temp. will be displayed

the thermo-temp. is showing the current temperature.

the thermo-temp. is showing set temperature for alarm function.

25 thermo-temp

50 set-temp

4.the default set – temp. is 50 . use the up or down button to set the proper temperature

to decrease the set – temp. press down

to increase the set – tem. press up

hold the down or up button down for a fast decrement or increment.

5.if you have set a wrong temperature, simply press down and up simultaneously to reset

6.press the start button once ,the alarm stand – by mode will replace the setting mode

7.the alarm will sound when the thermo- temp. reaches the set-temp.

8.press stop button once to stop the alarm . temp. range: -50 ~300 (-58 ~572)

using the timer

the timer is used to keep track of your setting time in hours ,minutes, and/or seconds

hold the min or sec button down for a fast increment .when the minute dlgit reach 60,it will advance to an hour.

4.if you have set a wrong time, rest (see setp 2)

5.if you have set the correct time , press the start button once.

note: once the time has been set ,do not push the timer – thermo button , since it will cancel the set time .

6.the alarm stand – by mode replaces the setting mode the time starts to count down

7.the timer will sound when it counts down to 00:00 00 .

8.press the stop button once to stop the alarm.

9.the unit will return to its pre-set position . your may reset the unit or start again.

10.1.1meter sensor wire.

11.working temperature range for the body.(0 ~50 . 32 ~122)

12. please do not surpass 300 above object with this test