

PC/ABS(1)?????GE?C6600-111 C6200-111
C2800-111?C2800-701?C2950-111?C2950-701?C1110?C1110HF?C1200HF;
(2)????FR2010?FR2000?T45?T65?T85

PA6(1)????1013B?1015B?1022T; (2)????1013J?1300S 1300G;
(3)????1010C2?1010C?1020A?1030C; (4)????CM1017?CM3001?CM3004;
(5)????CM3001?21SPC;(6)????B30S ; (7)????101F?101L?;

POM(1)????M90-44?M90-04; (2)????F20-02?F20-03?F30-03?K-300?K-700
(3)????M90-04?M90-44?M25S(4)????F20-02?F20-03????500P 500T 100P; (5) ?????C9021 M90
C13031 ; (6)????FM090?FM270 (7)???4520?8????F20-03

PMMA(1)????MF001?VH-001 (2)????CM-205?CM-207?CM-211?CM208 (3)????LG???LG:IF850

PBT(1)??GE855?310-SE0?420-SE0?DR48???ST-820?NC010

PC(1)??????201-10 201-15 301-15(2)????7002?7025?7030I?7022IR?7025IR S2000 (3)????IR2200?I
(4)????K-1300?1250Y?1225Y?1350Y?3001?1225L (5)???L-1250Y?L-1225Y
(6)????2805?2605?2080?2858?2807?2405?2458?2658?1250?1239?6555
(7)?????????GE:141R-111?241R-111?940A-116?144R-111

PP????ST868M 7533?6331NW?7633???AW161