

SKF旗下LINCOLN林肯润滑系统 066030 ,066031 ,066042,066060

产品名称	SKF旗下LINCOLN林肯润滑系统 066030 ,066031 ,066042,066060
公司名称	苏州玛雅传动设备有限公司
价格	25.00/个
规格参数	品牌:SKF 型号:066030 发货地:江苏
公司地址	昆山市巴城镇东平路301号
联系电话	0512-21610976 17751221799

产品详情

SKF旗下LINCOLN林肯润滑系统 066030 ,066031 ,066042,066060

SKF润滑泵, SKF润滑, 066030 STEEL BALL

SKF Lincoln 润滑系统产品

066030 STEEL BALL

066031 COTTER

066042 COTTER

066060 CASTER

066071-9 BALL

066100 AIR GAUGE

066111 LUBRICANT GAUGE

066130 THUMB SCREW

066170 LOCK WASHER

066186 LOCK WASHER

066197 COTTER PIN

066200 TB.FITT. MS GE 1/4TUBE X 1/8NPT A,136BAR

066201 TB.FITT. MS WE 1/4TUBE X1/8NPT A,136BAR

066202 CLIP SCREW

066210 TB.FITT. MS WE 1/4TUBE X 1/4NPT A,136BAR

066211 TB.FITT. MS GE 1/4TUBE X 1/4NPT A,136BAR

066250 BALL

066260-9 NUT SS

066285 STEEL BALL

066310 COTTER PIN

066415 MALE CONNECTOR

066584 STRAINER

066645 ADAPTER UNION

066648 STRAIGHT ADAPTER

066649 ADAPTER 1/8NPTF AX1/8NPSM I ST

066650 TB.FITT. MS T 1/4TUBE,136BAR

066713 NUT

066714 MALE CONNECTOR

066714-9 MALE CONNECTOR SS

066716 TB.FITT. MS WE 1/8TUBE X 1/4-28 A,34BAR

066717 90 DEGREE SWIVEL

066717-9 90 DEGREE SWIVEL SS

066723 WASHER

066728 STEEL BALL

066730 MALE CONNECTOR

066762 TB.FITT. MS WE 3/8TUBE X 1/4NPT A,136BAR

066764 MUFFLER - PM SERIES

066772 MALE CONNECTOR

066846 TB.FITT. MS GE 3/8TUBE X 1/4NPT A,136BAR

066876 TB.FITT. MS TE 3/8TUBE X1/4NPTF A,136BAR

066878 TB.FITT. MS T 3/8TUBE,136BAR

066883 ADAPTER UNION

066893 WASHER

066935 TB.FITT. MS WAI 1/8TUBE X 1/8NPT I,34BAR

066957 STEEL BALL

066962 SELF TAP SCREW

066964 TOP NUT

066966 STUD

067007 CLOSURE PLUG

067007-9 CLOSURE PLUG SS

067011 ADAPTER,T 1/8NPTFIX1/8NPTFIX1/8NPTF I MS

067041 TEE

067044 CLOSURE PLUG

067054 STREET ELBOW (BRASS) 1/4"NPT (F. X M.)

067062 ELBOW 3/4NPTF IX3/4NPTF A90DEG MA.IRON

067063 ADAPTER 1/8NPTF IX1/8NPTF I ST

067069 ADAPTER 3/8NPT I X 1/2NPT A ST

067102 ADAPTER,T 1/4NPTFIX1/4NPTFIX1/4NPTFI MS

067117 PIPE PLUG

067171 BUSHING

067176 ADAPTER 1/4 NPTF IX 1/2 NPTF I ST

067179 ADAPTER 1/2NPTF IX1/2NPTF I ST

067198 ADAPTER 3/4NPTF AX3/8NPTF I ST

067224 PLUG

067241 VENT PIPE

067296 COUPLING (ST) 3/8" NPF(F) X 1/2" NPT(F)

067325 STREET ELBOW

067346 1 IN PIPE PLUG

067358 ELBOW 3/8NPT A X 3/8NPT I 90GR MS

067368 ADAPTER 1/8NPTF I X 1/8NPTF A 90DEG MS

067379 HEX BUSHING

067417 3/8 PIPE PLUG

068042 SHUT-OFF VALVE

068415 TB.FITT. MS GE 3/8TUBE X 1/8NPT A,136BAR

068421 SPRAY NOZZLE

068462 FERRULE ST 1/4TUBE STANDARD-DUTY

068463 FERRULE ST 3/8TUBE STANDARD-DUTY

068464 COUPLING NUT MS 1/4TUBE STANDARD-DUTY

068468 TB.FITT. MS G 1/4TUBE

068482 RETAINING RING

068483 PLASTIC CAP

068528 STRAINER

068531 EYE BOLT

068587 SPRAY NOZZLE

068615 TB.FITT. MS LE 1/4TUBE X1/8NPTF A,136BAR

068645 PIPE PLUG

068649 STEEL BALL

068740 AIR COCK

068785 STEEL BALL

068797 PLUG BUTTON

068849 STRAINER

068850 COVER

068874 BRUSH

068881 RETAINING RING

068886 RETAINING RING

068887 HYDRAULIC COUPLER, 1/2" NPT FEMALE

068887-1 PLUG

068888 RETAINING RING

068908 RING

068943 TB.FITT. MS GAI 1/4TUBE X1/8NPT I,136BAR

维护

仔细且定期的维护是及时识别并排除可能故障的前提条件。根据设备的维护周期对润滑系统定期进行检查，并在必要时加以调整。请复印该表格，用于定期的维护作业。