

AH42F安全回流阀

产品名称	AH42F安全回流阀
公司名称	罗浮阀门集团飞环北京总代理
价格	面议
规格参数	
公司地址	北京市海淀区上奥世纪中心3号楼405室
联系电话	010-62918595 15811381206

产品详情

产品概述

[AH42E、A42F安全回流阀](#)

适用于工作温度在-40~80 的液化石油气的液相出口管上，当进出口压差0.5MPa时液化石油气能自动回流入罐。

型号	公称 口径	do	D	K	g	g1	b	f	f1	Z- ø d	DN	D1	K1	g2	b1	f'	Z1- ø d1	L	L1	H
AH4 2F-1	20	15	105	75	/	55	16	2	/	4-14	25	115	85	65	16	2	4-14	110	95	378
	25	16	115	85	/	65	16	2	/	4-14	32	140	100	78	18	2	4-18	110	95	378
6C A	32	20	140	100	/	78	18	2	/	4-18	40	150	110	85	18	3	4-18	115	100	378
42F-	40	25	150	110	/	85	18	3	/	4-18	50	165	125	100	20	3	4-18	120	110	406
16C	50	32	165	125	/	100	20	3	/	4-18	65	185	145	120	20	3	4-18	135	120	450
	65	40	185	145	/	120	20	3	/	4-18	80	200	160	135	20	3	8-18	160	140	520
	80	50	200	160	/	135	20	3	/	8-18	100	220	180	155	22	3	8-18	170	135	525
	100	65	220	180	/	155	22	3	/	8-18	125	250	210	185	22	3	8-18	195	175	690
	125	80	250	210	/	185	22	3	/	8-18	150	285	240	210	24	3	8-23	210	190	780
	150	100	285	240	/	210	24	3	/	8-23	175	310	270	240	26	3	8-23	255	230	838
	200	125	340	295	/	265	26	3	/	12-2 3	250	405	355	320	30	3	12-2 6	300	260	992
	250	150	405	355	/	320	30	3	/	12-2 6	300	460	410	375	30	4	12-2 6	350	320	1266
	300	220	460	410	/	375	30	4	/	12-2 6	400	580	525	485	36	4	16-3 0	370	350	1283
	350	250	520	470	/	435	34	4	/	16-2 6	500	715	650	608	44	4	20-3 4	500	450	1520
400	280	580	525	/	485	36	4	/	16-3 0	500	715	650	608	44	4	20-3 4	500	450	1530	
AH4	20	15	105	75	/	55	16	2	/	4-14	25	115	85	65	16	2	4-14	110	95	378

2F-2	25	16	115	85	/	65	16	2	/	4-14	32	140	100	78	18	2	4-18	110	95	378
5 A4	32	20	140	100	/	78	18	2	/	4-18	40	150	110	85	18	3	4-18	115	100	378
2F-2	40	25	150	110	/	85	18	3	/	4-18	50	165	125	100	20	3	4-18	120	110	406
5	50	32	165	125	/	100	20	3	/	4-18	65	185	145	120	20	3	4-18	135	120	450
	65	40	185	145	/	120	22	3	/	8-18	80	200	160	135	20	3	8-18	160	140	520
	80	50	200	160	/	135	22	3	/	8-18	100	220	180	155	22	3	8-18	170	135	525
	100	65	230	190	/	160	24	3	/	8-23	125	250	210	185	22	3	8-18	195	175	690
	125	80	270	220	/	188	28	3	/	8-26	150	285	240	210	24	3	8-23	210	190	780
	150	100	300	250	/	218	30	3	/	8-26	175	310	270	240	26	3	8-23	255	230	838
	200	125	360	310	/	278	34	3	/	12-2 6	250	405	355	320	30	3	12-2 6	300	260	992
	250	150	425	370	/	332	36	3	/	12-3 0	300	460	410	375	30	4	12-2 6	350	320	1266
	300	220	485	430	/	390	40	4	/	16-3 0	400	580	525	485	36	4	16-3 0	370	350	1283
	AH4	20	15	105	25	51	55	16	2	4	4-14	25	115	85	65	16	2	4-14	110	95
2F-4	25	16	115	85	58	65	16	2	4	4-14	32	140	100	78	18	2	4-18	110	95	378
0 A4	32	20	140	100	66	78	18	2	4	4-18	40	150	110	85	18	3	4-18	115	100	378
2F-4 0	40	25	150	110	76	85	18	3	4	4-18	50	165	125	100	20	3	4-18	120	110	406
	50	32	165	125	88	100	20	3	4	4-18	65	185	145	120	20	3	4-18	135	120	450
	65	40	185	145	110	120	22	3	4	8-18	80	200	160	135	20	3	8-18	160	140	520
	80	50	200	160	121	135	22	3	4	8-18	100	220	180	155	22	3	8-18	170	135	525
	100	65	235	190	150	160	24	3	4.5	8-23	125	250	210	185	22	3	8-18	195	175	690
	125	80	270	220	176	188	28	3	4.5	8-26	150	285	240	210	24	3	8-23	210	190	780
	150	100	300	250	204	218	30	3	4.5	8-26	175	310	270	240	26	3	8-23	255	230	838
	200	125	375	320	260	282	38	3	4.5	12-3 0	250	405	355	320	30	3	12-2 6	300	260	992
	250	150	450	385	313	345	42	3	4.5	12-3 4	300	460	410	375	30	4	12-2 6	350	320	1266

安装说明：

各种安全回流阀都应垂直安装。安全回流阀出口处应无阻力，避免产生受压现象。
安全回流阀在安装前应专门测试，并检查其密封性。对使用中的安全回流阀应作定期检查。