

卡特发动机大修件 5I8670 093-7521 131

产品名称	卡特发动机大修件 5I8670 093-7521 131
公司名称	湖南承载机械设备有限公司
价格	.00/件
规格参数	
公司地址	湖南省长沙市天心区刘家冲北路238号满庭芳家园三期601房-899（注册地址）
联系电话	19079192829 19079192829

产品详情

2223909/1154109 曲轴后油封 6N9916/1487455 排气门 9M2418 轴承2A3746 堵头 6N9988 停车电磁阀 9M4335 销子2A4429 锁片 6P2233 齿轮 9M4849 油封2D8009 油封 6P2233 齿轮 9M5024 油封2H3088 油封 6P7704 油封架 9M6302 轴承2H3755 螺丝 6P7742 轴 9M9647 油封 2H3932 油封 6P7743 轴 9M9740/1R0719 滤芯2H3934 油封 6P7772 环 9N0111 增压器芯子2H6184 油封 6P7773 油封 9N1330 皮带(9N1329两根) 2H6338 油封 6P7968 钢片 9N1330 皮带(含3根) 2H9247 油封 6P7968 钢片 9N2837 气门座2J2864 螺栓 6P7983 卡环 9N3078 水泵轴2J3507/1B4333 螺冒 6P7985 油封 9N3617 弹簧 2J8163 油封 6P8003 齿轮 9N3617 弹簧 2K0713 轴承 6P8003 齿轮 9N3718 滤芯2K2961 油封 6P8005 齿轮 9N3832 连杆螺丝2K3258 环 6P8005 齿轮 9N3832 连杆螺丝2K5069 轴承 6T1705 轴 9N5246/9L8072 凸轮轴瓦2L5271 轴承 6T1706 齿轮 9N5569 机油泵转子2M0849 垫 6T3285 轴 9N5627 壳子2N2489 油封 6T5383 齿轮 9N5786 随动柱2M2561 油封 6T6111/1741495 马达 9N5786 随动柱2M2689 黄油枪头 6T6111 马达 9N5920 瓦2M3340 油封 6V0238 修理包 9N5921 瓦2M4210 垫子 6V0473 卡环 9N5922 瓦2M4453 油封 6V0513 马达 9N6275 缸套2M5407 垫子 6V0539 轴承 9N6500 挺杆2M5685 轴承 6V0539 轴承 9P3713 架子2M5685 轴承 6V0890/5L5353 马达 9P3713 架子2M9780 油封 6V0890/5L5353 马达 9P3731 架子2M9780 油封 6V1426 螺栓 9N3738 垫片 2N1311 传感器 6V1427 螺栓 9P5558 环2N2766 螺母 6V1882 轴承 9P7256 环2N2766 螺母 6V2318 油封 9P7390 摩擦片2N8943 气门座 6V2483 油封 9P7390 摩擦片2P0220 垫子 6V3866 阀 9P7390 摩擦片2P0583 垫子 6V3988 油封 9P7756/9W3605 架子2P1168 轴承 6V3988/8C5210 油封 9P7757 齿轮2P1262/1487425 导管 6V4365 油封 9P8516 齿轮2P1262/1487425 导管 6V5121 油封 9P8518/6Y4843 齿轮2P1262/1487425 导管 6V5227/2071560 启动机/4N3181 9P8521 齿轮2P1692 油封 6V5227/2071560 启动机/4N3181 9P8521 齿轮2P1751 吸油滤网 6V6228 油封 9P8614 齿轮2P3859 套 6V6888 垫片 9P8623 轴2P6132 垫子 6V6889 螺冒 9P8624 轴2P6210 管子 6V6921 油封 9P8626 齿轮2P6210 管子 6V7196 油封 9P8847/6Y4840 板2P6245 轴 6V7196 油封 9P9031 齿轮2P7809 调节器 6V7658 油封 9P9509 齿轮2P8889/1105800 缸套 6V8349 接头 9P9517 变矩器涡轮2P8889/1105800 缸套 6V8397 油封 9P9610 传动油泵2P9678 螺栓 6V8398 油封 9S3111 油封2R0239 油封 6V8398 油封 9S6129 皮带轮2S0669 轴承 6V8628 油封 9S9972 空滤2S0669 轴承 6V8647 接头 9S9972 空滤2S0669 轴承 6V9746 油封 9U3124 终传动行星齿轮2S1286/P158662 滤芯 6V9746 油封 9U3125 终传动太阳齿轮2S4078 油封 6Y

1690 架子 9U8810 套子 2S5658 垫子 6Y4819/9P3714 架子 9U9658/8T0123 轴承 2S8439 环 6Y5
323 拖带轮 9V0205 刹车修理包 2V2380 熔断器 6Y5352 摩擦片 9V5159/8V2538 刹车修理包 2V5
737 轴 6Y5911/7G3129 摩擦片 9V5160/8V2535 刹车修理包 2V7092 板 6Y5911/7G3129 摩擦片
9V6558 管 2V9473 二极管 6Y5912/9P1861 摩擦片 9V6932 电线组 2W0027 铜套 7B3642 轴承
9V6933 线 2W0256 高压油泵 7B7515 轴承 9W0335 点烟器 2W0263 高压油泵 7C0111 卡环 9
W0517 油封架 2W0712 水泵水封 7C0115 销子 9W0518/7G5592 油封架 2W0712 水泵水封 7C019
2 气压表 9W0519 摩擦片 2W0716 修理包 7C1152 垫子 9W2452 裂土齿 2W0722 修理包 7C1
152 垫子 9W3043 发电机 2W0725 增压器修理包 7C1160 垫子 9W4949 架子 2W0865 活塞 7
C1160 垫子 9W4950 齿轮 2W1225 水泵 7C1161 垫子 9W4950 齿轮 2W1707 活塞环 7C3864/
1N4407 凸轮轴 7E9980 9W6652 油封 2W1708 活塞环 7C3901 连杆销 9W7235 油封 2W1708 活
塞环 7C4273 弹簧 9W8437 齿轮 2W1709 活塞环 7C4273 弹簧 9W8437/7G5299 齿轮 2W1709
活塞环 7C4297 后油封 9X1413 停车电磁阀 2W1733 油封 7C4297
后油封 9X3463 灯泡 2W1734 油封 7C4297 后油封 9X4276/6T1546 机油压力开关
2W2410 调速器 7C4297 后油封 9X5301 电磁阀 2W2621 气门 7C4508 水泵 9X8257 垫片 2W
3687 柴油表 7C4957 水泵 9X9511/7T0258 电磁阀 2W4831 活塞 7C5232 活塞环 9Y0231/9N086
1 高压油管 2W6000 缸套 7C5825 轴承 9Y0232/9L6042 高压油管 2W6000/1979322 缸套 7C5828
油封 9Y0233/9N0863 高压油管 2W6091 环 7C6208 缸套 9Y0234/9N1374 高压油管 2W6134 环
7C6208 缸套 9Y0235/9L6045 高压油管 2W6134 环 7C6660/9N0307 曲轴油封 9Y0236/9L6046
高压油管 2W7211 轴承 7C7431 增压器垫 9Y0237/9L6047 高压油管 2W7213 轴承 7C7579 增压
器 9Y0238/9L6048 高压油管 2W7213 轴承 7C7582 增压器 9Y1723 凸轮轴 2W7566 轴承套 7C7
596 增压器 9Y1798 油封 2W8078 机油泵阀 7C7598 增压器芯 7C7582 9Y1979 垫片 2W8265 活
塞环 7D8348 轴承 9Y1979 垫片 2W8265 活塞环 7E2464/7W8412 阀 9Y2148 排气管 2W8625
机油泵 7E3205 歧管 9Y2149 排气管 2W8412/9N5629 活塞 7E5214 活塞环 9Y2150 排气管 2W8
476 齿轮 7E5786/7C4111 活塞环 9Y2151 排气管 2W8951 皮带 7E7779 气门座 9Y2991 凸轮
轴瓦 2W8952 皮带 7E7894/9N5790 小瓦 9Y2992 凸轮轴瓦 2W9162 呼吸器 7E9262 止推片 9Y4
004 活塞 2W9162 呼吸器 7E9817 垫片 9Y7212 活塞 3B4506 垫 7E9817 垫片 9Y7212 活塞 3B
8489 黄油嘴 7F7590 垫片 9Y8103 垫片 3D2824 油封 7F8267 油封 9Y8848 导管 3D2824 油封
7F8268 油封 9Y8848 导管 3D2992/1148718 油封 7F8268 油封 9Y8217/1684531 活塞 3D6509
销子 7F9223 锁片 9Y8217/1684531 活塞 3E6455 机油压力开关 7G0437 片 9Y9497 瓦 3E6799
油封 7G2491 行星轮 9Y9497 瓦 3E7570/1619930 水温感应塞 1109735 7G2506/7T3370 连接盘 9Y9
895 油封 3G5098 环 7G2516 齿轮 9Y9895 油封 3G5098 环 7G2830 油封 304606 油封 3H1461
油封 7G2830 油封 1P3704 油封 3H2617 销子 7G3707 活塞 2S4078 油封 3H2652 油封 7G3
707 活塞 3K0360 油封 3J0634 油封 7G3711 齿轮 4J0519 油封 3J1907 油封 7G3711 齿轮 4J0
520 油封 3J1907 油封 7G3708 活塞 4J0523 油封 3J7354 油封 7G4030 阀杆 4J0525 油封 3K01
09 轴承 7G4311 齿圈 4J0526 油封 3K0158 油封 7G4856 950B 传动泵 4J0527 油封 3K0158 油
封 7G5444 架子 4J5140 油封 3K0159 环 7G5569 齿轮 4J5267 油封 3K0360 油封 7G5569 齿
轮 6K6307 油封 3K1432 环 7G5569 齿轮 6V8398 油封 3L1425 轴承 7G5589 齿轮 6V8400
油封 3N8506 油封 7G5589 齿轮 7J9108 油封 3P0623 环 7G5614 轴 8M4991 油封 3P3321 环
7G5670 油封 8M5253 油封 3P3461 垫子 7G5674 油封 8T0315 油封 3P7019 油封 7G5674
油封 9M5248 油封 3P7447 钢片 7G5675 油封 1089139 油水分离器 3P7447 钢片 7G5730 环
9W6672/6T8438 轮边浮动油封 3P7489 钢片 7G7218 行星架 1968191 机滤座 3R8920 熔断器 7G8
121 环 1U9891 液压油添加剂 3S2708 销子 7G9224 油封 9W2142/9W7220 支重轮油封 3S2708
销子 7H2976 灯泡 1709376/2130677 油位开关 3S5496 油封 7H7658 弹簧 5I7633 增压器接口螺
栓 3S5496 油封 7J7673/7S7673 油封 5I7679 增压器接口垫片 3S6162 垫子 7K1839 片 135-2373/2
375 大修包 3S8109 销子 7K1840 垫 5I7624 气门油封 3S9896 油封 7K6058 螺丝 5I8011 气门
座 3T0689 继电器 7K9208 油封 5I8012 气门座 3T1815 报警器 7K9210 油封 5I8018 增压器 3T2
094 轴套 7K9211 油封 5I7738 气门 3T4215 塞子 7K9212 油封 5I7739 气门 3T4615/1174013
套子 7K9680/1870424 修理包 1838172 导管 3T4616/1174013 轴承 7L5452 垫子 1838173 导管 3T
4705 碳刷架 7M4046 凸轮瓦 5I7733/5I8002 气门室垫 3T4712 卡子 7M4046 凸轮瓦 5I5129/A89
柱塞 3T6353 调节器 7M4707 皮带 5I5130/12A 出油阀 3T6795/7G3909 活塞 7M4715 皮带 5I7
713/118 喷油头 3T7726 小滤网 9W9831 7M4715 皮带 5I7507 输油泵 3T9960 摩擦片 3V2351 卡

环 517511 手油泵3T9960 摩擦片 3V5571 压条 517648 缸垫3T9960 摩擦片 1252927/39A 出油
阀 1905858/A758 柱塞/6Y1936 1932750 喷油头276回油阀 2812725 (2380296) 水位传感器 2
399957 (1656634) 风扇支架 1P9946风扇支架暗销 4N0684风扇支架 6N6490手油泵 1375541 (1597324
) 缸盖 154-1612缸盖垫片 110-6991缸套 211-7826O环衬垫 7N-2046排气门 210-2529进气门 210-25
42气门座垫 130-2607排气门垫片 130-2608气门导管 133-9306进气门弹簧 194-4902排气门弹簧 281-6
157活塞环 278-0247中间活塞环 144-5695上活塞环 214-6066油环 223-6361标准主轴瓦
149-6031止推片 7c-6029标准连杆轴瓦 107-7330喷油器总成 162-8809海水泵 5N-5757增压器总成 12
1-57361994496 SHAFT-PINION 4E9408 BEARING1505870 SHAFT 1865690 BEARING-
SLEE4I5693 CYL GP 1226566 BEARING2092917 CYLINDER GP 1882258 BEARING1850165 CYL
GP-0180 4E9374 BEARING1211512 CYLINDER 4E9376 BEARING2358969 BRACKET-
MAST 2453805 BUSHING-TRK2358970 CONTROL GP 2453806 BUSHING-MSTR2475275 CONT
GP-PEDA 2P9419 RING-THRUST2431276 BELT 2453808 RING-THRUST3109714 COUPLING GP-
1476982 MOUNT-RUBBER1740217 LINK-TRK-RH 1476983 MOUNT-RUBBER1740218 LINK-TRK-
LH 1740219 PIN-TRACK1740224 SHOE-TRACK 2532742 PIN-TCK MSTR2276098 GEAR GP-
BRG 7y5241 BOLT2011704 SPROCKET 2642171 tip3004611 ROLLER GP-
TR 1250800 PROTECTOR1484602 GEAR-PLANET 1559224 PUMP GP-GR A1484600 GEAR-
SUN 3350029 PUMP GP-2PS-1484601 GEAR-SUN 3362213 PUMP GP-WATE1484604 GEAR-
RING 1654962 PUMP G-MOTOR1484603 GEAR-PLANET 1709918 PUMP GP1484626 DRIVE GP-
SWI 2667953 PUMP GP-PS-B1484598 DRIVE GP-SWI 3050325 COMPRESSOR G1994661 DRIVE
GP-FIN 1398878 SPIDER AS4N2514 GEAR 1398877 SPIDER AS1560622 SWIVEL
GP-03 1832823 PUMP AS-F PR9X4600 SEAL 3166864 PUMP GP-F
XF1135950 SEAL 2530616 INJECTOR GP-7X4803 SEAL 2967635 TURBO GP-
BAS1038236 RING 2959447 MOTOR GP-PSF2481537 SEAL AS. 2959446 MOTOR GP-
PSF2448697 SEAL AS-MSTR 2095859 GUARD-ALTERN1982948 SEAL-SWIVEL 2478978 MOTOR
GP-PIS9X4597 SEAL LIPTYPE 2254614 MOTOR GP7X4803 SEAL 2457836 CORE AS-
EVAP095-1687 O-RING 1295429 CORE AS6D0692 SEAL O RING 2813516 CORE AS-O
C6V7681 SEAL 4t6788 OIL FILTER095-1633 O-RING 1850337 FILTER AS-HY095-1728 O-
RING 1799806 ELEMENT1223772 SEAL O RING 1469290 FILTR
ELEMEN1V6341 SEAL 2931137 FILTER AS4M0189 SEAL O RING 1r1808 FILTER AS-
LU1880210 GASKET-RAIL 1327168 ELEMENT A1S4295 GASKET 1063973 ELEMENT
AS9Y8389 GASKET 3261641 FILTER AS2159996 SEAL KIT 3435527 BOWL AS FUEL1211597 SEAL
KIT 1r0755 FILTER A2160000 SEAL KIT 2379147 VALVE GP-TE51948258 SEAL
KIT 1119997 VALVE G2095980 SEAL KIT 2095937 VALVE GP-COM2526101 SEAL
KIT 2042730 VALVE GP-COM6Y0473 PLUG 2478762 VALVE
GP7G4332 STOPPER 1946722 SENSOR GP-PR1452970 BOLT 1946725 SENSOR GP-
PR1740221 BOLT-TRACK 2393478 SENSOR GP-PR1740222 NUT-TRACK 2644297 SENSOR
PG5P8247 WASHER 2705620 CONT GP-HAND1994501 SPACER 2622879 CONT GP-
E2B7558 CORK 1512106 CONT GP9U8693 BEARING 2075262 CONTROL
GP7I7619 BEARING 1895746 SENSOR GP-SP1912514 BEARING AS 1918303 SENSOR G-
SPD1912513 BEARING AS 2016617 SENSOR GP-SP1865688 BEARING-SLEE 3439866 HARNESS
AS.-4E8732 BEARING 2395929 HARNESS AS4E8734 BEARING 1562829 SOLENOID
GP4E8735 BEARING 1779953 ALTERNATOR G1865689 BEARING-SLEE 2727123 MOTOR GP-
ELE 3277482 MONITOR GP-O4N3181卡特彼勒 3A1872 4N3182 D7 CAT KICK STARTER
33063T8950 7N8604 3T2781 D8 CAT KICK STARTER
D83P6816 9S9384 CAT TRANSMISSION PUMP D6/D8
ITR3T1446 3T1445 CHARLES CAT TRANSMISSION PUMP D6H D7H1150637 2P9239 D7
D8? CAT TRANSMISSION PUMP D7 ITR

BOSCH 0120240038 BOSCH 0122469001 BOSCH 0122469003 CATERPILLAR 0R2698
CATERPILLAR 0R5217 CATERPILLAR 3N2702 CATERPILLAR 3N2706 CATERPILLAR
3T6352 CATERPILLAR 3Y6691 CATERPILLAR 3Y8200 CATERPILLAR 5A8908

CATERPILLAR 5N5692 CATERPILLAR 6N5217 CATERPILLAR 6N9249 CATERPILLAR
6N9294 CATERPILLAR 7N9720 CATERPILLAR 7T6172 CATERPILLAR 9G8255
CATERPILLAR OR2698 CATERPILLAR OR5217 CUMMINS 210227 CUMMINS 3016627
CUMMINS 3016627RX DELCO/FORD 1117615 DELCO/FORD 1117619 DELCO/FORD
1117622 DELCO/FORD 1117623 DELCO/FORD 1117640 DELCO/FORD 1117642
DELCO/FORD 1117643 DELCO/FORD 1117645 DELCO/FORD 1117647 DELCO/FORD
1117655 DELCO/FORD 1117665 DELCO/FORD 321665 DENSO 1002110860 LEECE
NEVILLE 2303JB LUCAS LRA02479 LUCAS LRA2479 VALEO A13R182
2P0661 73 ---- Waterpump GP*R8M1584 133 18 *Valveservice
Group4N4314 135 ----- Fuellprimingpump GP7N0950 136 ----- Waterseparator
GP11D5800 14A.02 3 Under - CilinderW6134 14A.02 4 Band - Tiller5S6670 14A.02 5 Seal - O
- Ring [117.1 mmid]4W5739 18A 5 Bearing - Konnecting Rod7S9404 16A 9 Ringgp -
Piston3N0519 147J ----- Startings Motorrs 24V3T4704 147K 2 Solenoid As Start
Motor4M1868 147K 10 Armature3T4712 147K ----- Hollder AS9G4513 147K 32 Bushing -
Terminal9G9817 147K 47 Bushing - Terminal4M1853 147K 51 Lever AS -
Shift6N3827 147K 58 Drive AS motorCATERPILLAR 2A4429CATERPILLAR 8T6678CATERPILLAR
1153657CATERPILLAR 1909861CATERPILLAR 1W8922CATERPILLAR 1609874CATERPILLAR 6V989
2CATERPILLAR 5L8854CATERPILLAR 5S2106CATERPILLAR 9F4446CATERPILLAR 1313815 / 101070
0CATERPILLAR 8C3100CATERPILLAR 7L0520CATERPILLAR 1152367CATERPILLAR 1737188CATER
PILLAR 1W5283CATERPILLAR 4N7253CATERPILLAR 2N2766CATERPILLAR 4S6137CATERPILLAR
4N0933CATERPILLAR 3178766CATERPILLAR 4W5698CATERPILLAR 9Y9497
FP3285574CATERPILLAR 9Y7735 FP3285573CATERPILLAR 4W5702CATERPILLAR 1152368CATERPILL
AR 4W2474CATERPILLAR 4N5893CATERPILLAR 4W2471CATERPILLAR 4W2472CATERPILLAR 4
W0788 / 1052508CATERPILLAR 1P0436CATERPILLAR 4N2927CATERPILLAR 1017788CATERPILLAR
7W0688CATERPILLAR 1282922CATERPILLAR 7C0307CATERPILLAR 2322922CATERPILLAR 122377
2CATERPILLAR 1090077CATERPILLAR 1090076CATERPILLAR 3056843CATERPILLAR 4N6658CATE
RPILLAR 4N0685CATERPILLAR 1H7339CATERPILLAR 3E6747CATERPILLAR 4P7688CATERPILLAR
1317123CATERPILLAR 2223909CATERPILLAR 1538920CATERPILLAR 1393526CATERPILLAR 4C5
599CATERPILLAR 3E8017CATERPILLAR 1548030CATERPILLAR 2165586CATERPILLAR 1478218CAT
ERPILLAR 1478211CATERPILLAR 1409670CATERPILLAR 1478220CATERPILLAR 1457390CATERPIL
LAR 1853241108-5912 7W1650 1078769 5S-5918 1W-5283 122-0321 7W-1650 03022597 5T-4374
1W-5300 122-0322 7W-1938 03081817 6I-0497 202-7475 122-3772 7W-6570 03200250 6J-7855
205-0640 130-4698 7 -7977 03253556 6L-2282 211-0592 133-7029 8B-7624 03388097 6N-7174
216-1252 134-3761 8L-2786 03404142 6N-8659 219-7007 134-9807 8N-3639 03425212 6V-1394
227-1204 143-6626 8N-3640 03443751 6V-3508 227-2902 143-6628 8N8418 03549631 6V-3538
246-3274148-7425 8N8446 03549656 6V-3916 251-1005 148-7455 8N8447 3549821 6V-3935
263775-1152-8380 8N-8451 03549862 6V-3959 2A-4429 154-4580 8V-0295 03549888 6V-3968
2B-0947 160-9874 8 -5249 03549896 6V-3971 2L-2094163-1533 9F-8127 03549896 6V-4589
2P-2817 166-2903 9H-1113 3549920 6V-5049 2W-6078166-2904 9S-4191 03551413 6V-5052
2W-9162 173-7188 9X-6458 03614757 6V-5055 2 -3931 189-4583 9Y-3307 03616141 6V-5063
354-9648194-0629 9Y-6232 3690682 6V-5095 355-1322194-0630 9Y-7735 03690807 6V-5102
355-1470197-9251 9Y-9842 03690807 7C-2422 394-2794197-9322 9 -7430 03691094 7C-2424
3B-0623 1L-5072 OR9851 3691318 7C3371 3B-4505 1L7340 OR9856 03691326 7C3372 3E-6772
1L-8497 RA3372 03831047 7C3374 3E-7471 1P-1111 OR9858 03859535 7E-7202 3F-2065 1P-1123
4W5108 03915303 7F3538 3J-7354 1W-0022 4W-5441 0S-1588 7F5151 3J-7719 1W-0098
4W-5739 100-7860 7L8424 3K-6905 1W-1748 4W-7391 100-8150 7L-9061 3N-7281 1W-1749
4W-7394 105-5081 7N-0170 3P-0658 1W-1752 4W-8344 107-0265 7S-7144 3P-1896 1W-1756
5F-3999 107-0268 7W0016 3S-8313 5N-8372 5K-7138 5P-7701 4P-3873 4B-4910 5N-8374
5M-4606 5P-8429 4P-4113 4N-1151 5N-8375 5N-8381 5P-8768 4W-0695 4N-5893 5N-8377
5N-8390 5P-8861 5N-8380 5P-0840 5N-8379 5N-9574 5P-9514 气门盖垫 2256451O型圈 150
7732曲轴瓦 3537423连杆轴瓦 2984524止推片 329090止推片 329091活塞 3109269连接衬套 2255438

进气门 3153390 排气门 3153394 气门油封 2526438 气门油封 2543954 活塞冷却喷嘴 2765605 皮带盘固定螺栓 喷油器总成件 315-3381 空滤总成 1102556 预热塞 水箱底座垫 320-9211 垫圈 101-7539 垫圈 101-7540 螺栓 100-4461 螺栓 101-7541 连杆总成 225-5441 连杆螺栓 2255439 AS 燃油管路 232-9759 AS 管 236-2144 燃油过滤器和管路 357-4187/299-9265 AS 排放管 324-6505 AS 排放管 232-1794 AS 排放管 232-1328 曲轴总成 359-0715 气门导管 1850882 进气门座圈 3229663 排气门座圈 3229664 柴油滤芯 3574 187/2999265 机油泵 2258329 气缸套 喷油器垫圈 1408718 喷油器 O 型垫圈 2751038 燃油泵 O 垫圈 15239 68 柴油滤芯 1R1804 机油滤芯 7W2326 缸盖衬垫 2584946 曲轴前油封 2880422 曲轴后油封 2327449 发动机前壳体垫片 2773012 发动机前壳体盖垫片 2268766 油底壳垫片 2256005 机油滤芯座垫片 2257944 机油冷却器壳体垫片 2722265 机油冷却器壳体垫片 2256818 增压器垫片 1945390 排气管垫片 2258536 增压器管路垫片 2258530 增压器管路垫片 2258533 增压器管路垫片 2258534 进气管垫片 2343030 凸轮轴瓦 23274405 P8953 修包 1N4320 主轴瓦 8H1994 气门 1N4332 BEARING 8N7924 修包 6V1395 修包 1N4338 轴瓦 5H5992 7N4160 开关 1N4324 轴瓦 1N4322 主轴瓦 7S8308 .050 5P9221 修理包 5P8955 修包 7S9859 V 型皮带 9M8745 气门座 4K8659 轴承 1N3601 环 G 6K4197 轴承 8M9810 气门座 1N4321 主轴瓦 7N5036 活塞 9M1068 机油泵 6K2697 轴承 1N4333 轴瓦 8M4014 气门座 4N5390 皮带轮 5P8949 修理包 5P9550 修包 5S1757 进气门阀座 8N7935 连杆瓦 3E3278 修理包 5H2788 泵 1N4319 轴瓦 3K1650 开关 8N1985 衬套 1261818 空气滤芯 611210 CROWN AS 6N1813 燃油泵 4M9275 4M1868 ARMATURE A 4N4875 泵 7S3033 轮毂 7W8064 进气门 1051746 活塞环 4M4431 轴 9K0735 CYLINDER G 2W7213 轴承 7N2051 导管 8N7930 凸轮轴瓦 7S3688 活塞 1N4337 轴承 5M5345 V 型皮带 7C6976 连杆瓦 7M0323 ARMATURE A 2W9128 ROD A 7X2521 修理包 1157550 GASKET 3K0158 密封 7C3570 密封组件 7C3901 活塞销 4P1549 活塞裙 8M5070 摩擦片 6V2507 修理包 9S6387 修包 7X2525 修理包 2W7211 轴承 5P9115 修包 7W9414 轴承 7W9415 连杆瓦 7W5903 散热器芯 2P6538 消声器 9S1195 机油泵 2P8624 皮带 7W9417 轴承 5M2667 垫圈 6P8262 环 8H9155 密封 9J5110 密封包 (SEP) 7C6208 缸套 6L7816 密封 1058919 机油表 7H9803 壳体 9S6386 修包 8T1472 密封包 9S3138 密封包 9S3135 组件 7C6966 轴承-THRU 8T1382 KIT-密封 8T1375 密封包 9H0415 环 2P2698 管 7S3687 空气滤芯罩 2S6442 环 1P6442 垫圈 8T1410 密封包 2V9448 修理包 9P2946 环 .030 OVER 9S6338 CYLINDER 1M4093 环 6V9884 KIT TUNE UP 8T1462 密封包 2W6681 底座 9X4823 磁力开关 8S0557 环 7C6971 主轴瓦 7C6961 主轴瓦 8S0558 环 6D1904 BIT 8T1479 密封包 9H0438 环 8T1401 密封包 6V4705 修包 6K2430 密封 8T1398 密封包 1T0309 环 8T1411 密封包 7W3278 缸盖 2S6443 STD.环 8T1461 密封包 7D9999 END BIT 2P1776 BELL A 1T0233 环 8T1385 密封包 9H5548 密封 8T1379 密封包 3G5307 接头 8T1473 密封包 8J9821 刀角 1U3302 斗齿 5J4773 螺栓 8N6000 HEAD A 8T1384 密封包 8T1434 密封包 9X1439 灯 5D9554 GRADER BLADE 7N1164 Mount 4K8033 灯 7N3630 缸盖 1T0542 轴瓦 9S3068 活塞环 2S3966 动环 4N7562 表 2N2839 火花塞 9N6289 水泵修理袋 8L4296 汽化器修理包 1H8278 密封 2W7100 增压器涡壳 7W4358 火花塞胶杆密封 7W8542 高压器塞子 2550025 气缸盖 2N0553 火花塞 6J2244 O 型圈 6V3019 调节螺钉锁紧帽 3S3535 静环 1927870 连杆瓦 5P4889 O 型圈 7E8215 活塞环气环 2N2560 水泵密封 2404641 活塞 4P8958 活塞环 1R0659 机油滤芯 5P7815 O 型圈 2044385 气门调节螺钉 1S1638 垫子 1791502 机油滤芯 7E1630 垫片 2181915 球座 4N4688 呼吸器总成 1059741 空气滤芯 6V3602 气缸头罩壳垫子 6V1179 O 型圈 1G8878 空气滤芯 1495150 予油滑压力传感器 1919346/2326351 变压器 1952431 爆震传感器 1593219 燃烧传感器 1085603 气门调整螺母 7N1903 气门内弹簧 1409669 液压油压力开关 1976999 弹簧上垫圈 7C7886 活塞环 1W0098 连杆螺栓 1432878 气缸垫 2136967/2550028 缸盖总成 1520807 缸套水温传感器 3P0647 密封 7N1904 气门外弹簧 1308299 排温传感器 (增压器) 2090962 弹簧下垫圈 1976980 单流阀座套 7C1413 活塞销卡簧 7W4377 变压器 9L7712 气门调整螺母 1S5772 垫片 5P2725 适配器 5P3591 适配器 1216159 模块 1017685 继电器 1364605 火花塞延伸头 7W3668 活塞 7E3056 导线 1638523 机油压力传感器 3E7573 继电器 9M5590 钢珠 4W7749 垫片 0870546 继电器 1715900 单流阀 6V4368 O 型圈 3K8782 保险丝 7W1650 起动马达齿轮 6I2313 密封圈 9Y6792 火花塞垫片 8C3680 冷却剂 1W9460 活塞环 9X1124 传感器 4W5870 直流电流表 4N4946 皮带轮 1P8482 滤芯 7N7078 活塞环 1W0703 燃油压力表 5P8245 垫片 5L7443 传感器 8S9089 螺栓 1W6280 缸套 6N6653 风扇皮带 1D4719 螺母 2P2817 活塞环 5S9088 发电机 2W1709 活塞环 5P8771 修理包 2P3858 SLEEVE 8S1605/1118015 气门室上盖软底垫 7S3206 密封 8M7892

电表 0937521 液压油滤 6I2504 ELEMENT AS 2W3747 高压器总成 4N6658 凸轮轴衬套 6V2547
燃油系统修理包 4W6168 增压器涡轮 1684531 活塞16:1 1N3576 缸体 6L4714 空滤 4N0685
凸轮轴衬套 2W6000 缸套 8N6796 气缸盖 6I2509 ELEMENT AS 3S4031 活塞环 9Y2623
曲轴(裸轴) 1077548 活塞环 1H3654 988B万向节螺栓垫片 1S7374 卡环 1S9498 环 1U2281 卡环
2M0340 O型圈 2M4453 密封 2S4078 O型圈 3B6753 螺栓 3G1797 油封 3S9634 节温器油封
3N4851 水泵 7E6843 水泵 1018314 排气门 6I4014 排气圈 7C3372 启动气马达 4W5108
启动气马达 0R9857 启动气马达 4W5103 启动气马达 7W0017 启动气马达 0R9858 启动气马达
7W0016 启动气马达 1054324 启动气马达 4W5106 启动气马达 1406905 启动气马达 0R9855
启动气马达 6N7855 启动气马达 6N6002 启动气马达 7W8587 启动气马达 0R9853 启动气马达
7W8589 启动气马达 1230231 启动气马达 4N4370 启动气马达 6N3789 启动气马达 1297563
启动气马达 0R1051 启动气马达 1642032 启动气马达 1544576 启动气马达 1544580 启动气马达
6N6608 启动气马达 1435162 启动气马达 6N6003 启动气马达 0R9852 启动气马达 1335962
启动气马达 1406909 启动气马达 1077862 启动气马达 6N4147 启动气马达 1065521 启动气马达
1435169 启动气马达 1544577 启动气马达 1406913 启动气马达 1189045 启动气马达 1544578
启动气马达 1701133 启动气马达 4N4368 启动气马达 1077859 启动气马达 5N8775 启动气马达
2W2262 启动气马达 4W5101 启动气马达 8N8473 启动气马达 6N9550 启动气马达 1544579
启动气马达 4Q5612 启动气马达 8N8418 启动气马达 8N8474 启动气马达 1054035 启动气马达
2W5511 启动气马达 7C3374 启动气马达 6N9133 气缸床垫 0R9851 启动气马达 5N8788
启动气马达 4W5110 启动气马达 5N8789 启动气马达 1077861 启动气马达 4W5105 启动气马达
6N1633 启动气马达 4W0697 启动气马达 6N4148 启动气马达 4W5109 启动气马达 5N8773
启动气马达 8N8475 启动气马达 4W5104 启动气马达 1378397 启动气马达 1055080 启动气马达
1055081 启动气马达 4W5102 启动气马达 4W5732 启动气马达 4W6633 启动气马达 5N7898
启动气马达 4W5107 启动气马达 0R9856 启动气马达 6N6456/4N0590 发电机 5N5692 发电机
4N3181 启动机 3T8950 启动机 2113025 喷油器 6V4707 燃油泵修理包 3306 8S3656 柱塞 6N2766
柱塞 7S6681 柱塞 9 mm 7W5928 柱塞 9H5796 柱塞 8 mm 8N3539 柱塞 9 mm 7W7026 喷油嘴
9L6969 喷油嘴 7W7030 喷油嘴 7E3969 喷油嘴 9N6173 油嘴 7W7032 喷油嘴 4N4997 柱塞 10
mm 9N2366 喷油嘴 7W3710 喷油嘴 7W7038 喷油嘴 8N7003 喷油嘴 7E6007/1082104 柱塞总成
9N3299 油嘴 1W3010 柱塞 9N3246 D/F 油嘴 7W7024 喷油嘴 4S7913 柱塞 4W7016 喷油嘴
4W7021 喷油嘴 4W8483 油嘴 4W1819 油嘴 4W7022 喷油嘴 1278218 喷油器 6V9223
燃油泵修理包 3406B, 825C 6V9725 燃油泵修理包 3406B 7E5085/2M4314 衬套 6V8908 燃油泵修理包
936 6V7461 燃油泵修理包 3304 6V6368 燃油泵修理包 1693 6V9245 燃油泵修理包 3406 7M7431
喷油嘴 6V5425 燃油泵修理包 G379 6V5455 燃油泵修理包 D379, 3398 6V5494 燃油泵修理包 D379
6V9701 燃油泵修理包 D399 7N1415 垫片 6V5459 燃油泵修理包 D379, D398 6V5497 燃油泵修理包
3406 6V9715 燃油泵修理包 3406 7E6006/1086633 泵总成 6V9894 燃油泵修理包 3406B 7N1208
弹簧 7N7264 重锤 7X7971 燃油泵修理包 3176 6V8575 燃油泵修理包 1676, D336 6V6369
燃油泵修理包 1693 7X2633 燃油泵修理包 3406B 7N1220 柱塞 10 mm 6V9710 燃油泵修理包 D399
7N1219 燃油泵 风扇皮带 9L——6641DF交流发电机皮带 4N——8216DF空气滤芯(内.外) 外151-773
7, 内189-0202柴油滤清器 1R——0781柴油粗滤器分离杯 机油滤清器 1R——0716(二:C-18配件)
序列号: WJW00281 柴油粗滤器分离杯 风扇皮带 空气滤芯: 内芯 106——3973空气滤芯: 外芯 1
06——3969发动机专用卸滤器扳手 c18柴油滤清器 1R-0771c18机油油滤清器(三:12V190配件) 1
90柴油机空气滤芯(内.外) 内: 12VB.36M.50; 外12VB.36M.40风扇皮带 15J-2120离心过滤器总成 12V
B.19.00启动预供油泵 2012.54.00喷油嘴总成一组 机油滤芯 12VB.18.10B柴油滤芯 12VB.10.30.03柱塞
偶件弹簧 Z12V.12.14A 水泵 12VB.22.00B水泵水封与上配套 129.22.00B
手油门 190柴油机启动气马达 701.46F .60柴油输油泵 235.11.00216-9872 6/pc161-3425
6/pc168-7209 6/pc197-9299 6/pc205-1320 1/pc115-4072 1/pc1R-0762 1/pc210-5522
1/pc10R-1984 1/pc167-0166 1/pc2A-4429 4/pc119-2921 1/pc187-8961 1/pc187-1315
1/pc163-2478 24/pc166-1781 1/pc190-6114 1/pc217-5701 1/pc5P-5678 1/pc9M-1974
11/pc8C-0563 12/pc208-2833 1/pc135-2142 1/pc1R-1808 1/pc1106991
12/pc7E7581 12/pc8N1234 12/pc7W2221 12/pc8T6732 gasket kit8T6731 gasket
kit8C3792 gasket kit7X2846 gasket kit7W3202 seal1W0311 liner9L7735 seal1003652 shaft thrust
plate9N5246 bearing1W5920 shaft bearing7N9803 pin8N7294 stopper9L6233 o-ring7E7297 o-

ring7C1146 piston1N3821 piston liner9N6275 bushing型号与规格 零件号码滤清器滤芯：9T9054，CAT 9T9054卡特彼勒171-4400的通讯适配器总成,带通讯电缆，软件光盘 3177484柴油滤清器总成（带油水分离器）:129-0372，CAT 1290372BOWL/1290372 129-0375ELEMENT-FILT 133-5673手油泵安装座 141-5138 配3126B柴油机,CAT 1415138机油喷射压力电控阀122-5053 valve gp-solenoid,CAT 1225053涡轮增压器胶管:1165
159-2829,CAT 1592829柴油滤芯：3261643(升级前1R-0771) CAT柴油机用 3261643机油滤芯：1R-1808 CAT柴油机用 1R1808 空气滤清器滤芯 1063973，Caterpillar 1063973空气滤清器滤芯1063969，Caterpillar 1063969空滤指示器:145-4212,美国/卡特比勒公司 1454212油门位置传感器：219-2384-00，CAT卡特彼勒 266-1473水温传感器：WZB-269 BAI IG18NI9TI
量制04210104，配常州600机车，CAT3412发动机 无号变速箱过滤器总成：8E-4269，美国/卡特彼勒公司 8E4269变速箱过滤器总成：6P-4603，美国/卡特彼勒公司 6P4603手油泵：CAT 4N3287.PUMP GP-FUEL PRIMING 4N3287手油泵：137-5541，CAT柴油机用 1375541手油泵：105-2508，CAT柴油机用 1052508断路器：3E-7294(105AMP)，CAT柴油机用 3E7294起动继电器：5803，8F124，118-3534，CATERPILLAR 1183534滤清器：102-2828 CAT 1022828喷油器总成：INJECTOR
零件号：178-0199，配在CAT的3126B发动机上使用 1780199液压油过滤器：1R-0773，CAT柴油机用 1R0773液压油过滤器：1R-0773，CAT柴油机用 1R0773空滤器一级滤心：6I-2509，CAT柴油机用 6I2509空滤器二级滤心：6I-2509，CAT柴油机用 6I2509空虑外芯：6 - 2509，CAT柴油机用 6I2509空虑内芯：6 - 2506，CAT柴油机用 6I2506传动箱虑芯：1R - 0719，CAT柴油机用 1R0719柴油滤清器：1R-0712;CAT: 1R-0749滤清器：218-4142
CAT 2184142燃油滤芯（粗）:326-1644（IR-0770）CAT 3261644过滤器:4S-8598
美国卡特彼勒 4S8598空滤器：124-3237，卡特彼勒(CATerpillar) 1243237空滤器滤芯：106-3969? CAT柴油机用 1063969空滤器滤芯：106-3973? CAT柴油机用 1063973柴油滤芯1R-0762美国/卡特彼勒公司 1R0762空滤器外芯6I-0273美国卡特比勒公司 6I0273空滤器内芯6I-0274美国卡特比勒公司 6I0274机油滤芯1R-1807美国/卡特比勒公司 1R1807传动箱滤芯1R-1809美国/卡特比勒公司 1R1809卡特ET检测仪：317-7484，CAT ET Adapter III Comm 3，CAT 3177484起动马达：PART NO 207-1517 CONSIST 207-1517 24G 01L06
10476961:CATERPILLAR 2071517起动马达：6V-0890，CAT柴油机用 6V0890CAT C-10发动机冷却液温度传感器264-4297 2644297CAT C-10发动机燃油温度传感器264-4297 ? 2644297CAT C-10发动机燃油压力传感器1946725（升级前194-6925）1946725CAT
C-10发动机大气压传感器161-1703 1611703CAT C-10发动机发动机机油压传感器161-1705 1611705CAT C-10发动机补用机转速/正时传感器191-8304 1918304CAT
C-10发动机进气歧管内气温度传感器264-4297 2644297CAT 836G变扭箱温度传感器 1310427 1310427柴油机转速表：P/M153-8059.03,9 × 116，RPM，CAT 用于G221/JX-3DT接触网作业车 1538059柴油转速表：153-8059，CAT柴油机用 1538059组合仪表：166-6936，CAT柴油机用 1666936主显示单元：198 - 9749，CAT柴油机用 1989749转速表:117-9016
CAT 1179016空气滤清器堵塞标志:7S-0687,CAT 7S0687空气滤清器滤芯:132-7165，CAT 1327165空气滤清器滤芯:6I-2504，CAT 6I2504发电机皮带:5H-4207DF，CAT 5H4207组合仪表（进口件）:132-8044 CAT 1328044主显示单元（进口件）:133-4850 CAT 1334850压力指示器:CAT：8N-2694 8N2694油门开度调节器（进口件）:161-8906（CAT）266-1473温度传感器（进口件）:131-0427（CAT）1310427压力传感器（进口件）:161-9932（CAT）1619932油门开度调节器:166-0690
REV00,CAT 1660690液力油滤清器:1G-8878,CAT 1G8878换向换档控制手柄:299-5840(旧201-0212)，CAT 2995840起动马达: 2371962（升级前6V0890），24V，CAT 338-3454充电发电机:(CAT),3E7577 3E7577柴油减压阀:(CAT),4W1968,DAMPER-SURGE 4W1968柴油管:(CAT),6N4379 HOSE AS 6N4379柴油管:(CAT),6N4376 HOSE AS 6N4376柴油管:(CAT),6N4377 HOSE AS 6N4377柴油管:(CAT),6N4378 HOSE AS 6N4378机油压力表:CAT：2W-3681 2W3681柴油压力表:CAT：2W-3687 266-0889转速传感器:CAT3E,7886 3E7886PLUG KIT/3E3362 155-2270CONNECTOR 8T-8730SENSOR GP/1895746 318-1181空气滤清器滤芯:CAT：6L-4714 6L4714燃油滤芯 1R-0751 美国卡特彼勒公司 1R0751起动电磁开关总成：2068784，CAT3216B型柴油机 2068784密封圈:2S-8439，CAT 2S8439机油滤清器滤芯:1R-0716，CAT 1R0716柴油滤清器滤芯:1R-0749，CAT 1R0749粗滤器:129-0372,CAT 1290372BOWL/1290372 129-0375ELEMENT-FILT 133-5673柴油油水分离器:129-0372,CAT 1290372BOWL/1290372

129-0375ELEMENT-FILT 133-5673柴油油水分离器:129-0373,CAT (新型号为133-5673) 133-5673发电
机皮带:CAT , 3L-7540 , DF (490E : 12) 7L-7099软管卡箍 : 9M-2904 , CAT柴油机用 9M2904