

1746-OBP8 安装底座

产品名称	1746-OBP8 安装底座
公司名称	厦门亿佳天辰贸易有限公司
价格	453.00/件
规格参数	AB:5464 1756:124 美国:234
公司地址	厦门市湖里区枋湖西二路3号338室之五（注册地址）
联系电话	0592-6057707 18064452363

产品详情

1746-OBP8 安装底座

这些PLC的用户程序由主程序、子程序和中断程序组成。在每一个扫描循环周期，CPU都要调用一次主程序。主程序可以调用子程序，小型控制系统可以只有主程序。中断程序用于快速响应中断事件。在中断事件发生时，CPU将停止执行当时正在处理的程序或任务，去执行用户编写的中断程序。执行完中断程序后，继续执行被暂停执行的程序或任务。它们的子程序和中断程序没有局部变量，子程序没有输入、输出参数。

西门子的S7-200的程序结构

过程映像输入/输出（I/Q）、变量存储器V、内部存储器位M、定时器T、计数器C等属于全局变量。S7-200的程序组织单元(ProgramOrganizationalUnit，简称为POU)包括主程序、子程序和中断程序。每个POU均有自己的64字节局部变量，局部变量只能在它所在的POU中使用。与此相反，全局变量可以在各POU中使用。

下面是子程序可以使用的局部变量：

1)TEMP(临时变量)是暂时保存在局部数据区中的变量。只有在执行该POU时，定义的临时变量才被使用，POU执行完后，不再保存临时变量的数值。

2)IN是由调用它的POU提供的输入参数。

3)OUT是返回给调用它的POU的输出参数(子程序的执行结果)。

4)IN_OUT是输入_输出参数，其初始值由调用它的POU传送给子程序，并用同一变量将子程序的执行结果返回给调用它的POU。

主程序和中断程序的局部变量中只有临时变量TEMP。

Swagelok Process out stick 809-470314915A

APPLIED MATERIALS ION / TC BOX CONTROLLER, 01-81911-00

LAM ASSY, PCB, ADIO - AO, 810-017031-004

Leitz Wetzlar PL Fluotar 50x/0.85 567013

GRANITE MICROSYSTEMS COMPUTER, 1 GHZ, 256M RAM

FURON VALVE 3-WAY PNEUMATIC MOB3-122HP

Entegris Pressure Transducer 41501-110G-F04-?B12-A-S3

Entegris 1" PFA Hand Valve, DS16-2ML-16F

Semitool 200MM End Effector Stiffen Style

SIMCO Ionization Kit 4009012

SIMCO Ionization Kit 4008899

Fortrend Model F8225 Wafer Transfer Unit

Microvision MVT 1080 Wafer Inspection Station, used

Acopian DC Power Supply A75HT560 MRC Eclipse Star

DNS Hot Plate Assembly For Model 60A, 150mm

CUTLER-HAMMER CIRCUIT BREAKER, HFD3175L

D SQUARED TRANSFORMER, 45T3HFI5NLP

BLOWER In Great Condition

Front End Load Port

MICROPUMP HEAD L15368, 2170/56C

USHIO UV LAMP SUV-2002NIL

USHIO UV LAMP SUV-2011NI

White Knight AP-200 Pump Rebuild Tool Set KC-AP20-170

Schumacher ELOI Overlay, 1495-3174

Air Products, Spill alarm cable assembly, 2103-3615

AXIOMTEK COMPUTER ASSEMBLY BOARD SBC8360/ 73300-33

FUJI CIRCUIT BREAKER 150A 3PL GFI ELB EG203B

Mykrolis Stainless Steel Filter Housing KC-YY55P8000