

市场推送：8500300103福州到各地省市县区域/直送2023全+境+派+送

产品名称	市场推送：8500300103福州到各地省市县区域/直送2023全+境+派+送
公司名称	福建中立恒自动化设备有限公司
价格	.00/件
规格参数	
公司地址	福建省福州市鼓楼区温泉街道五四路9号宁德大厦（宏福大厦）10层1064室
联系电话	15659159037 15659159037

产品详情

主营产品：DCS集散式控制系统、PLC可编程控制器、数控系统、

(CPU处理器、模块、卡件、控制器、伺服驱动、工作站、驱动器、

马达、内存卡、电源，机器人备件等)各类工控产品

BRONKHORST F-201AC-FAC-99-V AIR 50 LS_MIN

BRONKHORST HI TEC MFC F1C0-FA-88-P AsH3 1 ls/ min NOT IN BOX FREE SHIP

BRONKHORST HI TEC MFC F1C0-FA-88-P H2 1 ls/ min NOT IN BOX

BRONKHORST HI TEC MFC F1C0-FA-88-P H2 100mln /min NOT IN BOX FREE SHIP

BRONKHORST HI TEC MFC F1C0-FA-88-P H2 10mls/ min NOT IN BOX FREE SHIP

BRONKHORST HI TEC MFC F1C0-FA-88-P H2 30m1n / min NOT IN BOX FREE SHIP

BRONKHORST HI TEC MFC F1C0-FA-88-P H2 30mls/min NOT IN BOX #2

BRONKHORST HI TEC MFC F1C0-FA-88-P H2 500mls /min NOT IN BOX FREE SHIP

BRONKHORST HI TEC MFC F1C0-FA-88-P H2 500mls /min NOT IN BOX#2

BRONKHORST HI TEC MFC F1C0-FA-88-P MIX 30 m1s /min NOT IN BOX FREE SHIP

BRONKHORST HI TEC MFC F1C0-FA-88-P MIX 500 m1s/ min NOT IN BOX FREE SHIP

BRONKHORST HI TEC MFC F1C0-FA-88-P PH3 3 1s/ min NOT IN BOX FREE SHIP

BRONKHORST HI TEC MFC F1C1-GA-88-P PH3 1 1n /min NOT IN BOX FREE SHIP

BRONKHORST HI TEC MFC F1C1-GA-88-V H2 1000 m1n/ min NOT IN BOX FREE SHIP

BRONKHORST HI TEC MFC F1C1-GA-88-V H2 200 m1n/ min NOT IN BOX FREE SHIP

BRONKHORST HIGH-TECH F1C0-FA-88-P 300m1s min-1 H2S NOT IN BOX FREE SHIP

BRONKHORST AIX-027F 200 MLN/MIN HCI MASS FLOW CONTROLLER FREE SHIP

BROOKS 001-4450-01 BOARD P/N 001-1961-01

BROOKS 001-4450-01 REV:C15 BOARD 001-1951-02 REV:C9

BROOKS 001-5104-01 REV:C2 BOARD LB101 INTERNATIONAL POWER SOURCES WORKING FREE

BROOKS 001-5104-03 BOARD LB101 INTERNATIONAL POWER SOURCES WORKING FREE SHIP

BROOKS 001-6843-01 16843-01 MLC94VO43/94 BOARD

BROOKS 002-3754-01 REV F8 BOARD

BROOKS 002-7200-21 WAFER LOAD PORT KLA: 750-614044-000 01 FREE SHIP

BROOKS 002-8478-01 BOARD

BROOKS 002-8996-02 REV:E BOARD ,002-9016-02,002-9015-02,002-9022-01 FREE SHIP

BROOKS 002-9400-04 SERIES 8 CONTROLLER

BROOKS 002-9401-01 SERIES 8 ROBOT CONTROLLER FREE SHIP

BROOKS 002-9401-01 SERIES 8 ROBOT CONTROLLER FREE SHIP #1

BROOKS 017-0353-01 WAFER ROBOT & CABLE FREE SHIP

BROOKS 017-0353-01 WAFER ROBOT & CABLE FREE SHIP #1

BROOKS 102369 002-7729-03 SLG AXIS CONTROLLER SERIES 8 BOARD

BROOKS 122078 PRE-ALIGNER FREE SHIP

BROOKS 15104-01 MLC94VO 42/94 BOARD,PTS25-24-5 TESTED WORKING FREE SHIP

BROOKS 15104-03 MLC94VO 47/94 LB101 BOARD TESTED WORKING FREE SHIP

BROOKS 16843-01 MLC94VO43/94 BOARD

BROOKS 26VDC POWER SUPPLY 13710-03,TESTED WORKING FREE SHIP

BROOKS 3 AXIS 24V TYPE 3 ASSY 123737 BOARD

BROOKS 5866M MFC MASS FLOW CONTROLLER 5866MC1P1B4PKAA GAS:H2 200 SCCM

BROOKS 5964 5964C2MAFP5KA MFC MASS FLOW CONTROLLER GAS:SIH4 200SCCM

BROOKS 5964 5964C2MAFR5KA MFC MASS FLOW CONTROLLER GAS:He 500SCCM

BROOKS 5964 5964C2MAGQ5KA MFC MASS FLOW CONTROLLER GAS:AR 500SCCM

BROOKS 5964 5964C2MAGR5KA MFC MASS FLOW CONTROLLER GAS:OXYGEN 500SCCM

BROOKS 6256S (COMMON) MFC MASS FLOW CONTROLLER GAS:AR 10000 SCCM

BROOKS 6256S (COMMON) MFC MASS FLOW CONTROLLER GAS:NF3 10000 SCCM

BROOKS 6256S 3253704004 6256SCZ11 MFC MASS FLOW CONTROLLER GAS:N2O 10 SLPM

BROOKS 6256S 3253704004 6256SCZ11 MFC MASS FLOW CONTROLLER GAS:N2O 10 SLPM #

BROOKS 6256S 3253704005 6256SCZWCMAC MFC MASS FLOW CONTROLLER GAS:N2 10 SLPM

BROOKS 6256S 3253704006 6256SCZWCMAC MFC MASS FLOW CONTROLLER GAS:AR 10 SLPM

BROOKS 6256S 3253704007 6256SCZWCMAC MFC MASS FLOW CONTROLLER GAS:NH3 3 SLPM

BROOKS 6256S 3253704008 6256SCZWCMAC MFC MASS FLOW CONTROLLER GAS:HE 10 SLPM

BROOKS 6256S 3253704009 6256SCZWCMAC MFC MASS FLOW CONTROLLER GAS:N2O 1 SLPM

BROOKS 6256S 3253704010 6256SCZWCMAC MFC MASS FLOW CONTROLLER GAS:CIH4 2 SLPM

BROOKS 6256S 3253704023 6256SCZ12 MFC MASS FLOW CONTROLLER GAS:O2 25 SLPM

BROOKS 6256S 3253704024 6256SCZ13 MFC MASS FLOW CONTROLLER GAS:NF3 10 SLPM

BROOKS 6256S 6256SBZVCLA MFC MASS FLOW CONTROLLER GAS:ARGON 500SCCM

BROOKS 6256S 6256SBZVCLA MFC MASS FLOW CONTROLLER GAS:NF3 500SCCM

BROOKS 6256S 6256SZVCLA MFC MASS FLOW CONTROLLER GAS:SiH4 500SCCM

BROOKS 6256S MASS FLOW CONTROLLER 6256SCZVCLAC GAS:AR,2000SCCM FREE SHIP

BROOKS 6256S MASS FLOW CONTROLLER 6256SCZVCLAC GAS:AR,2000SCCM FREE SHIP #1

BROOKS 6256S MASS FLOW CONTROLLER 6256SCZVCLAC GAS:AR,200SCCM FREE SHIP

BROOKS 6256S MASS FLOW CONTROLLER 6256SCZVCLAC GAS:NF3,1500SCCM FREE SHIP

BROOKS 6256S MASS FLOW CONTROLLER 6256SCZVCLAC GAS:SiH2CL2,500SCCM FREE SHIP

BROOKS 6256S MASS FLOW CONTROLLER GAS:Ar,2000SCCM FREE SHIP

BROOKS 6256S MASS FLOW CONTROLLER GAS:Ar,200SCCM FREE SHIP

BROOKS 6256S MASS FLOW CONTROLLER GAS:Ar,3 SLPM FREE SHIP

BROOKS 6256S MASS FLOW CONTROLLER GAS:DCS/CF:0.442,500SCCM FREE SHIP

BROOKS 6256S MASS FLOW CONTROLLER GAS:SiH4,2SLPM FREE SHIP

BROOKS 6256S MASS FLOW CONTROLLER GAS:SiH4/CF:0.625,2000SCCM FREE SHIP

BROOKS 6256S MASS FLOW CONTROLLER GAS:WF6,30SCCM FREE SHIP

BROOKS 6256S MFC MASS FLOW CONTROLLER GAS:Ar CF:1 500SCCM

BROOKS 6256S MFC MASS FLOW CONTROLLER GAS:HE 10000 SCCM

BROOKS 6256S MFC MASS FLOW CONTROLLER GAS:N2 10000 SCCM

BROOKS 6256S MFC MASS FLOW CONTROLLER GAS:N2 CF:1 30 SLPM

BROOKS 6256S MFC MASS FLOW CONTROLLER GAS:O2 25000 SCCM

BROOKS 6256S MFC MASS FLOW CONTROLLER GAS:SiH4 CF:0.625 500SCCM

BROOKS 6256S MFC MASS FLOW CONTROLLER,KITS SCT VALVE

BROOKS 702-0008-01 702-0008-11 171323 CPU BOARD TESTED WORKING

BROOKS 702-0008-05 PN:216916 CPU BOARD TESTED WORKING

BROOKS 921-118,TCD-CPUF4 BOARD,BRD-T5X-IPACK-TRANSITION,MOTOROLA 01-W3960B 70F

BROOKS ASSY 002-4234-02 BOARD

BROOKS ASSY 002-4234-04 BOARD

BROOKS ASSY 002-4485-04 PCB 002-4484-03 BOARD TESTED WORKING

BROOKS ASSY 002-4485-04 PCB 002-4484-03 BOARD TESTED WORKING #

BROOKS ASSY 002-4485-04 PTC-M1V-0 BOARD TESTSED WORKING

BROOKS ASSY 002-7730-03/B5 BOARD

BROOKS ASSY 002-7988-01 BOARD

BROOKS ASSY 003-5090-01 REV B BOARD #

BROOKS ASSY-002-9014-01 BOARD

BROOKS AUTOMATION 001-1951-02 REV C3,001-4051-01 CCD CONTROLLER BOARD PCB11950

BROOKS AUTOMATION 001-1951-02 REV C9 BOARD,PN 11951,PCB 11950

BROOKS AUTOMATION 001-6605-01 CONTROLLER

BROOKS AUTOMATION 001-8092-01 REV A3,DD-001-7684-01 REV B BOARD

BROOKS AUTOMATION 002-8478-01 BOARD

BROOKS AUTOMATION 002-8478-01 BOARD #

BROOKS AUTOMATION 003-9010-03 FREE SHIP

BROOKS AUTOMATION 140911-C5 BOARD

BROOKS AUTOMATION ASSY 002-8478-02 BOARD

BROOKS AUTOMATION ASSY 108288 108287 BOARD

BROOKS AUTOMATION ASSY 123737 BOARD #

BROOKS AUTOMATION BOARD 3 AXIS 24V TYPE 3 ASSY 113709 REV. B

BROOKS AUTOMATION ROBOT 1-0125

BROOKS AUTOMATION ROBOT BOARD 002-1100-04,002-1099-02,002-2027-02

BROOKS AUTOMATION ROBOT BOARD 002-1100-04,002-7696-01,002-1099-02,002-2027-02

BROOKS AUTOMATION ROBOT WAFER TRANSFER PRE-ALIGNER 002-7391-08 FREE SHIP

BROOKS AUTOMATION ROBOT WAFER TRANSFER PRE-ALIGNER 002-7391-22 FREE SHIP

BROOKS AUTOMATION SOFTWARE BRD-T5-SLOTO-C REV-C BOARD

BROOKS BA 001-4450-01 BOARD BA #11951-03

BROOKS BOARD 001-5526-01

BROOKS BOARD 002-8486-01/C 002-8396-01 REV:B3 & PCB 002-8487-01 FREE SHIP

BROOKS BOARD 921-031 BRD-T5X-IPACK-TRANSITION, MOTOROLA 01-W3960B,01-W3992B WORK

BROOKS BOARD 921-031 BRD-T5X-IPACK-TRANSITION, MOTOROLA 01-W3960B,01-W3992B

BROOKS BOARD 921-031 BRD-T5X-IPACK-TRANSITION, MOTOROLA 01-W3960B,01-W3992B WORK#

BROOKS BOARD 921-065, BRD-T5XTMC-COMP-E REV E

BROOKS BOARD 921-118,MOTOROLA CPU 01-W3960B 70F 84-W8960B01G FAB REV A WORKING

BROOKS BOARD 921-120, BRD-T2U/T5X-COMP32-B REV.B

BROOKS BOARD 921-132 921-094 BRD-T5X-10SER-FXTR-A, MOTOROLA 01-W3528F50D WORKING

BROOKS BOARD 921-138, BRD-T2U/T5X-COMP32-B REV.B

BROOKS BOARD ASSY-101664 PCB-101665

BROOKS BOARD PN 002-8396-01

BROOKS BOARD Z-AXIS INTERCONNECT RD ASSY 127214 REV A

BROOKS BRD-T2ULTRA-COMP-A,TCX FXCO8 BOARD 921-112 FREE SHIP

BROOKS CARRIAGE BOARD PCA 017-0620-01 ASSY 118613, 002-5875-02

BROOKS CARRIAGE BOARD PCI 017-0178-01 ASSY 118613 BOARD

BROOKS CARRIAGE BOARD PCI 017-0178-01 ASSY 118613 BOARD #

BROOKS CARRIAGE BOARD(ATR) PCA# 017-0178-01 PCB# 017-0177-01-A 002-5875-02

BROOKS CARRIAGE BOARD(ATR) PCA# 017-0178-01 PCB# 017-0177-01-A 002-5875-02 #

BROOKS CARRIAGE BOARD(ATR) PCA# 017-0178-01 PCB# 017-0177-01-A 118613

BROOKS CARRIAGE BOARD(ATR) PCA# 017-0178-01, ASSY 002-5875-02

BROOKS GEN9 DAFA EXTERNAL MODULE PRD-0057EXTz-02 KOLLMORGEN SERVOTRONIX BOARD

BROOKS GEN9 DAFA EXTERNAL MODULE PRD-0057INTz-02 KOLLMORGEN SERVOTRONIX BOARD

BROOKS GEN9 DAFA EXTERNAL MODULE PRD-0057INTz-02 KOLLMORGEN SERVOTRONIX BOARD#

BROOKS GEN9 DAFA EXTERNAL MODULE PRD-0057INTz-02 ME594V01110 BOARD

BROOKS GEN9 DAFA EXTERNAL MODULE PRD-0057INTz-02 ME594V01110 BOARD#

BROOKS GEN9 DAFA EXTERNAL MODULE PRD-0057INTz-02 P/N 115378 BOARD

BROOKS GEN9 DAFA EXTERNAL MODULE PRD-0057INTz-03 PCB-00574000-03 BOARD

BROOKS GEN9 DAFA EXTERNAL MODULE PRD-0057INTz-03 SS-3 94V-0 E229342 BOARD

BROOKS GEN9 DAFA INTERNAL MODULE PRD-0057INTB-02 PCB-00573000-02 BOARD

BROOKS GF 125CXXC MASS FLOW CONTROLLER BROOKS P/N GF125C-100987,GAS:SiH4,500SCCM

BROOKS GF 125CXXC MASS FLOW CONTROLLER P/N GF125C-100987,GAS:SiH4,500SCCM

BROOKS GF 125CXXC MASS FLOW CONTROLLER,BROOKS P/N GF125C-906932,GAS:SiH4,500SCCM

BROOKS GF 125CXXC MASS FLOW CONTROLLER,BROOKS P/N GF125C-911380,GAS:He,10000SCCM

BROOKS GF 125CXXC MASS FLOW CONTROLLER,P/N GF125C-906863,GAS:Ar,10000SCCM

BROOKS GF 125CXXC MASS FLOW CONTROLLER,P/N GF125C-907048,GAS:NF3,15000SCCM

BROOKS GRANVILLE-PHILLIPS 354001-YK-T GAUGE FREE SHIP

BROOKS INSTRUMENT MASS FLOW CONTROLLER 6256S GAS: SiF4 FS FLOW RATE: 200 SCCM

BROOKS INSTRUMENT MASS FLOW CONTROLLER MFC GAS: NF3 FS FLOW RATE: 1SLPM

BROOKS INSTRUMENT MASS FLOW CONTROLLER MFC GAS: NF3 FS FLOW RATE: 300SCCM

BROOKS INSTRUMENT MASS FLOW CONTROLLER MFC MOD: 6256S GAS: HE FS FLOW: 10 SLPM

BROOKS INSTRUMENT MASS FLOW CONTROLLER MFC MOD: 6256S GAS: N2 FS FLOW: 10 SLPM