

## 市场推送：A16B-2201-0811/04B福州到各地省市县区域/直送2023全+境+派+送

产品名称	市场推送：A16B-2201-0811/04B福州到各地省市县区域/直送2023全+境+派+送
公司名称	福建中立恒自动化设备有限公司
价格	.00/件
规格参数	
公司地址	福建省福州市鼓楼区温泉街道五四路9号宁德大厦（宏福大厦）10层1064室
联系电话	15659159037 15659159037

## 产品详情

主营产品：DCS集散式控制系统、PLC可编程控制器、数控系统、

(CPU处理器、模块、卡件、控制器、伺服驱动、工作站、驱动器、

马达、内存卡、电源，机器人备件等)各类工控产品

EUROTHERM PROCESS SUPERVISOR PROCESSOR FREE SHIP

EUROTHERM PROCESS SUPERVISOR PROCESSOR T940 FREE SHIP

EUROTHERM PROCESS SUPERVISOR PROCESSOR T940,XAPMM,BATT,ENG FREE SHIP

EUROTHERM PRODUCT CODE 2500P/10A POWER SUPPLY TESTED WORKING FREE SHIP

EUROTHERM PRODUCT CODE 2500P/10A0 POWER SUPPLY TESTED WORKING FREE SHIP

EUROTHERM T310 BASE UNIT FREE SHIP

EUROTHERM TEMPERATURE CONTROLLER 810-047-000-003-615-12-00 WORKING

EX-079 FROM AD-TEC AX-2000 RF GENERATOR , UNCLEAN FREE SHIP

EX-11 SUB245 Z00SM8747D BOARD

EX-11 SUB290 Z00SM8747D BOARD

F2097 CX3HUB C2L03097 BOARD

F2120 D2E01393A BOARD

FA-121101-2 00G013I BOARD FK-121101A

FA-121102A

FA121104 CIRCUIT BOARD FK121104

FACTS ENGINEERING KOYO F4-CP128-1, U-01SP-8290(2), U-08N, U-18T (BROKEN)

FAG 3218 BEARING 175 B.B 160MM

FAG 3222M Angular Contact Ball bearing GERMANY 252 B.B 200MM

FAGOR AC BRUSHLESS SERVO MOTOR FXM32.20A.E1.000 WORKING FREE SHIP

FAGOR AXES 8055 BOARD TESTED .WORKING FREE SHIP

FAGOR BOARD RF:CPU-TUR 512K,TESTED WORKING

FAGOR CASE PSB6-8055 UC 8055/B & POWER SUPPLY TESTED .WORKING FREE SHIP

FAGOR CPU 8055/AB-M CPU BOARD TESTED .WORKING FREE SHIP

FAGOR DRIVE MODULE AXD 1.08-S0-0 TESTED .WORKING FREE SHIP

FAGOR H.DISK BOARD HD 8055-E 807000P3 TESTED .WORKING FREE SHIP

FAGOR H.DISK HD 8055-E [R],BOARD AR-B1375/6,NE2000,RF:HD CF,TESTED WORKING

FAGOR H.DISK HD 8055-E,BOARD AR-B1375/6,ETHER-16CT/104,HD 8055 CF,TESTED WORKING

FAGOR MON 50/55M 9-AMB OPERATOR PANEL

FAGOR SERCOS 8055 BOARD TESTED .WORKING FREE SHIP

FAIRCHILD CONVAC A3 CDRCIB BS WAFER RINSE, COAT DEVELOPE PROCESS,PCB BOARD

FAIRCHILD CONVAC C CPU2A.1 BS WAFER RINSE, COAT DEVELOPE PROCESS,PCB BOARD

FAIRCHILD CONVAC CDCIA BS WAFER RINSE, COAT DEVELOPE PROCESS,PCB BOARD

FAIRCHILD CONVAC CEA1A BS ART. NR. 45083 BOARD

FAIRCHILD CONVAC CEAIA BS WAFER RINSE, COAT DEVELOPE PROCESS,PCB BOARD #2

FAIRCHILD CONVAC CSCIA BS WAFER RINSE, COAT DEVELOPE PROCESS,PCB BOARD #1

FAIRCHILD CONVAC CSMS3A BS WAFER RINSE, COAT DEVELOPE PROCESS,PCB BOARD

FANTAS MFC 2470G1 MC-AGD1 C4F6 10 SCCM

FANTAS MFC 2470G1 MC-AGD1 C4F6 10 SCCM

FANTAS MFC 2470G1 MC-AGD1 C4F8 60 SCCM

FANTAS MFC 2470G1 MC-AGD1 C4F8 60 SCCM

FANTAS MFC 2470G1 MC-AGD1 C6F6 60 SCCM

FANTAS MFC 2470G1 MC-AGD1 C6F6 60 SCCM

FANTAS MFC 2480G1 MC-AGD1 Ar 1500 SCCM

FANTAS MFC 2480G1 MC-AGD1 Ar 1500 SCCM

FANTAS MFC 2480G1 MC-AGD1 C3F8 50 SCCM

FANTAS MFC 2480G1 MC-AGD1 C3F8 50 SCCM

FANTAS MFC 2480G1 MC-AGD1 CHF3 150 SCCM

FANTAS MFC 2480G1 MC-AGD1 CHF3 150 SCCM

FANTAS MFC 2480G1 MC-AGD1 O2 10 SCCM

FANTAS MFC 2480G1 MC-AGD1 O2 10 SCCM

FANUC \*FRST A16B-1000-0060/09B,A320-1000-T064/03 BOARD

FANUC 5F AC SERVO MOTOR A06B-0342-B221

FANUC 5F/3000 AC SERVO MOTOR A06B-0345-B221

FANUC 5M DC SERVO MOTOR A06B-0642-B011 FREE SHIP

FANUC A02B-0236-C205 SDU1 WORKING

FANUC A02B-0281-B504,A20B-8100-0660,A20B-8100-0770,A20B-3300-0390,A20B-3300-0280

FANUC A03B-0815-C001 WORKING

FANUC A05B-2115-C003 TEACH PENDANT + 2002-T902 L-10MA CABLE WORKING FREE SHIP

FANUC A05B-2400-C012 BOARD:A20B-9002-0310/02B FOR FANUC SYSTEM R-J3 FREE SHIP

FANUC A06B-0063-B203 AC SERVO MOTOR,A860-2020-T301 ENCODER FREE SHIP

FANUC A06B-0116-B203 AC SERVO MOTOR 1/6000

FANUC A06B-0116-B203 AC SERVO MOTOR 1/6000 #

FANUC A06B-0205-B200 AC SERVO MOTOR,A860-2000-T301 ENCODER FREE SHIP

FANUC A06B-0205-B500 AC SERVO MOTOR,A860-2000-T301 ENCODER FREE SHIP

FANUC A06B-0221-B000 AC SERVO MOTOR ENCODER A860-2000-T301 FREE SHIP

FANUC A06B-0247-B100 AC SERVO MOTOR FREE SHIP

FANUC A06B-6047-H040 VELOCITY CONTROL UNIT,A20B-0009-0320/09D

FANUC A06B-6047-H040 VELOCITY CONTROL UNIT,A20B-0009-0320/10D

FANUC A06B-6047-H202 VELOCITY CONTROL UNITA16B-1200-0230/07B,A20B-1000-0220/07B

FANUC A06B-6058-H334 POWER ON TESTED FREE SHIP

FANUC A06B-6077-H111 B,POWER SUPPLY TESTED WORKING FREE SHIP

FANUC A06B-6105-H002 2.2KW ROBOTIC SERVO AMPLIFIER FREE SHIP

Fanuc A14B-0075-B120-01,A13B-0073-C001 A20B-C008-0280/05B,A20B-1000-0472/02A

FANUC A16B-1000-0030/04C,A20B-0008-0440/03,A20B-0008-0430/05A

FANUC A16B-1000-0030/05C A320-1000-T034/03 BOARD

FANUC A16B-1000-0140/08B BOARD

FANUC A16B-1000-0210/05A BOARD

FANUC A16B-1010-0150/05A,A320-1010-T156/03 BOARD

FANUC A16B-1010-0150/06A,A320-1010-T156/03 BOARD

FANUC A16B-1010-0210/04B,A320-1010-T216/03 BOARD

FANUC A16B-1010-0210/08D,A320-1010-T216/04 BOARD

FANUC A16B-1010-0285/16B BOARD

FANUC A16B-1100-0130/04A,A320-1100-T134/03, BOARD

FANUC A16B-1100-0141/01A BOARD

FANUC A16B-1200-0201 / 02A WELD INTERFACE BOARD

FANUC A16B-1200-0250/01A,A320-1200-T252/01 BOARD

FANUC A16B-1200-0550/05A,A320-1200-T552/03 BOARD

FANUC A16B-1200-0880/01A BOARD

FANUC A16B-1210-0590/03A BOARD

FANUC A16B-1210-0820/03A,A320-1210-T824/02 BOARD

FANUC A16B-1211-0300/02A,A320-1211-306/02 BOARD

FANUC A16B-1211-0920/06A BOARD

FANUC A16B-1212-0471/03A POWER SUPPLY BOARD FREE SHIP

FANUC A16B-1300-0010/02B,A320-1300-T012 BOARD

FANUC A16B-1300-0100/02A,A320-1300-T102/02 BOARD

FANUC A16B-2000-0062/06C BOARD FREE SHIP

FANUC A16B-2200-0661/08C BOARD

FANUC A16B-2201-0071/04B BOARD

FANUC A16B-2201-0071/06C BOARD

FANUC A16B-2202-0750/06A,A320-2202-T754/03 BOARD

FANUC A16B-2203-0110/02A BOARD,A320-2203-T114/02

FANUC A16B-2203-0370/13E POWER SUPPLY WORKING FREE SHIP

FANUC A16B-2300-0021/03B,A320-2300-T024/04 BOARD

FANUC A16B-3200-0330, A20B-3900-0074, A17B-3300-0201, A20B-3300-0084/03B BOARD

FANUC A16B-3200-0421,A20B-3300-0310/08F,A20B-8101-0191/02B,3300-0340,3300-0392

FANUC A16B-3200-0610/10E,A20B-2101-0230/03C,A20B-2101-0221 SYSTEM R-J3iC M-16iB

FANUC A20B-0007-0040, A350-0007-T044/03 BOARD

FANUC A20B-0007-0070.08B A350-0007-T074/04

FANUC A20B-0007-009 ADD.AXIS(P/C) A20B-0007-0090 BOARD

FANUC A20B-0007-0090/08E BOARD

FANUC A20B-0007-0449/ 03,A20B-0007-0030/02A, A05B-2003-C031

FANUC A20B-0008-0410 03B, A350-0008-T414/03 BOARD

FANUC A20B-0008-0430 05A BOARD

FANUC A20B-0008-0430.05A,A350-0008-T434/02 BOARD

FANUC A20B-0008-0470/06C,A350-0008-T474/04 BOARD

FANUC A20B-0008-0540 / 01A,A350-0008-T544/01 BOARD #1

FANUC A20B-0008-0540/01A,A350-0008-T544/01 BOARD

FANUC A20B-0009-0150/10B

FANUC A20B-0009-0320/17D,A350-0009-T322/08 BOARD

FANUC A20B-1003-0010/07A,A350-1003-T016/03 BOARD

FANUC A20B-2000-0170/06B BOARD,A350-2000-T176/05

FANUC A20B-2002-0650/03A BOARD,A350-2002-T656/03

FANUC A20B-2002-0761/03B BOARD WORKING FREE SHIP

FANUC A20B-2100-0182 A350-2100-T186/07 BOARD FREE SHIP

FANUC A20B-2102-0207 BOARD

FANUC A20B-8100-0530/05B,A350-8100-T538/03 BOARD TESTED WORKING FREE SHIP

FANUC A20B-8100-0670/08C BOARD TESTED WORKING FREE SHIP

FANUC A20B-8101-055/02A A350-8101-T558/01 BOARD

FANUC AC SERVO MOTOR 10S A06B-0315-B233

FANUC AC SERVO MOTOR 3-0S A06B-0533-B251

FANUC AC SERVO MOTOR 6L,A06B-0563-B032

FANUC AC SERVO MOTOR A06B-0113-B075

FANUC AC SERVO MOTOR A06B-0113-B075 #0008 BO.5/3000

FANUC AC SERVO MOTOR A06B-0113-B075 #0008 BO.5/3000 #1

FANUC AC SERVO MOTOR A06B-0113-B078#0008 #1

FANUC AC SERVO MOTOR A06B-0113-B078#0008 #1

FANUC AC SERVO MOTOR A06B-0113-B078#0008,a0.5/3000

FANUC AC SERVO MOTOR A06B-0113-B175#0008 FREE SHIP

FANUC AC SERVO MOTOR A06B-0123-B175 FREE SHIP

FANUC AC SERVO MOTOR A06B-0123-B175 FREE SHIP #1

FANUC AC SERVO MOTOR A06B-0127-B077 FREE SHIP

FANUC AC SERVO MOTOR A06B-0142-B175

FANUC AC SERVO MOTOR A06B-0162-B175 FREE SHIP

FANUC AC SERVO MOTOR A06B-0212-B100 TESTED WORKING FREE SHIP

FANUC AC SERVO MOTOR A06B-0212-B100,PULSECODER A860-2000-T301 TESTED WORKING #1

FANUC AC SERVO MOTOR A06B-0372-B588,PULSCODER A860-0370-T002

FANUC AC SERVO MOTOR A06B-0512-B001 WORKING

FANUC AC SERVO MOTOR A06B-0563-B001 6L

FANUC AC SERVO MOTOR A06B-0564-B088 aL9/3000

FANUC AC SERVO MOTOR a1/3000 A06B-0371-B575

FANUC AC SERVO MOTOR a2/5000is A06B-0212-B100,PULSECODER A860-2000-T301 WORKING

FANUC AC SERVO MOTOR a22/4000is A06B-0265-B100,PULSECODER A860-2000-T301 WORKIN

FANUC AC SERVO MOTOR aL9/3000,A06B-0564-B075

FANUC AC SERVO MOTOR BM 0.5/4000,A06B-0115-B075#0008

FANUC AC SERVO,AMP,AMPLIFIER A06B-6077-H106 WORKING

FANUC AC SERVO,AMP,AMPLIFIER A06B-6102-H206#520 WORKING

FANUC AC SPINDLE MOTOR A06B-0853-B100

FANUC AC SPINDLE MOTOR A06B-0854-B100

FANUC AC SPINDLE SERVO UNIT A06B-6044-H016,A20B-0009-053,A20B-0008-0030/04C

FANUC AC SPINDLE SERVO UNIT A06B-6064-H301#H550,A16B-2100-0070/05A,FREE SHIP

FANUC AI6B-1200-0150/01A A320-1200-T154/01

FANUC aiPS 11 POWER SUPPLY A06B-6110-H011 D,TESTED WORKING FREE SHIP

FANUC aiSP 5.5 ,SPINDLE AMPLIFIER A06B-6112-H006#H550 C, FREE SHIP

FANUC aiSV 20/20/20 A06B-6114-H303 E,SERVO AMPLIFIER , FREE SHIP

FANUC AXIS CONT PCB BOARD A016B-2200-0855/03B,A20B-2900-0380,A20B-2901-0340/02A

FANUC BMU 64-1 A87L-0001-0015 08F BOARD

FANUC BOARD A16B-1200-0030/01A

FANUC BOARD A16B-1200-0041/01A

FANUC BOARD A16B-1200-0050/01A

FANUC BOARD A16B-1200-0080/04A & A16B-1600-0020/02A

FANUC BOARD A16B-1200-0090/04B & A16B-1600-0020/02A

FANUC BOARD A16B-1200-0100.02B & A16B-1200-0110.02B

FANUC BOARD A16B-1300-0010/02B,A320-1300-T012 #1

FANUC BOARD A16B-1300-0220/03A

FANUC BOARD A16B-2100-0070/05A

FANUC BOARD A16B-2200-0210/04A

FANUC BOARD A16B-2200-0210/04A

FANUC BOARD A16B-2200-0300/04A

FANUC BOARD A16B-2200-0300/04A #

FANUC BOARD A16B-2201-0071/05C

FANUC BOARD A16B-2201-0440/07B

FANUC BOARD A16B-2201-0472/06E FREE SHIP

FANUC BOARD A16B-2202-0420/07E #1

FANUC BOARD A16B-2202-066

FANUC BOARD A16B-2202-0661/01A

FANUC BOARD A16B-2202-0680/01A FREE SHIP

FANUC BOARD A16B-2203-0754/04A,A20B-3300-0393/02A,A20B-3300-0310/08F FREE SHIP

FANUC BOARD A16B-2203-0990/02A

FANUC BOARD A16B-3200-0010/08A & A20B-2901-0941/02A & A20B-2902-0271/03B WORKING

FANUC BOARD A16B-3200-0231/01A A320-3200-T236/02

FANUC BOARD A16B-3200-0330/17G100540,A20B-3300-0084/03B,A20B-3900-0072/01A WORK



FANUC BOARD A20B-0008-0871.04A

FANUC BOARD A20B-0008-0871.04A

FANUC BOARD A20B-0008-0901 03A