

ROSEMOUNT流量变送器8712ESR1A1N0M4B6

产品名称	ROSEMOUNT流量变送器8712ESR1A1N0M4B6
公司名称	福建中立恒自动化设备有限公司
价格	.00/件
规格参数	
公司地址	福建省福州市闽侯县滨江西大道闽商财富中心1806室
联系电话	15960122459 15960122459

产品详情

主营产品：DCS集散式控制系统、PLC可编程控制器、数控系统、
(CPU处理器、模块、卡件、控制器、伺服驱动、工作站、驱动器、
马达、内存卡、电源，机器人备件等)各类工控产品

AB：1756，1746，1794，1734，1769，2711P等系列

GE：IC693 IC695 IC697系列

Schneider（施耐德）：140 TSX 系列

Siemens 6DD，6FC，6SN，6ES7，6ES5系列，Foxboro系统卡件，

Triconex系统模块，Rexroth力士乐全系列产品，停产模块等各类工控产品

以及ABB、发那科、三菱、安川、欧姆龙、霍尼韦尔、艾默生等进口品牌PLC、CPU、DCS

AIRTEC PNEUMATIC HMP-40-080 CYLINDER HMP40080

AIRTEC SL-063-0025-0PNEUMATIC CYLINDER SL0630025050

AIRTEC ZS-200 SENSOR ZS200

AI-TEK INSTRUMENTS 70085-1010-0SENSOR 11C 700851010037

AJAX 72012A01 MAGNETHERMIC PULSE AMPLIFIER BOARD

AJAX MAGNETHERMIC 72011ATEMPERATURE MONITOR BOARD

AJAX MAGNETHERMIC 72011ATEMPERATURE MONITOR BOARD

AJAX MAGNETHERMIC CORP. U-01-1680-A PACER II LOGIC BOARD U011680A

AJAX MAGNETHERMIC CORP. U-02-0891-MK-A DIGITAL METER BOARD U0208917MKA

AJAX MAGNETHERMIC CORP. U-02-1683-2 AC2 LINE SENSING BOARD 72011A70

AJAX MAGNETHERMIC CORP. U-02-1684-05MK-A EXPANSION BOARD U02168405MKA

AJAX MAGNETHERMIC CORP. U-02-1743-05MK-A POWER SUPPLY BOARD U02174305MKA

AJAX MAGNETHERMIC NBRSC37796ATHYRISTOR SC37796A20

AJAX MAGNETHERMIC U-01-107B-00 MK-A TEMPERATURE MONITOR U01107B00MKA

AJAX MAGNETHERMIC U-02-0937-0PC BOARD 72011A1U02093703

AJAX TOCCO SC37706E40 110THYRISTOR DIODE

AJAX TOCCO SC37794A30 THYRISTOR MODULE

AJAX TOCCO SC37794A30 THYRISTOR MODULE

AJAX TOCCO SC37794A4THYRISTOR

AJAX TOCCO SC37794A4THYRISTOR

AJAX TOCCO U-02-1836-02 PC BOARD 75401A20

AJAX TOCCO U-02-1836-02 PC BOARD 75401A20

AJAX TOOLS 3400-RETAINER W/ SPRING 34003

AJAX TOOLS 3400-RETAINER W/ SPRING 34003

AJAX U-01-1052-13MK-B AMPLIFIER BOARD 72012A10 U01105213MKB

AKG COOL-LINE P22-30 WATER COOLER P2230

AKRON HYDRANT OPEN AND CLOSE VALVE

AKRON TURBOJET STYLE: 17NOZZLE 2 1/2"

ALBRIGHT SW132-CONTACTOR

ALBRIGHT SW132-CONTACTOR

ALBRIGHT SW181B-170 CONTACTOR SW181B170

ALBRIGHT SW181B-170 CONTACTOR SW181B170

ALBRIGHT SW200N-CONTACTOR SW200N29

ALBRIGHT SW80-1538L CONTACTOR SW801538L

ALBRIGHT SW80-1538L CONTACTOR SW801538L

ALBRIGHT SW80-740L CONTACTOR 24V SW80740L

ALBRIGHT SW80B-6CONTACTOR SW80B65

ALBRIGHT SW82-148L CONTACTOR 24V SW82148L

ALBRIGHT SW82-148L CONTACTOR 24V SW82148L

ALCAN ALESA L050022-040 LIMIT SWITCH BOX L050022040

ALCO CONTROLS 200RB 6T5T SOLENOID VALVE 200RB6T5T

ALCO CONTROLS AMG 120V SOLENOID COIL

ALCO CONTROLS BFK-16S FILTER DRIER BFK165S

ALCO CONTROLS HF-1/2-FC THERMO VALVE HF12FC

ALCO CONTROLS XB-101HC-2B POWER ASSEMBLY 054390 XB1019HC2B

ALCO EK-16FILTER DRIER EK164

ALCO TX3-N3THERMO EXPANSION VALVE

ALCO TX3-N3THERMO EXPANSION VALVE

ALCO VALVES UB6NS BALL VALVE 3/4" 316SS

ALCO X-22606-72 VALVE COIL X2260672

ALCON NACDNVALVE

ALEMITE 9969-B PUMP 9969B

ALEMITE 9969-B PUMP 9969B

ALEMITE PML PUMP 9616-A PNEUMATIC MOTOR LOGIC 9616A X3

ALERTON IBEX TX-APLC-K PROGRAMMABLE CONTROLLER TX-APLC

ALEXANDER MACHINERY 300CF COALESCER AIR FILTER

ALEXANDER MACHINERY 300CF COALESCER AIR FILTER

ALFA LAVAL 7610300SM2H152SRSTESNNN TRI-COVER VALVE

Alfa Laval 961192000Actuator Service Kit

Alfa Laval 961192000Actuator Service Kit

Alfa Laval 9611920030 Service Kit

ALFA LAVAL 961192659SERVICE KIT FPM UNIQUE SSV/7000

ALFA LAVAL 961239480SHUTTER KIT

ALFA LAVAL C216-1 SEAL KIT C2161

ALFA LAVAL LKB5VALVE REPAIR KIT

ALFAGOMMA T-330 AA HOSE 50FT T330AA

ALFAGOMMA T-330 AA HOSE 50FT T330AA

ALKON A-A7900 3/DIRECTIONAL VALVE 115/60 AA7900

ALKON AQ89-P-FITTING LOT OF 5

ALLDOS 205-4,0 D53/A01/V01/P02 DOSING PUMP 20540D53A01V01P02

ALLEN BRADLEY 800H-FRXTQ24XDPUSHBUTTON SER.F 800HFRXTQ24XD4

ALLEN BRADLEY ABB 3500-IOC CONNECTION BOARD SAFT-163-IO , 3500IOC

ALLEN BRADLEY ABB 50156POWER SUPPLY BOARD SAFT-110-POW , SAFT110POW

ALLEN BRADLEY 1000F-1791ES-IB1ETHERNET INPUT MODULE SER. A, 1791ES-IB16

ALLEN BRADLEY 100-A18NZ*CONTACTOR SER.B 100A18NZ3

ALLEN BRADLEY 100-C09EJ10 CONTACTOR SER.A 100C09EJ10

ALLEN BRADLEY 100-C09EY10 CONTACTOR SER.A 100C09EY10

ALLEN BRADLEY 100-C09KJ10 SER. A CONTACTOR 100C09KJ10

ALLEN BRADLEY 100-C09ZF10 CONTACTOR 100C09ZF10

ALLEN BRADLEY 100-C12A10 CONTACTOR SER.A 100C12A10

ALLEN BRADLEY 100-C12D10 CONTACTOR SER.A 100C12D10

ALLEN BRADLEY 100-C12DCONTACTOR 100C12D300

ALLEN BRADLEY 100-C12UKJ10 CONTACTOR

ALLEN BRADLEY 100-C16D10 CONTACTOR SER.B 100C16D10

ALLEN BRADLEY 100-C30KG10 CONTACTOR SER.C 100C30KG10

ALLEN BRADLEY 100-C37D01 SER. B CONTACTOR W/ 193-EA1HC SER. B RELAY

ALLEN BRADLEY 100-C37D10 CONTACTOR 100C37D10

ALLEN BRADLEY 100-C60D10 CONTACTOR 120V/60HZ SER. B, 100C60D10

ALLEN BRADLEY 100-C85DJ01 CONTACTOR

ALLEN BRADLEY 100-D180D11 CONTACTOR 100D180D11 SERIES B

ALLEN BRADLEY 100-DTB110 TERMINAL BLOCKS SER.A 100DTB110

ALLEN BRADLEY 100-FA0CONTACT BLOCK 100FA04

ALLEN BRADLEY 100-FSD2SURGE SUPRESSOR

ALLEN BRADLEY 100-K05D10 MINI CONTACTOR SER.A 100K05D10

ALLEN BRADLEY 100-K05ZJ10 MINI CONTACTOR SER.A 100K05ZJ10

ALLEN BRADLEY 100-M05ND3S MINI CONTACTOR SER.A 100M05ND3S

ALLEN BRADLEY 100-MO9NZ*SER A CONTACT RELAY

ALLEN BRADLEY 100-SA11 SER. B AUXILIARY CONTACT 100SA11

ALLEN BRADLEY 100S-C23EJ32C CONTACTOR

ALLEN BRADLEY 100S-D180H22C SAFETY CONTACTOR

ALLEN BRADLEY 104-C12B22 CONTACTOR SER.B 104C12B22

ALLEN BRADLEY 104-C12D22 REVERSING CONTACTOR

ALLEN BRADLEY 104-C16KJH22-XREVERSING CONTACTOR SER. C, 104C16KJH22X6

ALLEN BRADLEY 104-C16ZJ22 REVERSING CONTACTOR SER.C 104C16ZJ22

ALLEN BRADLEY 1202-C30 COMMUNICATIONS CABLE SER.A 1202C30

ALLEN BRADLEY 1202-H30 COMMUNICATIONS CABLE 1202H30

ALLEN BRADLEY 12M03-00022-02 TRANSFORMER RELAY BOARD 12M030002202

ALLEN BRADLEY 1305-AA02A-HA2 DRIVE

ALLEN BRADLEY 1305-BA01A MICRO DRIVE SER. C, .5HP, 1305BA01A

ALLEN BRADLEY 1326AB-A3E-11 SERVO MOTOR 122245, 1326ABA3E11

ALLEN BRADLEY 1326AB-B2E-11 SERVO MOTOR 122249, 1326ABB2E11

ALLEN BRADLEY 1326AB-C3E-11-ASERVO MOTOR 126118, 1326ABC3E11A7

ALLEN BRADLEY 1326-CEU-30 ENCODER CABLE 163680 1326CEU30

ALLEN BRADLEY 1326-CFU1COMMUNICATION CABLE SER.B 1326CFU15

ALLEN BRADLEY 1326-CFU-COMMUNICATION CABLE ASSEMBLY 50' 1326CFU50

ALLEN BRADLEY 1329RS-ZA00518BBC MOTOR WITH FAN 1329RSZA00518BBC

ALLEN BRADLEY 1332-AAA FREQUENCY DRIVE 230V, 60HZ, SER. B, 1332AAA

ALLEN BRADLEY 1333-YAB SER. B ADJUSTABLE FREQUENCY DRIVE 1333YAB

ALLEN BRADLEY 13S50399-001 DRIVER BOARD ASSEMBLY S50399001

ALLEN BRADLEY 1335-DAB-F4-FVARIABLE AC DRIVE 7.5HP 460V 1335DABF4F8

ALLEN BRADLEY 1336-B010-EAD DRIVE 10 HP

ALLEN BRADLEY 1336-BDB-SP49D GATE DRIVER BOARD KIT 1336BDBSP49D

ALLEN BRADLEY 1336E-AA2 DRIVE ACCESSORY SER.A 1336EAA2

ALLEN BRADLEY 1336E-BRF10-AA-EN-HA2-L7E DRIVE 1 HP SER. D

ALLEN BRADLEY 1336F-BRF10-AA-EN-HASP-LDRIVE 1HP SER.B 1336FBRF10AAHASPL4

ALLEN BRADLEY 1336F-BRF75-AA-EN-HAS1-LA4-LSensorless VECTOR DRIVE SER. A

ALLEN BRADLEY 1336F-BRF75-AN-EN-HAS2 DRIVE 7.HP 1336F-BRF75-AN-EN-HA

ALLEN BRADLEY 1336F-MCB-SP2K MAIN CONTROL BOARD 1336FMCBSP2K

ALLEN BRADLEY 1336-LCONTROL INTERFACE BOARD W/O ENCODER 115VAC, 1336L6

ALLEN BRADLEY 1336-LSER. B INTERFACE CARD 115VAC, 1336L6

ALLEN BRADLEY 1336-R2-SP5A SER. A RESISTOR KIT 1336R2SP5A

ALLEN BRADLEY 1336S-BRF20-AA-EN4-HA2-LAC DRIVE 2HP, 4.6A, 3PHASE

ALLEN BRADLEY 1336S-BRF30-AA-EN4-HA1-L6E Sensorless DRIVE SER. D

Allen Bradley 1336S-MCB-SP1A Main Control PC Board 1336SMCBSP1A

ALLEN BRADLEY 1336T-GT1-SP34B CONTROL BOARD 1336TGT1SP34B

ALLEN BRADLEY 1370-DBH7DYNAMIC BRAKE RESISTOR 1370DBH74

ALLEN BRADLEY 1392-B040-RF-MC-A-H-D1-F1-FHIGH PERFORMANCE DRIVE SER. A

ALLEN BRADLEY 140122 ISO SIGNAL BOARD RV. 02

ALLEN BRADLEY 1401-N42 FUSE CLIP KIT 1401N42

ALLEN BRADLEY 1406-R1SERIES A MOTOR PROTECTOR 1406R16

ALLEN BRADLEY 140G-H6C3-C30 CIRCUIT BREAKER

ALLEN BRADLEY 140G-H-TC3H CIRCUIT BREAKER ASSY. D1305SER. A 140GH3H

ALLEN BRADLEY 140G-K-EA2B SER. A CIRCUIT BREAKER ACCESSORY 140GKEA2B

ALLEN BRADLEY 140M-18P-B70S CIRCUIT BREAKER 140M18PB70S

Allen Bradley 140M-C2E-A1Circuit Breaker 140MC2EA16

ALLEN BRADLEY 140M-C2E-A6SER. B CIRCUIT BREAKER 140MC2EA63

ALLEN BRADLEY 140M-C2E-B10 MOTOR PROTECTOR SER.A 140MC2EB10

ALLEN BRADLEY 140M-C2E-B1SER. C STANDARD MAGNETIC STARTER 140MC2EB16

ALLEN BRADLEY 140M-C2E-BMOTOR PROTECTOR SER.B 140MC2EB25

ALLEN BRADLEY 140M-C2E-B40 CIRCUIT BREAKER

ALLEN BRADLEY 140M-C2E-CMOTOR PROTECTOR SER.B 140MC2EC20

ALLEN BRADLEY 140MG-H8E-C60 MOTOR PROTECTOR SER.A 140MGH8EC60

ALLEN BRADLEY 140M-I8E-D10 CIRCUIT BREAKER

ALLEN BRADLEY 140-MN-0060 SER. B 140MN0060

ALLEN BRADLEY 140-MN-0100 CIRCUIT BREAKER 140MN0100

ALLEN BRADLEY 140U-H6C3-C15-MT CIRCUIT BREAKER MCCB, SER. B, 140UH6C3C15M

ALLEN BRADLEY 140U-JTD3-D1TRIP UNIT 140UJTD3D15

ALLEN BRADLEY 141A-VN3300R SUPPLY MODULE 141AVN3300R