

传感器BNS819-B04-E08-40

产品名称	传感器BNS819-B04-E08-40
公司名称	福州迈康自动化有限公司
价格	10.00/件
规格参数	品牌:巴鲁夫 型号:BNS 819-B04-E08-40-11
公司地址	福州市鼓楼区铜盘路30号税务学会2楼
联系电话	0591-87272895 18250151453

产品详情

bns 819-b04-d08-46-11

bns 819-d06-d12-100-10

bns 813-b03-d12-61-a-10-0517

bns 819-b04-d08-46-13

bns 819-d06-d12-100-10-fd

bns 813-b03-d12-61-a-12-03

bns 819-d06-d12-100-10-fd-s90l

bns 813-b03-d12-61-a-20-02

bns 816-b03-pa-12-610-11

bns 819-b04-d08-46-3b

bns 819-d06-d12-100-10-fd-s90r

bns 813-b03-d12-61-a-22-03

bns 819-b04-d10-46-10

bns 819-d06-d12-100-10-fe

bns 813-b03-d12-61-a-55-0510

bns 816-b03-pa-16-602-11

bns 819-b04-d10-46-11

bns 813-b03-e12-61-a-10-0686

bns 816-b03-tha-16-602-11

bns 819-b04-d12-61-12-10

bns 813-b03-e12-61-a-22-03

bns 816-b03-tha-16-611-11

bns 819-b04-d12-61-12-10-fd

bns 819-d06-d16-100-10

bns 816-b03-tob-08-603-11

bns 819-d06-d16-100-10-fd

bns 816-b03-tob-08-650-11

bns 819-b04-d12-61-12-3b

bns 813-b03-k12-61-a-10-02

bns 816-b03-tob-10-603-11

bns 819-b04-d12-72-10

bns 819-d06-e12-100-10

bns 813-b03-k16-61-b-22-03

bns 819-b04-d12-72-10-fd

bns 819-d06-e12-100-10-fd

bns 813-b03-l12-61-a-10-01

bns 816-b03-ws-12-610-11

bns 819-b04-d16-61-16-10

bns 819-d06-k16-100-10

bns 813-b03-l12-61-a-10-02

bns 819-b04-e08-40-10

bns 819-d06-l12-100-10

bns 813-b03-l12-61-a-10-1020

bns 816-b04-khg-12-602-11

bns 819-b04-e08-40-11

bns 819-d06-l12-100-10-fd

bns 813-b03-l12-61-a-10-1038

bns 816-b04-khg-12-610-11

bns 819-b04-e08-40-13

bns 813-b03-l12-61-a-12-03

bns 816-b04-na-12-602-11

bns 819-b04-e08-46-13

bns 819-d06-l16-100-10

bos 18k-nu-id10-02

bns 813-b03-l12-61-a-22-03

bns 816-b04-na-12-610-11

bns 819-b04-e10-46-11

bns 819-d06-l16-100-10-fd

bos 18k-nu-id10-s4

bns 813-b03-l12-61-a-55-0908

bns 816-b04-na-16-602-11

bns 819-b04-e12-61-12-10

bns 819-d06-r12-100-10

bos 18k-nu-ie10-02

bns 813-b03-l16-61-b-12-03

bns 816-b04-pa-12-602-11

bns 819-b04-k08-40-10

bns 819-d06-r12-100-10-fd

bos 18k-nu-ie10-s4

bns 813-b03-r12-61-a-10-01

bns 816-b04-pa-12-602-11-s90l

bns 819-b04-k08-40-11

bns 819-d06-r12-100-10-fe

bos 18k-nu-pr10-02

bns 813-b03-r12-61-a-10-02

bns 816-b04-pa-12-602-11-s90r

bns 819-b04-k08-40-12

bos 18k-nu-pr10-s4

bns 813-b03-r12-61-a-10-02-fc

bns 816-b04-pa-12-605-11

bns 819-b04-k08-40-13

bns 813-b03-r12-61-a-10-0723

bns 816-b04-pa-12-610-11

bns 819-b04-k10-46-10

bns 819-d06-r16-100-10

bns 813-b03-r12-61-a-12-03

bns 816-b04-pa-16-602-11

bns 819-b04-k10-46-11

bns 819-d06-r16-100-10-fd

bns 813-b03-r12-61-a-12-0365

bns 816-b04-pa-16-611-11

bns 819-b04-k12-61-12-10

bns 819-d06-r16-100-10-fe

bos 18k-pu-id10-02

bns 813-b03-r12-61-a-20-01

bns 816-b04-tha-16-602-11

bns 819-b04-k16-61-16-10

bns 819-d06-r16-62-10

bos 18k-pu-id10-s4

bns 813-b03-r12-61-a-20-02

bns 816-b04-tha-16-605-11

bns 819-b04-l12-61-12-10

bos 18k-pu-ie10-02

bns 813-b03-r12-61-a-22-03

bns 816-b04-tha-16-611-11

bns 819-d08-d12-100-10-fd

bos 18k-pu-ie10-s4

bns 813-b04-d08-40-49-04

bns 819-b04-r08-40-10

bos 18k-pu-pr10-02

bns 813-b04-d12-61-a-10-01

bns 816-b04-tob-08-650-11

bns 819-b04-r08-40-11

bns 819-d08-d16-100-10

bos 18k-pu-pr10-s4

bns 813-b04-d12-61-a-10-02

bns 819-b04-r08-40-12

bns 819-d08-d16-100-10-fd

bns 813-b04-d12-61-a-10-0733

bns 816-b05-khg-16-602-11

bns 819-b04-r08-40-13

bns 819-d08-d16-62-10

bns 813-b04-d12-61-a-12-04

bns 816-b05-na-12-602-11

bns 819-b04-r08-46-10

bns 819-d08-e12-100-10-fd

bns 813-b04-d12-61-a-20-01

bns 816-b05-pa-12-602-11

bns 819-b04-r08-46-11

bns 813-b04-d12-61-a-20-02

bns 816-b05-pa-12-605-11

bns 819-b04-r08-46-13

bns 819-d08-l12-100-10-fd

bns 813-b04-d12-61-a-22-04

bns 816-b05-pa-12-610-11

bns 819-b04-r10-46-10

bns 813-b04-d12-72-10-01

bns 816-b05-pa-16-602-11

bns 819-b04-r10-46-11

bns 813-b04-d12-72-10-02

bns 816-b05-tha-16-602-11

bns 819-b04-r10-46-12

bns 819-d08-r12-100-10-fd

bns 813-b04-e12-61-a-22-04

bns 819-b04-r10-46-13

bns 819-d08-r12-100-10-fe

bwg 0-08-14-00-p-r-01 5

bns 816-b05-tob-08-603-11

bns 819-b04-r12-61-12-10

bns 813-b04-k12-61-a-22-04

bns 816-b05-tob-08-650-11

bns 819-b04-r12-61-12-10-fd

bns 819-d08-r16-100-10

bns 813-b04-l12-61-a-12-04

bns 819-b04-r12-72-10

bns 819-d08-r16-100-10-fd

bns 813-b04-l12-61-a-20-01

bns 816-b05-ws-12-610-11

bns 819-b04-r16-61-16-10

bns 819-d08-r16-62-10

bns 813-b04-l12-61-a-22-04

bns 819-b04-r16-72-10

bns 819-d10-d12-100-10

bns 813-b04-l16-61-b-10-01

bns 819-b04-r16-72-10-fd

bns 819-d10-d12-100-10-fd

bns 813-b04-r12-61-a-10-01

bns 816-b06-na-12-602-11

bns 819-b05-d08-40-10

bns 819-d10-d12-100-10-fd-s90s

bns 813-b04-r12-61-a-20-01

bns 816-b06-pa-12-602-11

bns 819-b05-d08-40-11

bns 813-b04-r12-61-a-20-01-fc

bns 816-b06-pa-12-610-11

bns 819-b05-d08-40-13

bns 819-d10-d16-100-10

bns 813-b04-r12-61-a-20-02

bns 816-b06-pa-16-602-11

bns 819-b05-d08-46-11

bns 813-b04-r12-61-a-22-04

bns 816-b06-tha-16-602-11

bns 819-b05-d08-46-13

bns 813-b04-r12-61-a-2204fc

bns 816-b06-tha-16-602-11-s90r

bns 819-b05-d10-46-11

bns 819-d10-l12-100-10

bns 816-b06-tha-16-605-11

bns 819-b05-d12-61-12-10

bns 819-d10-r12-100-10

bns 813-b04-r16-61-b-22-04

bns 816-b06-tnb-10-603-11

bns 819-b05-d12-61-12-10-fd

bns 819-d10-r12-100-10-fd

bns 813-b05-d12-61-a-10-01

bns 816-b06-tob-08-603-11

bns 819-b05-d12-72-10

bns 819-d10-r12-62-10

bns 813-b05-l12-61-a-10-01

bns 816-b06-tob-08-650-11

bns 819-b05-e08-40-11

bns 819-d10-r16-100-10

bns 813-b05-l12-61-a-12-05

bns 816-b06-ws-12-602-11

bns 819-b05-k08-40-10

bns 819-d12-d12-100-10

bns 813-b05-l12-61-a20-02

bns 816-b06-ws-12-605-11

bns 819-b05-k08-40-11

bns 819-d12-d12-100-10-fd

bns 813-b05-l12-61-a-22-05

bns 816-b08-pa-12-602-11

bns 819-b05-k08-46-11

bns 819-d12-d12-100-10-fe

bns 816-b08-pa-12-605-11

bns 819-b05-k12-61-12-10

bns 819-d12-d12-62-10

bns 813-b05-r12-61-a-22-05

bns 816-b08-pa-16-602-11

bns 819-b05-l12-61-12-10

bos 18k-xt-is10-02

bns 813-b06-d12-61-a-10-01

bns 816-b08-tha-16-602-11

bns 819-b05-r08-40-10

bns 819-d12-r12-100-10

bos 18k-xt-is10-s4

bns 813-b06-d12-61-a-10-02

bns 816-b08-tob-08-603-11

bns 819-b05-r08-40-11

bns 819-d12-r12-100-10-fd

bns 813-b06-d12-61-a-22-06

bns 816-b10-pa-12-602-11

bns 819-b05-r08-40-12

bns 813-b06-l12-61-a-12-06

bns 816-b10-pa-12-602-11-s90s

bns 819-b05-r08-40-13

bns 819-d14-d12-100-10-fd

bns 813-b06-l12-61-a-22-06

bns 819-b05-r08-40-13-s 80

bns 816-b10-tha-16-602-11

bns 819-b05-r08-46-11

bns 819-fd-60-101

bns 813-b06-r12-61-a-10-01

bns 816-b12-pa-12-602-11

bns 819-b05-r08-46-13

bns 819-fd-60-101-fd

schalteinheit kpl bsw 5/2 wv

bns 813-b06-r12-61-a-20-01-fc

bns 816-b12-pa-12-602-11-s90s

bns 819-b05-r10-46-10

bns 819-fd-60-101-fd-s 80

bns 813-b06-r12-61-a-22-06

bns 816-b12-tob-08-603-11

bns 819-b05-r10-46-11

bns 819-fd-60-101-fd-s80r

bns 813-b06-r12-61-a-22-06-fc

bns 816-b14-pa-12-602-11

bns 819-b05-r10-46-13

bns 813-c02-d12-61-c-10-01

bns 819-b05-r12-61-12-10

bns 819-fd-60-101-fe-s80r

bns 813-c02-d16-61-d-22-02

bns 819-b05-r12-61-12-10-fd

bns 819-b05-r12-72-10

bns 819-fd-60-101-s80r

bns 813-c03-d12-61-c-10-01

bns 819-b05-r12-72-10-fd

bns 819-fd-60-w13

bns 813-c03-d12-61-c-12-03

bns 819-b06-d08-40-10

bns 819-fe-60-101

bns 813-d02-d12-100-10-01

bns 819-100-d-10

bns 819-b06-d08-40-11

bns 819-fe-60-101-fd

bns 813-d02-d12-100-10-01-fd

bns 819-b06-d08-40-12

bns 819-fk-60-101

bns 813-d02-d12-100-12-02

bns 819-100-d-11

bns 819-b06-d08-40-13

bns 819-fk-60-101-fd

bns 813-d02-d12-100-12-02-fd

bns 819-100-d-11-s 80

bns 819-b06-d08-40-13-s 80

bns 819-fk-60-101-fd-s 80

zws-15/cd/qs

bns 813-d02-d12-100-20-01

bns 819-100-d-11-s4

bns 819-b06-d08-46-10

zws-15/ce/qs

bns 813-d02-d12-100-20-01-fd

bns 819-100-d-12

bns 819-b06-d08-46-11

bns 819-fk-60-101-fe

c08f-3a1-5001

zws-15/ci/qs

blg 1-010-210-050-pv01-sx

bns 813-d02-d12-100-22-02

bns 819-100-d-12-s 80

bns 819-b06-d08-46-11-fc

zws-15/cu/qs

blg 1-010-210-070-pv01-sx

bns 813-d02-d12-100-22-02

bns 819-100-d-13

bns 819-b06-d08-46-13

zws-24/cd/qs

blg 1-015-085-040-pv01-sx

bns 819-100-d-13-s 80

bns 819-b06-d10-46-10

bns 819-fk-60-w13

c08f3b1-10k-010

zws-24/ce/qs

blg 1-015-085-070-pv01-sx

bns 813-d02-d16-100-10-01

bns 819-100-d-13-s4

bns 819-b06-d10-46-11

bns 819-fl-60-101

zws-24/ci/qs

blg 1-015-210-050-pv01-sx

bns 813-d02-d16-100-10-01

bns 819-100-e-10

bns 819-b06-d10-46-13

bns 819-fl-60-101-fd

zws-24/cu/qs

blg 1-015-210-070-pv01-sx

bns 813-d02-d16-100-22-02

bns 819-100-e-11

bns 819-b06-d12-61-12-10

bns 819-fl-60-w13

blg 1-030-085-070-pv01-sx

bns 813-d02-d16-100-22-02

bns 819-100-e-12

bns 819-b06-d12-61-12-10-f

bns 819-fr-60-101

zws-70/cd/qs

blg 1-030-210-070-pv01-sx

bns 819-100-e-13

bns 819-fr-60-101-fd

zws-70/ce/qs

bns 813-d02-d16-62-10-01-f

bns 819-100-k-10

bns 819-b06-e08-40-11

bns 819-fr-60-101-fd-s80r

zws-70/ci/qs - 18018

bns 813-d02-d16-62-12-02-fd

bns 819-100-k-10-s80

bns 819-b06-e08-46-11

bns 819-fr-60-101-fe

zws-70/cu/qs

bns 813-d02-l12-100-10-01

bns 819-100-k-11

bns 819-b06-k08-40-10

bns 819-fr-60-101-fe-s80r

bns 819-100-k-12

bns 819-b06-k08-40-11

bns 819-fr-60-101-s 80

bns 813-d02-l12-62-12-02

bns 819-100-k-12-s 80

bns 819-b06-k12-61-12-10

bns 813-d02-r12-100-10-01

bns 819-100-k-13

bns 819-b06-l12-61-12-10

bns 819-fr-60-w13

bns 813-d02-r12-100-12-02-fd

bns 819-100-r-10

bns 813-d02-r12-100-20-01

bns 819-100-r-10-s80

bns 819-b06-r08-40-10

bns 819-x481-99-k-10

bns 813-d02-r12-100-22-02

bns 819-100-r-11

bns 819-b06-r08-40-11

bns 819-x481-99-r-10

bns 819-100-r-11-fc

bns 819-b06-r08-40-13

bns 819-100-r-11-s80

bns 819-b06-r08-46-10

bns 819-x511-99-d-10-s 4

c08f4a1-500-012

bns 813-d05-r16-62-10-04-fd

bns 813-d06-d12-100-10-01-fd

bns 813-d06-d12-100-20-01

bns 813-d06-d12-100-22-06

bns 813-d06-d16-100-22-06

bns 813-d06-l12-100-10-02-fd

bns 813-d06-l12-100-22-06

bns 813-d06-l12-100-22-06-fc

bns 813-d06-r12-100-10-01-fd

bns 813-d06-r12-100-12-06-fd

bns 813-d06-r16-62-10-01

bns 813-d08-d16-100-10-02-fd

bns 813-d08-l16-100-22-08

bns 813-d08-r12-100-12-08-fd

bns 813-fe-60-183

bns 813-fe-60-186 zb2bz101c xb2-b body with in/0 contact 10

wg-100/100/3 2 wg-250/200/3 2 watsga-32a/4r 7 watsga-63a/4r 5 watsga-100/4r 3 watsga-200/4r 1 阀门指示器
50-0406-12670-532 3 rcs-985a电源插件 dc220v 1 rcs-985ts电源插件 dc220v 1 rcs-974ag电源插件 dc220v 1
钠玻璃电极 23-8s 2 甘汞参比电极 001s 2 流量计 lzb-6mt 水 50~500ml/min 20 二位二通常闭电磁阀
zcmf-50 2 nptla-c21d 10 npxm-2012po 8 npxj-43010 4 nppd-c111d 4 决对压力表 y-100 0-2mpa 2 决对压力表
y-100 0-4kpa 1 铝合金管头 20 30 闪光报警器 xxs-01b 4 直角式丝口电磁阀 dmf-25l 10
tds-1300智能式低压电力电容器 hlsz/450-20.20g.c 16 tds-1300智能式低压电力电容器 hlfz/250-20g.c
3钠测量电极 hk-5101s 2 钠参比电极 hk-5102s-l9 2 转速传感器 cs-1(l100mm 高阻引线2米) 14 irg-4x-
z2 s13 6 光洋编码器 trd-j1000rz 10 1762-iq16 1 1762-ow16 1 snat602tac 2 电缆 1485cp1a300 1 电缆 1485cp1a150
1 万能转化开关 lw21-16/9.2208.2 2 电流表 pa11341-3x4 75/5 4 电刷 ds2222 6*32 40 多功能电源盘
oydp1-16yt/2f3032 4 流量传感器 p51530-p2 量程 : 0.3-6米/秒 管径10-36" 2 交流接触器 lc1-d40m7c 8
接触器辅助触头 la-dn31c 4 接触器辅助触头 la-dn22c 4 断路器附件 3rb2016-1sbo 2