

## RCA RCU404 多功能遥控器

产品名称	RCA RCU404 多功能遥控器
公司名称	扬州市越扬电器制造有限公司
价格	4.00/件
规格参数	适用设备:RCA 型号:RCU404 电池:2*AAA
公司地址	中国 江苏 仪征市 工厂地址：江苏省扬州市（仪征）大仪工业园区1号
联系电话	86 0514 85813052/85813066 13952706766

## 产品详情

适用设备	RCA	型号	RCU 404
电池	2*AAA	产地	扬州
品质	OK	品牌	RCA
传输距离	10-12 ( m )		

更多rca系列以及其他遥控器请联系：冯德本

qq:913914119

msn:fengdeben@hotmail.com

e-mail:deanyic@163.com

tel:13952706766

供应全球市场各大品牌各种型号sat、tv、vcd、dvd遥控器

rc-33key aiwa remote controlrc-44key aiwa remote controlrc-5vt02 aiwa remote controlrc-6vt06 7461 aiwa tv-cn201  
24 keys remote controlrc-7as08 aiwa remote controlrc-l7d aiwa remote controlrc-tc141ke 7461 aiwa 24 keys remote  
controlrc-tep1 vcr 5052 aiwa 11 keys remote controlrc-tn380b aiwa remote controlrc-tn520ex aiwa remote controlrc-  
t148 audio nc aiwa 48 keys remote controlrc-tv2 aiwa remote controlrc-zas01 vcd nc aiwa 24 keys remote controlrc-  
zvt16 7461 aiwa 30 keys remote controlrc-51a 9012 akai 21 keys remote controlrc20ve akai remote controlrc-23ve vcr  
5052 akai 16 keys remote controlre-100 akai remote control2507sum daewoo remote controldscn3928 dtc2172 50560  
daewoo 27 keys remote controlr-22 3010 daewoo 34 keys remote controlr-28b03 3010 daewoo 27 keys remote

controlr-28b04 3010 daewoo 27 keys remote control20j 9012 funai 20 keys remote control30 key funai remote control36j funai remote controlfunai24 funai remote controlvsqs0342 ge remote controlltp-623 9v batterie grundig 28 keys remote controlltp-661 grundig remote controlltp-711 grundig 24 keys remote controlltp-720 grundig 31 keys remote controlltp-725 grundig 31 keys remote controlltp-760 grundig 34 keys remote controlcle-860a hitachi remote controlcle-862a 5052 hitachi 29 keys remote controlcle-862g hitachi remote controlcle-865a 5052 hitachi cmt2138 cmt2150 26 keys remote control hitachicle-865b 5052 hitachi cmt2157 26 keys remote control hitachicle-865c 5052 hitachi 29 keys remote controlcle-866a tv-vcr 5052 hitachi 39 keys remote controlcle-866b tv-vcr 5052 hitachi 40 keys remote controlcle-866c hitachi remote controlcle-866e hitachi remote controlcle-878 5052 hitachi 26 keys remote controlcle-884 hitachi remote controlcle-886 5052 hitachi 41 keys remote controlcle-891 5052 hitachi 21d8c 29 keys remote control hitachicle-893 5052 hitachi 45 keys remote controlcle-893a hitachi remote controlcle-898 5052 hitachi 25 keys remote controlcle-900 5052 hitachi 27 keys remote controlcle-905 hitachi remote controlcle-924a 5052 hitachi 26 keys remote controlfn111 hitachi remote controlvm101 5052 hitachi cmt1435 26 keys remote control hitachivm201 hitachi remote controlvm222 hitachi remote controlvm301 5052 hitachi 29 keys remote controlvp101 3010 hitachi 29 keys remote controlvs141 hitachi remote controlrm-c300 50462 jvc 22 keys remote controlrm-c334 jvc remote controlrm-c416 jvc remote controlrm-c439 jvc remote controlrm-c457 -long 50462 jvc 26 keys remote controlrm-c457-small 50462 jvc 26 keys remote controlrm-c461 jvc remote controlrm-c462 50462 jvc 27 keys remote controlrm-c463 50462 jvc 30 keys remote controlrm-c470 50462 jvc 34 keys remote controlrm-c471 jvc remote controlrm-c530 50462 jvc 26 keys remote controlrm-c547 jvc remote controlrm-c548 50462 jvc 28 keys remote controlrm-c549 50462 jvc 27 keys remote controlrm-c565 50462 jvc 28 keys remote controlrm-c566 jvc remote controlrm-c567 50462 jvc 31 keys remote controlrm-c601 50462 jvc 34 keys remote controlrm-rxut4r audio 50462 jvc 36 keys remote controlkk-y100 3004 konka 27 keys remote controlkk-y101 3004 konka 27 keys remote controlkk-y102 50560 konka 30 keys remote controlkk-y103 50560 konka 28 keys remote controlkk-y104 50560 konka 29 keys remote controlkk-y112 3004 konka 26 keys remote controlkk-y113 50560 konka 29 keys remote controlkk-y119 50560 konka 29 keys remote controlkk-y125 9012 konka 27 keys remote controlkk-y141 3004 konka 24 keys remote controlkk-y168 3004 konka 25 keys remote controlkk-y173 chinese 7461 konka 26 keys remote controlkk-y175 3004 konka 26 keys remote controlkk-y176 chinese 3004 konka 27 keys remote controlkk-y181 konka remote controlkk-y186 50560 konka 27 keys remote controlkk-y221 konka remote controlkk-y225 konka remote controlkk-y52 3010 konka 24 keys remote controlkk-y55 3004 konka 21 keys remote controlkk-y59 3004 konka 24 keys remote controlkk-y60 50560 konka 26 keys remote controlkk-y62 50560 konka 25 keys remote controlkk-y78 50560 konka 27 keys remote controlkk-y79 50560 konka 25 keys remote controlkk-y84 3004 konka 30 keys remote controlkk-y85 3004 konka 85 keys remote controlkk-y93 3004 konka 23 keys remote controlkk-y98 50560 konka 27 keys remote control105-198d 5052 lg 31 keys remote control lg goldstar105-210a 5052 lg 25 keys remote control105-210j 5052 lg 26 keys remote control105-210n 5052 lg 26 keys remote control105-224p 3010 lg 42 keys remote control105-229w lg remote control105-230a 3010 lg 25 keys remote control105-230d 3010 lg 25 keys remote control105-230f 5052 lg 25 keys remote control105-230g lg remote control105-230m 3010 lg 25 keys remote control105-520t nc lg 23 keys remote control229y(46key) lg 46 keys remote control6710u00017m lg remote control6710v00007a tv-vcr 3010 lg 51 keys remote control6710v00007d 3010 lg 50 keys remote control6710v00008k 5052 lg 37 keys remote control6710v00011j lg remote control6710v00011q lg remote control6710v00017f 3010 lg 25 keys remote control6710v00017g 3010 lg 24 keys remote control6710v00017h 3010 lg 26 keys remote control6710v00017m 3010 lg 22 keys remote control6710v00028n chinese 3010 lg 26 keys remote control6710v00029d tv-vcr 3010 lg 50 keys remote controlfs-185e 5020 lg nc-95j/k 24 keys remote controltv5710v00005a lg remote controlvs-068a 3010 lg 28 keys remote control2098 nc mitsubishi 24 keys remote control28 key tv-vcr nc mitsubishi 28 keys remote controllc-1631-es 50119p mitsubishi 20 keys remote controllc-1631-es 50119p mitsubishi 20 keys remote controlmx-236 5052 nec 25 keys remote controlrc-1111 nec remote controlrd-1078e 5052 nec 26 keys remote controlrd-1083e 5052 nec 25 keys remote controlrd-1110e 50530 nec 31 keys remote controlrd-339e 7461 nec 31 keys remote controleur3rq 2188 panasonic 38 keys remote controleur501310 2188 panasonic tc-2014 tc-2140 23 keys remote controleur501320 panasonic tc-2550 remote controleur501325 2188 panasonic 25 keys remote controleur501350 panasonic remote controleur501380 2188 panasonic 27 keys remote controleur501390 2188 panasonic 30 keys remote controleur501450 2188 panasonic remote controleur50700 2188 panasonic 43 keys remote controleur50701 2188 panasonic 47 keys remote controleur50707 50531 panasonic 47 keys remote controleur50708 2188 panasonic 52 keys remote controleur50710 50531 panasonic tc-2111r tc-29v30r 42 keys remote controleur50711 panasonic remote controleur511022 panasonic remote

controleur511023 panasonic remote controleur51910 panasonic remote controleur51912 panasonic remote  
controleur51970s rmpc-54key tv-vcr 2188 panasonic 54 keys remote controleur51971s rmpa-46key tv-vcr 2188  
panasonic 46 keys remote controleur51973s rmpc-52key tv-vcr 2188 panasonic 52 keys remote controleur5711001 vcr  
2188 panasonic 10 keys remote controleur641027 560200 remote controleur641952 tv-vcr 2188 panasonic 36 keys  
remote controleur64198 panasonic remote controleur644660 2188 panasonic 38 keys remote controleur644661  
panasonic tc-2197 tc-21s90x tc-22s200x tc-29s95x tc-25s100x tc-25f1 tx14f2t remote controlpab9-42key see rm9ab-42  
tv-vcr 2188 panasonic 42 keys remote controlraksl429wh 2188 panasonic 27 keys remote controlrmak-sl429wh  
panasonic remote controlrmhe-46key tv-vcr 2188 panasonic 45 keys remote controlrmpc-55key panasonic remote  
controlsr-30 vcr 2188 panasonic 14 keys remote controltnq10408 2188 panasonic tc-2188 tc- 2588 tc-2110 tc-2140  
tc-2150 tc-2160 tc-21-10r tc-2530 tc-2550 22 keys remote control panasonicctnq10481 panasonic remote  
controltnq1652 2188 panasonic 16 keys remote controltnq20026a tv-vcr 2188 panasonic 33 keys remote  
controltnq2636 tv-vcr 560200 panasonic 34 keys remote controltnq2637 panasonic remote controltnq2643 panasonic  
remote controltnq2645 560200 panasonic tc-2186 tc-1870 tc1871 tc-1872 tc-1873 tc-2070 tc-2185 tc-2 171 tc-2173 tc-  
d21c tc-d25c 54c3 26 keys remote controltnq2647 560200 panasonic tc-2185 26 keys remote control  
panasonicctnq2673 panasonic remote controltnq2678 panasonic tc-2163 tc-2187 tc-2636 tc-2678 tc-m25 remote  
controltpnq10449-4722 panasonic remote controlveq1183 2188 panasonic 41 keys remote controlrc-0301 philips  
remote controlrc-0764-01 nc philips 31 keys remote controlrc-27427 3010 philips 27 keys remote  
controlrc-283501-01 3010 philips 35 keys remote controlrc-283502-01 philips remote controlrc-283503-78 philips  
remote controlrc-5901 philips remote controlrc-6805 3010 philips 25 keys remote controlrc-7801 philips remote  
controlrc-7802 3010 philips 25 keys remote controlrc-7802-s 3010 philips 26 keys remote controlrc-7805 philips  
remote controlrc-7807 philips remote controlrc-7812 3010 philips 26 keys remote controlrc-7812-s philips remote  
controlrc-7847-01 philips remote controlrc-7851-64 philips remote controlrc-7940 3010 philips 39 keys remote  
controlrc-7952 3010 philips 39 keys remote controlrc-7953 nc philips 39 keys remote controlrc-7954 3010 philips 39  
keys remote controlrc-7959 3010 philips 39 keys remote control3f14-00034-162 3010 samsung 29 keys remote  
control3f14-00034-470 samsung remote control3f14-00034-490 9012 samsung 33 keys remote control3f14-00034-890  
samsung remote control3f14-00034-901 samsung remote control3f14-00034-982 9012 samsung 24 keys remote  
control3f14-00034-a10 9012 samsung 27 keys remote control3f14-00034-b80 3010 samsung 29 keys remote  
control3f14-00038-091 tv-vcr 3010 samsung 31 keys remote control3f14-00038-093 3010 samsung 27 keys remote  
control3f14-00038-120 9012 samsung 27 keys remote control3f14-00038-150 samsung remote control3f14-00038-162  
3010 samsung remote control3f14-00038-220 3010 samsung 34 keys remote control3f14-00038-242 3010 samsung 31  
keys remote control3f14-00038-300 3010 samsung 27 keys remote control3f14-00038-310 samsung remote  
control3f14-00038-311 9012 samsung 26 keys remote control3f14-00038-340 samsung remote control3f14-00038-420  
3010 samsung 27 keys remote control3f14-00038-450 tv-vcr "3010 samsung cs-3385z cs-3385z cs-5385zr (trtbr)  
ck-5079zr ck-5081z ck-5085zr (trtbr) ck-5379zr (tr) ck-3382zr ck-5366zr" 31 keys remote control3f14-00038-470  
9012 samsung 26 keys remote control3f14-00038-570 3010 samsung 26 keys remote control3f14-00038-781 9012  
samsung 24 keys remote control3f14-00038-900 samsung remote control3f14-00038-981 9012 samsung 24 keys  
remote controlaa59-00064a 3010 samsung 26 keys remote controlaa59-00104h samsung 28 keys remote  
controlaa59-00135a 9012 samsung 29 keys remote controlaa59-0026b 3010 samsung 27 keys remote  
controlaa59-10031f samsung remote controlaa59-10031q 3010 samsung 27 keys remote controlaa59-10075l samsung  
remote controlaa59-10081f-1 "3010 samsung ck-3373 ck-3385zr ck-5085zr ck-5366zr ck-5373 ck-5385zr ck-5073  
ck-5079 ck-5379 ck-5320 ck-14e3 ck-14f1vr(xr) ck-20e3vr ck-20f1vr ck-3339zr ck-1463vr ck-20e3vr ck-14c8vr  
ck-20c8vr ck-14r1vr ck-20r1vr ck-501fzr4x ck-fxb4x ck-ck-338ctr4x ck-czr4x ck-ck-508ctr4x ck-5386 ck-5344" 27  
keys remote controlaa59-10093a samsung remote controlaa59-10095t see 3f14-00034-982 9012 samsung k15a ct-501h  
ct-5038 ct-501fz ct-20f2z remote controlaa59-10129d chinese 3010 samsung 24 keys remote controlah59-00020c vcd  
nc samsung 22 keys remote control2102 sansui remote controlrs-s161 3010 sansui 25 keys remote  
control1av0u10b06700 sanyo remote control1avov10b056000 sanyo remote control11b4u10b00100 5052 sanyo 23  
keys remote control11b4u10b00300 5052 sanyo 24 keys remote control11b4u10b00400 5052 sanyo 32 keys remote  
control11b4u10b00500 5052 sanyo 26 keys remote control11b4u1t0032 sanyo remote control41keys sanyo remote  
control4aa4u1t0032 sanyo remote control4aa4u1t0064 5052 sanyo 28 keys remote control4aa4u1t0104 sanyo remote  
control7462 huaqiang sanyo=huaqiang 33 keys remote control huachangctp6771 5052 sanyo 32 keys remote  
controlctp6791 5052 sanyo 23 keys remote control7462 huaqiang 7462 huaqiang=sanyo 33 keys remote control

huaqiangfor sanyo 5052 sanyo 30 keys remote controllav0u10b00800 5052 sanyo 23 keys remote controllavou10b03202 sanyo remote controllavou10b09300 sanyo remote controllavov10b01900 sanyo remote controlrc344 ampli sanyo 6 keys remote controlrc-371 sanyo remote controlrm-d 7461 sanyo 32 keys remote controlg0009kj 50530 sharp 33 keys remote controlg0018kj sharp remote controlg0021kj sharp remote controlg0023kj 50530 sharp 29 keys remote controlg0029key sharp remote controlg0329cesa nc sharp 18 keys remote controlg0552cesa sharp remote controlg0597cesa sharp remote controlg0676cesa 50530 sharp dv-2100 27 keys remote control sharpg0711cesa sharp remote controlg0755pesa 50530 sharp 30 keys remote controlg0756cesa 50530 sharp 21n52 dv-5407 29 keys remote control sharpg0764pesa 50530 sharp 29 keys remote controlg0775cesa sharp remote controlg0804pesa 50530 sharp 31 keys remote controlg0814pesa 50530 sharp 25 keys remote controlg0817pesa 50530 sharp 23 keys remote controlg0826pesa sharp remote controlg0854pesa sharp remote controlg0896cesa sharp remote controlg0933pesa 50530 sharp 32 keys remote controlg1021cesa sharp remote controlg1030cesa sharp remote controlg1035cesa sharp remote controlg1069pesa 50530 sharp 31 keys remote controlg1084pesa 50530 sharp 37 keys remote controlg1085pesa 50530 sharp 38 keys remote controlg1119cesa 50530 sharp 50 keys remote controlg1133pesa 50530 sharp g1169pesa 25 keys remote controlg1169pesa 50530 sharp g1133pesa 25 keys remote controlg1250 sharp remote controlg1324cesa sharp remote controlg1342pesa 50530 sharp 25 keys remote controlg1350pesa tv-vhs 50530 sharp remote controlg1943ce see spx1943ce 50530 sharp 27 keys remote controlg2050 c-2050 nc sharp 23 keys remote controlg9807 sharp remote controlrc510n sharp remote controltob1450b nc sharp 21 keys remote control26c-1 3010 skyworth 33 keys remote control26c-2 3010 skyworth 35 keys remote control26c-3 chinese 3010 skyworth 35 keys remote control26c-4 3010 skyworth 36 keys remote control26r-1 3010 skyworth 37 keys remote control26t-1 3010 skyworth 37 keys remote controlrm remote controlrm-116 no reset 50531 sony 26 keys remote controlrm-210 sony remote controlrm-2910 50531 sony 28 keys remote controlrm-338 sony remote controlrm-626a 50119p sony ic £ ° m50119p kv-1882ch kv-1432ch kv-2062ch 26 keys remote control sonyrm-643 sony remote controlrm-656 50531 sony 24 keys remote controlrm-656a 50531 sony ic £ ° bu2483-2d kv-2181dv kv-182d 24 keys remote control sonyrm-677 sony remote controlrm-677c 50531 sony ic £ ° bu3780f kv-2553 24 keys remote control sonyrm-681 chinese 50531 sony 30 keys remote control sonyrm-687c 50531 sony kv-2184tc 23 keys remote control sonyrm-80902 sony remote controlrm-80903 sony remote controlrm-80904 sony remote controlrm-821 sony remote controlrm-827s 50531 sony kv-1485 kv-2185 kv-2565 kv-2585 kv-2825 kv-2965 kv-2966 27 keys remote control sonyrm-827t 50531 sony 29 keys remote controlrm-836 50531 sony 27 keys remote controlrm-839 50531 sony 28 keys remote controlrm-841 sony remote controlrm-845p tv-vcr 50531 sony 43 keys remote control sonyrm-845s 50531 sony 30 keys remote controlrm-849s 50531 sony kv-2189 25 keys remote control sonyrm-857 50531 sony 27 keys remote controlrm-857a 50531 sony kv-f29mf1 kv-k29mf1 kv-f25mf1 27 keys remote control sonyrm-858 50531 sony 29 keys remote controlrm-859 sony remote controlrm-861 50531 sony kv-25fxr1 30 keys remote controlrm-867 sony remote controlrm-869 50531 sony 29 keys remote control sonyrm-870 50531 sony 29 keys remote controlrm-873 50531 sony 29 keys remote controlrm-878 sony remote controlrm-883 50531 sony 29 keys remote controlrm-952 50531 sony 31 keys remote controlrm-954 50531 sony 33 keys remote controlrm-99 sony remote controlrm-s305 sony remote controlrmt-217 vcr 50119p sony 17 keys remote controlrmt-dv10 vcd 50530 sony 24 keys remote controlrmt-v181g 50531 sony 45 keys remote controlrmt-v55 sony remote controlrm-v11 universal sony remote controlrm-v12 universal sony remote controlrm-v18a ntsc universal sony remote controlrm-v8a ntsc universal sony 30 keys remote controlrm-y116 50531 sony 27 keys remote controlrm-y145a 50531 sony 28 keys remote controld-001 tcl dvd2500 remote controlrc-031 nc tcl-2101as tcl-1701as 24 keys remote controlrc-033 3010 tcl-2128 tcl-2129 tcl-2166 tcl-2969a 23 keys remote controlrc-034 tcl-2528 tcl-2938 remote controlrc-035 see rc-093 3010 tcl-9525z tcl-9421 tcl-2568 tcl-9329z tcl-9425 tcl-2968z tcl-2566 tcl-9328 tcl-2966s tcl-2508 tcl-2908 tcl-9329sp tcl-2166 tcl-2169 tcl-2118z tcl-2188z tcl-2986z tcl-2509s tcl-9228 tcl-9529z tcl-9229 28 keys remote controlrc-036 tcl-2166 tcl-2566 tcl-2129sz tcl-1701 tcl-2969a tcl-2128sz tcl-2128s tcl-2509 tcl-2568 tcl-2199 tcl-2128 remote controlrc-037 tcl-2129ni tcl-2938zni remote controlrc-038 chinese 9012 tcl-2108 tcl-2169a 24 keys remote controlrc-039 chinese 3010 tcl-2501c 30 keys remote controlrc-040 chinese 3010 tcl-2501a tcl-2901a 29 keys remote controlrc-041 tcl-2919az remote controlrc-042 tcl-2966a remote controlrc-042 tcl-2966a remote controlrc-062gh tcl-9625bgh tcl-9629bgh remote controlrc-062h tcl-9625bzh remote controlrc-063n tcl-2969n tcl-9625bn tcl-9629bn tcl-2968ni remote controlrc-064 see rc-032 9012 tcl-2968z tcl-2968 tcl-9629b tcl-9629bz tcl-2969 tcl-9625b tcl-9625bz tcl-9621 tcl-9621c tcl-9621d 25 keys remote controlrc-071 tcl-3438r remote controlrc-072 tcl-3438d tcl-3438l remote controlrc-073 tcl-3438 tcl-3409 remote controlrc-074 tcl-2968sp remote controlrc-074bp tcl-5438bpr remote

controlrc-075 tcl-2968sz remote controlrc-076ni tcl-3409ni tcl-2509ni remote controlrc-078 tcl-2976s tcl-2966  
tcl-3438r tcl-2968sz remote controlrc-078b 3010 tcl-2976s tcl-2966 26 keys remote controlrc-081 tcl-3498gh remote  
controlrc-091 9012 tcl-1419 tcl-9614c tcl-9621b tcl-9621c tcl-9621d 25 keys remote controlrc-092 3010 tcl-2129  
tcl-2129s tcl-2128sb tcl-2568 tcl-1701 tcl-2128 tcl-2566 tcl-2166 27 keys remote controlrc-093 see rc-035 3010  
tcl-9525z tcl-9421 tcl-2568 tcl-9329z tcl-9425 tcl-2968z tcl-2566 tcl-9328 tcl-2966s tcl-2508 tcl-2908 tcl-9329sp  
tcl-2166 tcl-2169 tcl-2118z tcl-2188z tcl-2986z tcl-2509s tcl-9228 tcl-9529z tcl-9229 24 keys remote controlrc-094p  
tcl-2938p remote controlrc-095h tcl-2938h remote controlrc-096gh tcl-2968ch tcl-2528p remote controlrc-097h  
tcl-2968h remote controlrc-099p tcl-2968p remote controlrc-099sz tcl-2938sz tcl-2528sz remote controlrc-801 tcl  
d-303 d-302a remote controlrc-803 tcl d-603 remote controlrc-805 tcl d-305 d-306 remote controlrc-b01 chinese  
9012 tcl-2166b 25 keys remote controlrc-b02 tcl-2109c remote controlrc-b02t tcl-2139a remote controlrc-c001 tcl  
cvd2500 remote controlrc-c501 tcl cvd3000 remote controlrc-v701 tcl d-305a remote controlrc-v808 tcl d-303b  
remote controlrc-v810 tcl d-305c remote controlrct1003 thomson remote controlrct2011 thomson remote  
controlrct3000 thomson remote controlrct3001 thomson remote controlrct3003 nc thomson 20 keys remote  
controlrct3004 nc thomson 22 keys remote controlcq-b046a ct-10000 5052 toshiba remote controlct-3500 5052  
toshiba remote controlct-3700 5052 toshiba remote controlct-5900 5052 toshiba remote controlct-9129 toshiba  
remote controlct-9199 5052 toshiba 198d6c 218d6c 2185 289 218rc2 26 keys remote controlct-9200 toshiba remote  
controlct-9335 toshiba remote controlct-9369 5052 toshiba 219r9c 24 keys remote controlct-9396 5052 toshiba 21r92  
25 keys remote controlct-9430 5052 toshiba 2500xh j ø 2806 j ø 289x8m 28 keys remote control toshibact-9476  
toshiba remote controlct-9507 5052 toshiba 25 keys remote control toshibact-9565 5052 toshiba 24 keys remote  
controlct-9599 5052 toshiba 26 keys remote controlct-9600 toshiba remote controlct-9630 tv-vcr 5052 toshiba 46 keys  
remote controlct-9631 5052 toshiba 40 keys remote controlct-9632 tv-vcr 5052 toshiba 46 keys remote controlct-9640  
5052 toshiba 2125 2128 24 keys remote control toshibact-9643 toshiba remote controlct-9687 5052 toshiba 24 keys  
remote controlct-9712 5052 toshiba 40 keys remote controlct-9730 toshiba remote controlct-9731 5052 toshiba 37  
keys remote controlct-9734 5052 toshiba 46 keys remote controlct-9737 5052 toshiba 25 keys remote controlct-9760  
toshiba remote controlct-9777 5052 toshiba 41 keys remote controlct-9782 5052 toshiba 29 keys remote  
controlct-9785 toshiba remote controlct-9801 toshiba remote controlct-9807 toshiba remote controlct-9818 5052  
toshiba 35 keys remote controlct-9840 5052 toshiba 2540 25 keys remote controlct-9842 5052 toshiba 26 keys remote  
controlct-9843 5052 toshiba 31 keys remote controlct-9851 5052 toshiba 25 keys remote controlct-9858 5052 toshiba  
34 keys remote controlct-9869 5052 toshiba 40 keys remote controlct-9872 toshiba remote controlct-9878 5052  
toshiba 26 keys remote controlct-9879 5052 toshiba 26 keys remote controlct-9880 5052 toshiba 31 keys remote  
controlct-9881 5052 toshiba 36 keys remote controlct-9893 toshiba remote controlct-9922 5052 toshiba 25 keys  
remote controlct-9931 toshiba remote controlct-9975 toshiba remote controlvt-b2 vcr 5052 toshiba 11 keys remote  
controlvt-e35 toshiba remote controlvt-k3c toshiba remote control00819 universal zhongghe 47 keys remote  
control00897a chinese universal zhongghe 47 keys remote controlrc-608 remote controlrm-33c chinese universal  
chunghop 33 keys remote controlrm-99 tv-vcd chinese universal chunghop 42 keys remote controlzx689 universal 22  
keys remote controlleaper-10 handy universal writer 1 pc program toolsleaper-3 standalone eprom programmer 1 pc  
program toolslp-su1 stand-alone universal & tester 1 pc program toolsemmibox cellular phone program tools 1 pc  
program toolsaxel ax-1500 video head tester video head tester (vhs beta multi system) ax-1500 1 pc testers-811a  
remote control tester 1 pc testers.h-w118a flyback tester 1 pc testerttl coms ic tester ttl/coms ic tester (for ttl 74xx &  
coms cd4xxx ) 1 pc tester