

艾默生变频器维修

产品名称	艾默生变频器维修
公司名称	上海芯维自动化科技有限公司
价格	面议
规格参数	品牌:艾默生 型号:EV2000-4T0075P
公司地址	上海市奉贤区南桥镇金齐路188弄
联系电话	021-31606878 18679441819

产品详情

可修复艾默生变频器常见故障：无显示、缺相、过流、过压、欠压、过热、过载、接地、参数错误、有显示无输出、模块损坏等；

?????????td2100????????? ?ev1000?ev2000?????????????td3000?????????????????td3100?????????????????td3200????????????? ?ev3000????????????????? td900?????????:td900-4t0022g,td900-4t0015g,td900-4t0007g,td900-2t0022g,td900-2t0015g,td900-2s0007g,td900-2s0004g; ev1000?????????:ev1000-2s0004g,ev1000-2s0007g,ev1000-2s0015g,ev1000-2s0022g,ev1000-4t0007g,ev1000-4t0015g,ev1000-4t0022g,ev1000-4t0037g,ev1000-4t0037p,ev1000-4t0055g,ev1000-4t0055p; ev2000?????????:ev2000-4t0055g,ev2000-4t0075p,ev2000-4t0075g,ev2000-4t0110p,ev2000-4t0110g,ev2000-4t0150p,ev2000-4t0150g,ev2000-4t0185p,ev2000-4t0185g1,ev2000-4t0220p1,ev2000-4t0220g1,ev2000-4t0300p1, ev2000-4t0300g1,ev2000-4t0370p1,ev2000-4t0370g1,ev2000-4t0450p1,ev2000-4t0450g1,ev2000-4t0550p1,ev2000-4t0550g,ev2000-4t0750g,ev2000-4t0750p,ev2000-4t0900g,ev2000-4t0900p,ev2000-4t100p; ev3100?????????:ev3100-4t0300e,ev3100-4t0220e,ev3100-4t0185e,ev3100-4t0150e,ev3100-4t0110e,ev3100-4t0075e,ev3100-4t0055e; td1000?????????:td1000-4t0055g,td1000-4t0037g,td1000-4t0022g,td1000a-4t0022g,td1000-4t0015g,td1000-4t0007g,td1000-2t0037g,td1000-2t0022g,td1000-2t0015g,td1000-2s0022g,td1000-2s0015g,td1000-2s0007g,td1000-4t0055p,td1000-4t0037p; td2000?????????:td2000-4t0450g,td2000-4t0550p,td2000-4t0370g,td2000-4t0450p,td2000-4t0300g,td2000-4t0370p,td2000-4t0220g,td2000-4t0300p,td2000-4t0185g,td2000-4,t0220p,td2000-4t0150g,td2000-4t0185p,td2000-4t0110g,td2000-4t0150p,td2000-4t0075g,td2000-4t0110p,td2000-4t0055g,td2000-4t0075p,td2000-4t2500p,td2000-4t2200g,td2000-4t2200p,td2000-4t2000g,td2000-4t2000p,td2000-4t1600g,td2000-4t1600p,td2000-4t1320g,td2000-4t1320p,td2000-4t1100g,td2000-4t1100p,td2000-4t0900g,td2000-4t0900p,td20

00-4t0750g,td2000-4t0750p,td2000-4t0550g

td2000-1?????????:td2100-4t0055s,td2100-4t0075s,td2100-4t0110s,td2100-4t0150s,td2100-4t0185s,t
d2100-4t0220s,td2100-4t0300s,td2100-4t0370s,td2100-4t0450s,td2100-4t0550s,td2100-4t0750s;

td2000-1?????????:td3000-4t0055g,td3000-4t0075g,td3000-4t0110g,td3000-4t0150g,td3000-4t0185g,t
d3000-4t0220g,td3000-4t0300g,td3000-4t0370g,td3000-4t0450g,td3000-4t0550g,td3000-4t0750g;
td3200?????????:td3200-2s0004d,td3200-2s0002d; ev800?????????:ev800-2s0002g,ev800-2s0004g,ev80
0-2s0005g,ev800-2s0007g,ev800-2s0011g,ev800-2s0015g,ev800-2s0022g,ev800-4t0004g,ev800-4t0
005g,ev800-4t0007g,ev800-4t0011g,ev800-4t0015g,ev800-4t0022g,ev800-4t0030g,ev800-4t0037g; td
3400?????????:td3400-4t0075j,td3400-4t0110j,td3400-4t0150j,td3400-4t0185j,td3400-4t0220j,td3400-4t
0300j,td3400-4t0370j,td3400-4t0450j,td3400-4t0550j,td3400-4t0750j?