

船用柴油机配件N330喷油器总成

产品名称	船用柴油机配件N330喷油器总成
公司名称	重庆蜀阳商贸有限公司
价格	1.00/件
规格参数	品牌:YANMAR 型号:N330
公司地址	重庆市沙坪坝区小杨公桥118号附6-16-2号
联系电话	15340572037

产品详情

船用柴油机配件 洋马 N330喷油器总成 YANMAR 6N330 8N330柴油机配件

?????? B&W??? L35MC; L35MCE; L42MC; L50MC; L50MCE; L60MC; L60MCE; L70MC; L70MCE; L80MC; L80MCE; S26MC; S35MC; S42MC; S50HU; S50MC; S50MC-C; S60MC; S60MC-C; S70MC; K90MC; L45GF; L45GFCA; L55GB; L55GF; L55GFCA; L67GBE; L67GF; L67GFCA; L80BS; L80GF; L80GFCA; L90GF; L90GFCA; K42EF; K45GF; K45GFCA; K62EF; K67GF; K74EF; K84EF; K90GF; L20/27; L23/30; L23/30H; L28/32; S28LH-4E; S28-U; T23HH; T23LH; T23LH-2/4; MAN??? KSZ52/105CL; KSZ70/125A; KSZ70/125B; KSZ70/150CL; KSZ90/160A; KZ52/90N; KZ60/105E; KZ70/120E; KZ70/125A; KZ78/155F; KZ86/160E; KZ90/160(A); VV40/54; VV40/54A; VV52/55; VV52/55A; VV52/55B; VV58/64;GV23.5/33; GV23.5/33ATL DAIHATSU??? DK-20; DKB-20; DK-26; DK-28; DK-32; DL-19; DLB-19; DL-20; DLB-20; DL-22; DLB-22; DL-26; DLB-26; DLM-26; DL-32; DS-16A; DS-18; DS-18A; DSB-18A; DS-20; DS-22; DSB-22; DSM-22; DSM-22S; DS-26; DS-26A; DS-26D; DSB-26A; DSM-26S; DS-28; DSB-28; DSM-28FL; DS-32; DSM-32; PKTB-16; PS-20; PSH-20; PS-22; PSHTB-22; PSHTC-22; PS-26; PS-26D; PSHT-26D; PSHTB-26D; PSHTC-26D; PS-26H; PSHT-26H; PSHTB-26H; PSHTC-26H; PSHTD-26H; PS-30; PSHTB-30; PSHTC-30 SULZER??? RTA38; RTA48; RTA48TB; RT48; RT48T; RTA52; RTA52U; RTA58; RTA58TB; RTA62; RTA62U; RTA68; RTA76; RTA84; RTA84C; RTA84M; RLA56; RLB56; RLA66; RLB66; RLA76; RLB76; RLA90; RND68; RND68M; RND76; RND76M; RND90; RND90M; RD44; RD68; AH25/30;

AL20/24; AL25/30; AL25D; ASL25/30; AT25/30; ATL25R; BAH22; ZA40S; ZL40/48 HANSHIN???
EL30; EL32; EL35; EL40; EL44; EL44D; ELS32; LF58; LH26RG; LH28; LH28G; LH28RG; LU26;
LU28; LU32; LU32G; LU35; LU35G; LU38; LU40A; LU46; LU46A; LU50A; LUD32; LUD35; LUN28;
LUN28A; LUS38 MITSUBISHI???UEC37H; UEC37L; UEC37LA; UEC45H; UEC45HA; UEC45L;
UEC45LA; UEC52HA; UEC52L; UEC52LA; UEC52LS; UEC60HA; UEC60L; UEC60LA; UEC60LS;
UEC37/88; UEC37/88?; UEC37/88H; UEC37/88H-II; UEC37/88H-IIB; UEC45/115H; UEC52/105D;
UEC52/125H; UEC60/150H; UET45/115H; UET45/75C; UET45/80D; UET52/105D; UET52/90D;
G26SS; SH-20AC; S6N-MTK; S6R-MPTK NIIGATA??? L16HS;L16HS;L25BX;L25HS;M26KGHS;M28
AFTE;M28AGTE;M28GX;M28KGHS;M31;M31X;MG25BX YANMAR??? AL-ST; AL-UT; CHL; CHL-
HTN; CHL-N; ESDL; ESL; ESL-6; GL; GL-DT; GL-ET; GL-HT; GL-ST; GL-UT; HAL; HAL-DTN; HAL-
HT; HAL-HTN; HAL-N; HAL-TN; KDL; KFL; KFL-HT; KFL-UT; KL; LAAL; LAAL-DTN; M200; M200AL-
DT; M200AL-EN; M200AL-ST; M200L; M200L-EN; M200L-ET; M200L-SN; M200L-ST; M200L-UN;
M200L-UT; M200-ST; M200-UT; M220; M220L; M220L-EN; M220L-EX; M220L-SX; M220L-UT;
M220-SN; MAL; MAL-DT; MAL-HT; MAL-HT/DT; MAL-HTS; MAL-UT/DT; ML; ML-DT; ML-HT; ML-
HTS; ML-T; N165L; N18; N18L-UN; N21; N21L; N280; N280L; N280-UN; NS40; PAL-HT; RAL; RAL-
HT; RAL-T; RL-HT; S165; S165-DT; S165-HT; S165-ST; S165-UT; S165L; S165L-DN; S165L-DT;
S165L-HN; S165L-HT; S165L-SN; S165L-T; S165L-UT; S185; S185-ST; S185-UT; S185L; S185L-ET;
S185L-ST; S185L-UT; S186L-ST; SV8A; T200-UT; T220; T220-UT; T220L; T220L-ST; T220L-UT;
T240L-ET; T240L-ST; T260; T260-ST; T260L-ST; UAL-ST; UAL-UT; UL-ST; UL-UT; U-UT; Z280;
Z280A; Z280A-EN; Z280A-ET; Z280L-UX; ZL-DT; ZL-UT ?????
S.K.L.???NVD24/20,6NVD36/24,6NVD36A-1U, 6NVD36A-2U, 6VD36/24, 6NVD48A2, 6NVD48A-2U,
6VD48A2 DEUTZ???BAM716, BAM528, BVM358, BVM540, F3 (4/5/6) 912 AKASAKA???A28?A31?A3
4?A37?A41?AH27?AH28?AH30?AH33?AH36?AH38?AH40?DM28AK?DM30FD?DM33?DM36?DM38A
K?DM46?UHS27

??YANMAR N330???????

[YANMAR??N330???????? YANMAR????8N330-EN????132654-13770](#)

[YANMAR 6N330????????? ????????](#)

-
[???????YANMAR N330??22133-140000 ??????14GB/T97.1 GASKET](#)