



????	??		
	BZ41Y-16I-25I-40I	BZ41Y-16I-25I-40I	BZ41Y-16I-25I-40I
?????	???		
??	??+????	????	?????
??	???		
????	????		
??	?????????		

?BZ41W?????????????

??	????				?????	????
		??(?) (MPa)	??(?) (MPa)	????(?) (MPa)		
BZ41H-16C	1.6	2.4	1.8	0.6	?200	????
BZ41W-16P						



32	180	135	100	78	18-2	4-18	270	180
40	200	145	110	85	18-3	4-18	310	200
50	250	160	125	100	18-3	4-18	358	240
65	265	180	145	120	18-3	4-18	373	240
80	280	195	160	135	20-3	8-18	435	280
100	300	215	180	155	20-3	8-18	500	300
125	325	245	210	185	22-3	8-18	614	320
150	350	280	240	210	24-3	8-23	674	360
200	400	335	295	265	26-3	12-23	818	400
250	450	405	355	320	30-3	12-25	969	450
300	500	460	410	375	30-4	12-25	1145	560

??	????DN	??
----	--------	----

		L	D	D1	D2	D6	b-f	Z-?d	H
BZ41W-40 P(R)	15	130	95	65	45	40	16-2	4-14	135
	20	150	105	75	55	51	16-2	4-14	190
	25	160	115	85	65	58	16-2	4-14	205
	32	180	135	100	78	66	18-2	4-18	270
	40	200	145	110	85	76	18-3	4-18	310
	50	250	160	125	100	88	20-3	4-18	371
	65	280	180	145	120	110	22-3	8-18	39
	80	310	195	160	135	121	22-3	8-18	455
	100	350	230	190	160	150	24-3	8-23	551
	125	400	270	220	188	176	28-3	8-25	628
150	450	300	250	218	204	30-3	8-25	708	



80	310	210	170	140	121	30-3	8-23	485
100	350	250	200	168	150	32-3	8-25	590
125	400	295	240	202	176	36-3	8-30	688
150	450	340	280	240	204	38-3	8-34	768
200	550	405	345	300	260	44-3	12-34	972
250	650	470	400	350	313	48-3	12-41	1059