

# BETTIS气动执行器

|      |                             |
|------|-----------------------------|
| 产品名称 | BETTIS气动执行器                 |
| 公司名称 | 天津启隆机电设备有限公司                |
| 价格   | 面议                          |
| 规格参数 | 品牌:BETTIS<br>型号:BETTIS气动执行器 |
| 公司地址 | 天津市南开区咸阳路蓝馨大厦435室           |
| 联系电话 | 022-27698160 18602688560    |

## 产品详情

BETTIS执行器, BETTIS电动执行器, BETTIS气动执行器, BETTIS液动执行器,Bettis绞齿轮式气动执行器,Bettis执行机构,Bettis球阀,Bettis蝶阀,Bettis旋塞阀

BETTIS代理 BETTIS厂家 BETTIS价格 BETTIS经销 BETTIS型号 BETTIS现货

天津启隆机电设备有限公司特价供应美国Bettis执行器, Bettis电动执行器, Bettis气动执行器,Bettis液动执行器 ,Bettis绞齿轮式气动执行器,Bettis执行机构,Bettis球阀,Bettis蝶阀,Bettis旋塞阀等。

Bettis世界气动拨插执行机构的领导者，在ESD，放空阀、切断阀应用比较广泛。Bettis成立于1929年，逐步发展成为阀门执行机构的制造集团公司及先驱。今天，Bettis作为EMERSON公司的品牌，已成为世界范围内气动、液压阀门执行结构生产制造的领先者。

Bettis BH 系列液压执行机构

Bettis GVO 系列执行机构

Bettis G 系列 Robotarm II 执行机构

Bettis CBB CBA-300系列执行机构

Bettis D系列执行机构

Bettis CBA300系列拨叉式执行机构

Bettis CBA 系列气动执行机构

Bettis CBA系列拨叉式执行机构

## Bettis CBA300系列拨叉式执行机构

## Bettis G系列拨叉式执行机构

CBA1030-SR80(CW)-M3HW ACT. BETTIS S/R JS O/R HW MAWP = 160 PSIG VA131632

CBA730-M3HW ACTUATOR BETTIS D/A JS O/R HW MAWP = 200 PSIG VA131245

CBA730-SR100(CW) ACTUATOR BETTIS S/R MAWP = 200 PSIG VA127398

CBA730-SR100(CW)-M3HW ACT. BETTIS S/R JS O/R HW MAWP = 200 PSIG VA131620

CBA730-SR80(CW)-M3HW ACT. BETTIS S/R JS O/R HW MAWP = 200 PSIG VA131622

CBA830-M3HW ACTUATOR BETTIS D/A JS O/R HW MAWP = 200 PSIG VA131251

CBA830-SR80(CW)-M3HW ACT. BETTIS S/R JS O/R HW MAWP = 160 PSIG VA131625

CBA930-SR80(CW)-M3HW ACT. BETTIS S/R JS O/R HW MAWP = 200 PSIG VA131629

CBB315-M3HW ACTUATOR BETTIS D/A JS O/R HW MAWP = 200 PSIG VA001-137-06

CBB315-SR100-M3HW ACTUATOR BETTIS S/R JS O/R HW MAWP = 200 PSIG VA001-092-24

CBB315-SR80 ACTUATOR BETTIS S/R MAWP = 200 PSIG VA152369

CBB315-SR80-M3HW ACTUATOR BETTIS S/R JS O/R HW MAWP = 200 PSIG VA001-092-91

CBB415-SR80-M3HW ACTUATOR BETTIS S/R JS O/R HW CW FAIL CLOSE

CBB420-SR100 ACTUATOR BETTIS S/R MAWP = 200 PSIG VA153636

CBB420-M3HW ACTUATOR BETTIS D/A JS O/R HW MAWP = 200 PSIG VA001-041-52

CBB420-SR80-M3HW ACTUATOR BETTIS S/R JS O/R HW MAWP = 200 PSIG VA001-093-71

CBB420-SR100-M3HW ACTUATOR BETTIS S/R JS O/R HW MAWP = 200 PSIG VA001-093-68

CBB520-M3HW ACTUATOR BETTIS D/A JS O/R HW MAWP = 160 PSIG VA001-095-95

CBB520-SR80-M3HW ACTUATOR BETTIS S/R JS O/R HW CW FAIL CLOSE

CBB525-M3HW ACTUATOR BETTIS D/A JS O/R HW MAWP = 200 PSIG VA001-005-84

CBB725 ACTUATOR BETTIS D/A MAWP = 160 PSIG VA001-005-79

CBB725-M3HW ACTUATOR BETTIS D/A JS O/R HW MAWP = 160 PSIG VA001-068-92

CBB725-SR80-M3HW-CW ACT. BETTIS S/R JS O/R HW MAWP = 160 PSIG VA001-004-87

CBB725-SR100-M3HW ACTUATOR BETTIS S/R JS O/R HW MAWP = 160 PSIG VA001-099-41

1212 110V BRAKE KIT P/N 1420-02 BETTIS

EM212 POSITION INDICATOR KNOB P/N 21355

15400 110V BRAKE KIT FLAT HUB P/N 15400-02

2212 AUX LIMIT SWITCH KIT (2) 110V BETTIS

15800 BRAKE KIT FLAT BETTIS

2800 1K OHM POT SINGLE BETTIS 800

CBA1030 ACTUATOR BETTIS D/A MAWP = 160 PSIG

CBA1030-SR60CW ACTUATOR BETTIS S/R MAWP = 160 PSIG

CBA1030-SR80(CW) ACTUATOR BETTIS S/R MAWP = 160 PSIG VA127413

CBA730 ACTUATOR BETTIS D/A MAWP = 200 PSIG VA127391

CBA730-SR100(CW) ACTUATOR BETTIS S/R MAWP = 200 PSIG VA127398

CBA730-SR60CW ACTUATOR BETTIS S/R MAWP = 200 PSIG

CBA730-SR80(CW) ACTUATOR BETTIS S/R MAWP = 200 PSIG VA127640

CBA830 ACTUATOR BETTIS D/A MAWP = 200 PSIG VA127400

CBA830-SR100CW ACTUATOR BETTIS S/R MAWP = 160 PSIG

CBA830-SR60CW ACTUATOR BETTIS S/R MAWP = 160 PSIG

CBA830-SR80(CW) ACTUATOR BETTIS S/R MAWP = 160 PSIG VA130438

CBA930 ACTUATOR BETTIS D/A MAWP = 200 PSIG

CBA930-SR100CW ACTUATOR BETTIS S/R MAWP = 200 PSIG

CBA930-SR60CW ACTUATOR BETTIS S/R MAWP = 200 PSIG

CBB315 ACTUATOR BETTIS D/A MAWP = 200 PSIG VA001-005-78

CBB315-SR100 ACTUATOR BETTIS S/R MAWP = 200 PSIG VA153725

CBB315-SR80 ACTUATOR BETTIS S/R MAWP = 200 PSIG VA152369

CBB415-SR100CW ACTUATOR BETTIS S/R MAWP = 200 PSIG

CBB420 ACTUATOR BETTIS D/A MAWP = 200 PSIG VA001-005-80

CBB520-SR100CW ACTUATOR BETTIS S/R MAWP = 160 PSIG

CBB520-SR80CW ACTUATOR BETTIS S/R MAWP = 160 PSIG

CBB420-SR100 ACTUATOR BETTIS S/R MAWP = 200 PSIG VA153636

CBB525 ACTUATOR BETTIS D/A MAWP = 200 PSIG VA001-005-81

CBB525-SR100CW ACTUATOR BETTIS S/R MAWP = 200 PSIG

CBB525-SR60CW ACTUATOR BETTIS S/R MAWP = 200 PSIG

CBB725 ACTUATOR BETTIS D/A MAWP = 160 PSIG VA001-005-79

CBB725-SR100 ACTUATOR BETTIS S/R MAWP = 160 PSIG VA153743

CBB725-SR60CW ACTUATOR BETTIS S/R MAWP = 160 PSIG

87460 HIGH TEMP SEAL KIT F/ RPB 2250 BETTIS

CBA930-SR60CW ACTUATOR BETTIS S/R MAWP = 200 PSIG

CBB415-SR100CW ACTUATOR BETTIS S/R MAWP = 200 PSIG

CBB415-SR60CW ACTUATOR BETTIS S/R MAWP = 200 PSIG

EM300M-15-C4-02-001 120V BETTIS ELEC

EM320M-30-C4-02-100 120V 4-20mA BETTIS

EM500M-30-C4-02-001 120V BETTIS ELECT

EM500M-30-C4-02-100 120V MODULATING BETTIS

EM830-18-04-02-001 NEMA4 120V ACT STD BETTIS

EM810-18-04-02-001 NEMA4 120V ACT STD BETTIS

EM520M-15-C4-02-001 120V BETTIS ELEC

EM820-18-04-02-001 NEMA4 120V ACT STD BETTIS

300915 SWITCH FOR EM300/500 /800 BETTIS

301353-1-K LIMIT SWITCH KIT 300 BETTIS

301354-1-K LIMIT SWITCH KIT 500 BETTIS

4400 1K OHM POT SINGLE BETTIS 400

LINKAGE KIT FOR 2 FLOWTE 3WAY-BETTIS RPC2250

120139 SERVICE KIT BETTIS RPC1000/1000SR

120140 SERVICE KIT BETTIS RPC5000/5000SR

38484 REPAIR KIT - BETTIS FOR CB315

120141 SERVICE KIT BETTIS RPC11000/11000SR

38494 REPAIR KIT - BETTIS

124726 SERVICE KIT RPC3650/ 3650SR BETTIS

87170 SERVICE KIT BETTIS RPB250/250SR

RPB250 SR4 ACTUATOR-BETTIS

87270 SERVICE KIT BETTIS RPB450/450SR

RPB5000 SR4 ACTUATOR-BETTIS

87370 SERVICE KIT BETTIS RPB1000/1000SR

87470 SERVICE KIT BETTIS RPB2250/2250SR

87570 SERVICE KIT BETTIS RPB5000/5000SR

87670 SERVICE KIT BETTIS RPB11000/11000SR

G1 MODULE, BLIND END CAP BETTIS G-SERIES MOP = REFER TO COMPLETE UNIT VA132640

G2 MODULE, BLIND END CAP BETTIS G-SERIES MOP = REFER TO COMPLETE UNIT VA127672

G3 MODULE, BLIND END CAP BETTIS G-SERIES MOP = REFER TO COMPLETE UNIT VA126439

G5 MODULE, BLIND END CAP BETTIS G-SERIES MOP = REFER TO COMPLETE UNIT VA119878

G4 MODULE, BLIND END CAP BETTIS G-SERIES MOP = REFER TO COMPLETE UNIT VA119877

G8 MODULE, BLIND END CAP BETTIS G-SERIES MOP = REFER TO COMPLETE UNIT VA125198

G7 MODULE, BLIND END CAP BETTIS G-SERIES MOP = REFER TO COMPLETE UNIT VA125120

CBB315SR60 ACTUATOR BETTIS

CBB420SR60 ACTUATOR BETTIS

CBB520SR60 ACTUATOR BETTIS

EM300F-15-C4-02-001 120V BETTIS

EM300M-10-C4-02-001 120V BETTIS ELEC

EM500M-15-C4-02-003 BETTIS ELECTRIC

EM300M-15-C4-02-003 BETTIS ELECTRIC

EM500M-10-C4-02-001 120VAC BETTIS ELECT

EM300M-30-C4-02-001 120V BETTIS

EM500M-10-C4-02-003 BETTIS ELECT

EM500M-30-C4-02-100 120V MODULATING BETTIS

EM500M-15-C4-02-001 120V BETTIS ELECT

M11 G70-SR-00 MODULE, O/R BETTIS G-SERIES MOP = REFER TO COMPLETE UNIT VA135946

M11 G80-DA-00 MODULE, O/R BETTIS G-SERIES MOP = REFER TO COMPLETE UNIT VA141785

M11 G80-SR-00 MODULE, O/R BETTIS G-SERIES MOP = REFER TO COMPLETE UNIT VA140248

G4 12-00 MODULE, POWER BETTIS G-SERIES MOP = REFER TO COMPLETE UNIT VA122004-D

87370 SERVICE KIT BETTIS RPB1000/1000SR

38494 REPAIR KIT – BETTIS

87470 SERVICE KIT BETTIS RPB2250/2250SR

87170 SERVICE KIT BETTIS RPB250/250SR

87270 SERVICE KIT BETTIS RPB450/450SR

87570 SERVICE KIT BETTIS RPB5000/5000SR

87670 SERVICE KIT BETTIS RPB11000/11000SR

M11 G20-DA-00 MODULE, O/R BETTIS G-SERIES MOP = REFER TO COMPLETE UNIT VA132650

M11 G20-SR-00 MODULE, O/R BETTIS G-SERIES MOP = REFER TO COMPLETE UNIT VA133658

M11 G010-DA-00 MODULE, O/R BETTIS G-SERIES MOP = REFER TO COMPLETE UNIT VA132637

M11 G70-DA-00 MODULE, O/R BETTIS G-SERIES MOP = REFER TO COMPLETE UNIT VA133907

M11 G30-DA-00 MODULE, O/R BETTIS G-SERIES MOP = REFER TO COMPLETE UNIT VA130338

M11 G010-SR-00 MODULE, O/R BETTIS G-SERIES MOP = REFER TO COMPLETE UNIT VA132638

M11 G70-SR-00 MODULE, O/R BETTIS G-SERIES MOP = REFER TO COMPLETE UNIT VA135946

M11 G30-SR-00 MODULE, O/R BETTIS G-SERIES MOP = REFER TO COMPLETE UNIT VA133493

G01 8-00 MODULE, POWER BETTIS G-SERIES MOP = REFER TO COMPLETE UNIT VA130358

M11 G80-DA-00 MODULE, O/R BETTIS G-SERIES MOP = REFER TO COMPLETE UNIT VA141785

G3 10-00 MODULE, POWER BETTIS G-SERIES MOP = REFER TO COMPLETE UNIT VA127253

M11 G80-SR-00 MODULE, O/R BETTIS G-SERIES MOP = REFER TO COMPLETE UNIT VA140248

G3 12-00 MODULE, POWER BETTIS G-SERIES MOP = REFER TO COMPLETE UNIT VA127254

G4 12-00 MODULE, POWER BETTIS G-SERIES MOP = REFER TO COMPLETE UNIT VA122004-D

G3 14-00 MODULE, POWER BETTIS G-SERIES MOP = REFER TO COMPLETE UNIT VA127255

G4 14-00 MODULE, POWER BETTIS G-SERIES MOP = REFER TO COMPLETE UNIT VA118687-D

G3 16-00 MODULE, POWER BETTIS G-SERIES MOP = REFER TO COMPLETE UNIT VA127256

G4 16-00 MODULE, POWER BETTIS G-SERIES MOP = REFER TO COMPLETE UNIT VA118546

G5 16-00 MODULE, POWER BETTIS G-SERIES MOP = REFER TO COMPLETE UNIT VA122035-D

G3 MODULE, POWER SWIVEL BETTIS G-SERIES MOP = REFER TO COMPLETE UNIT VA126083

G4 20-00 MODULE, POWER BETTIS G-SERIES MOP = REFER TO COMPLETE UNIT VA118711-D

G5 20-00 MODULE, POWER BETTIS G-SERIES MOP = REFER TO COMPLETE UNIT VA118804

G4 MODULE, POWER SWIVEL BETTIS G-SERIES MOP = REFER TO COMPLETE UNIT VA119879

G8 MODULE, POWER SWIVEL BETTIS G-SERIES MOP = REFER TO COMPLETE UNIT VA130013

G5 MODULE, POWER SWIVEL BETTIS G-SERIES MOP = REFER TO COMPLETE UNIT VA119880

G5 28-00 MODULE, POWER BETTIS G-SERIES MOP = REFER TO COMPLETE UNIT VA119722-D

G7 MODULE, POWER SWIVEL BETTIS G-SERIES MOP = REFER TO COMPLETE UNIT VA130012

M3HW18 G01-SR-00 MOD, O/RHW BETTIS G-SERIES MOP = REFER TO COMPLETE UNIT VA131054

M3HW24 G2-SR-00 MOD, O/RHW BETTIS G-SERIES MOP = REFER TO COMPLETE UNIT VA129805

M3HW24 G3-SR-00 MOD, O/RHW BETTIS G-SERIES MOP = REFER TO COMPLETE UNIT VA129232

G02-M3HW24-00 MODULE, BLIND BETTIS G-SERIES MOP = REFER TO COMPLETE UNIT VA129230

G70-00 MODULE, DRIVE BETTIS G-SERIES MOP = REFER TO COMPLETE UNIT VA118139

G80-00 MODULE, DRIVE BETTIS G-SERIES MOP = REFER TO COMPLETE UNIT VA118006

DS0600-05-CW ACTUATOR F/C BETTIS RACK & PINION MAWP = 120 PSIG VA139675

DS0950-03-CW ACTUATOR F/C BETTIS RACK & PINION MAWP = 120 PSIG VA139678

DS0600-06-CW ACTUATOR F/C BETTIS RACK & PINION MAWP = 120 PSIG VA139676

M11 G70-DA-00 MODULE, O/R BETTIS G-SERIES MOP = REFER TO COMPLETE UNIT VA133907

M11 G70-SR-00 MODULE, O/R BETTIS G-SERIES MOP = REFER TO COMPLETE UNIT VA135946

M11 G50-SR-00 MODULE, O/R BETTIS G-SERIES MOP = REFER TO COMPLETE UNIT VA134573

M11 G80-DA-00 MODULE, O/R BETTIS G-SERIES MOP = REFER TO COMPLETE UNIT VA141785

G3 10-00 MODULE, POWER BETTIS G-SERIES MOP = REFER TO COMPLETE UNIT VA127253

M11 G80-SR-00 MODULE, O/R BETTIS G-SERIES MOP = REFER TO COMPLETE UNIT VA140248

G3 12-00 MODULE, POWER BETTIS G-SERIES MOP = REFER TO COMPLETE UNIT VA127254

G4 12-00 MODULE, POWER BETTIS G-SERIES MOP = REFER TO COMPLETE UNIT VA122004-D

G4 14-00 MODULE, POWER BETTIS G-SERIES MOP = REFER TO COMPLETE UNIT VA118687-D

G4 16-00 MODULE, POWER BETTIS G-SERIES MOP = REFER TO COMPLETE UNIT VA118546

G4 20-00 MODULE, POWER BETTIS G-SERIES MOP = REFER TO COMPLETE UNIT VA118711-D

G8 MODULE, POWER SWIVEL BETTIS G-SERIES MOP = REFER TO COMPLETE UNIT VA130013

G01-SR2-00 MODULE SPRING BETTIS G SERIES MOP - REFER TO COMPLETE UNIT

G2-SR2-00 MODULE SPRING BETTIS G SERIES MOP - REFER TO COMPLETE UNIT

G01-SR3-00 MODULE SPRING BETTIS G SERIES MOP - REFER TO COMPLETE UNIT

G2-SR3-00 MODULE, SPRING BETTIS G-SERIES MOP = REFER TO COMPLETE UNIT VA130496

G01-SR4-00 MODULE, SPRING BETTIS G-SERIES MOP = REFER TO COMPLETE UNIT VA125155

G2-SR4-00 MODULE, SPRING BETTIS G-SERIES MOP = REFER TO COMPLETE UNIT VA130497

G3-SR1-00 MODULE, SPRING BETTIS G-SERIES MOP = REFER TO COMPLETE UNIT VA130506

G5-SR2-00 MODULE, SPRING BETTIS G-SERIES MOP = REFER TO COMPLETE UNIT VA118689

G7-SR2-00 MODULE, SPRING BETTIS G-SERIES MOP = REFER TO COMPLETE UNIT VA117643-D

G7-SR3-00 MODULE, SPRING BETTIS G-SERIES MOP = REFER TO COMPLETE UNIT VA117644

G7-SR4-00 MODULE, SPRING BETTIS G-SERIES MOP = REFER TO COMPLETE UNIT VA117645

G8-SR2-00 MODULE, SPRING BETTIS G-SERIES MOP = REFER TO COMPLETE UNIT VA117647

G20-00 MODULE, DRIVE BETTIS G-SERIES MOP = REFER TO COMPLETE UNIT VA119012

G010-00 MODULE, DRIVE BETTIS G-SERIES MOP = REFER TO COMPLETE UNIT VA130361

G40-00 MODULE, DRIVE BETTIS G-SERIES MOP = REFER TO COMPLETE UNIT VA119087

G30-00 MODULE, DRIVE BETTIS G-SERIES MOP = REFER TO COMPLETE UNIT VA120143-D

G50-00 MODULE, DRIVE BETTIS G-SERIES MOP = REFER TO COMPLETE UNIT VA118803

DS0350-04-CW ACTUATOR F/C BETTIS RACK & PINION MAWP = 120 PSIG VA139667

DS0950-03-CW ACTUATOR F/C BETTIS RACK & PINION MAWP = 120 PSIG VA139678

DS0350-06-CW ACTUATOR F/C BETTIS RACK & PINION MAWP = 120 PSIG VA139671

DS0950-05-CW ACTUATOR F/C BETTIS RACK & PINION MAWP = 120 PSIG VA139680

DS1600-06-CW ACTUATOR F/C BETTIS RACK & PINION MAWP = 120 PSIG VA001-074-52

DS1600-04-CW ACTUATOR F/C BETTIS RACK & PINION MAWP = 120 PSIG VA139682

G01-SR1-00 MODULE SPRING BETTIS G SERIES MOP - REFER TO COMPLETE UNIT

G01-SR2-00 MODULE SPRING BETTIS G SERIES MOP - REFER TO COMPLETE UNIT

G4-SR2-00 MODULE, SPRING BETTIS G-SERIES MOP = REFER TO COMPLETE UNIT

G01-SR3-00 MODULE SPRING BETTIS G SERIES MOP - REFER TO COMPLETE UNIT

G4-SR3-00 MODULE, SPRING BETTIS G-SERIES MOP = REFER TO COMPLETE UNIT VA118918-D

G01-SR4-00 MODULE, SPRING BETTIS G-SERIES MOP = REFER TO COMPLETE UNIT VA125155

G4-SR4-00 MODULE, SPRING BETTIS G-SERIES MOP = REFER TO COMPLETE UNIT VA118908

G5-SR1-00 MODULE, SPRING BETTIS G-SERIES MOP = REFER TO COMPLETE UNIT VA118688

G7-SR2-00 MODULE, SPRING BETTIS G-SERIES MOP = REFER TO COMPLETE UNIT VA117643-D

G8-SR3-00 MODULE, SPRING BETTIS G-SERIES MOP = REFER TO COMPLETE UNIT VA001-084-28

G7-SR3-00 MODULE, SPRING BETTIS G-SERIES MOP = REFER TO COMPLETE UNIT VA117644

G7-SR4-00 MODULE, SPRING BETTIS G-SERIES MOP = REFER TO COMPLETE UNIT VA117645

G8-SR2-00 MODULE, SPRING BETTIS G-SERIES MOP = REFER TO COMPLETE UNIT VA117647

BETTIS代理 BETTIS厂家 BETTIS价格 BETTIS经销 BETTIS型号 BETTIS现货