

# TDM1.2-30-300-W1

产品名称	TDM1.2-30-300-W1
公司名称	上海星宇机械设备有限公司
价格	面议
规格参数	
公司地址	上海市杨浦区唐山路1188弄5号602室
联系电话	021-60510250 18717727482

## 产品详情

TDM1.2-30-300-W1

TDM1.2-30-300-W1 TDM1.2-30-300-W1 TDM1.2-30-300-W1 TDM1.2-30-300-W1 TDM1.2-30-300-W1  
TDM1.2-30-300-W1 TDM1.2-30-300-W1 TDM1.2-30-300-W1 TDM1.2-30-300-W1 TDM1.2-30-300-W1  
TDM1.2-30-300-W1 TDM1.2-30-300-W1

销售热线：(86) 021-60510250 18717727482 联系人：闫菲

传 真：(86) 021-55032831 QQ：[395717253@QQ.COM](mailto:395717253@QQ.COM)

公司名：上海心雨机电设备有限公司

官方网站：<http://www.021-888.com> 伺服驱动器

DKC02.3-040-7-FW

DKC02.3-100-7-FW

DKC01.3-040-7-FW

DKC01.3-100-7-FW

DKC03.3-040-7-FW

DKC03.3-100-7-FW

DKC11.3-040-7-FW

DKC11.3-100-7-FW

DKC02.1-040-7-FW

DKC10.3-008-MGP-01VRS

FWA-ECODR3-SMT-01VRS-MS

FWA-ECODR3-SMT-02VRS-MS

FWA-ECODR3-FGP-02VRS-MS

FWA-ECODR3-FGP-03VRS-MS ,

FWA-ECODR3-SGP -03VRS-MS

FWA-ECODRV-ASE-04VRS-MS

TDM1.2-050-300-W1/220 INDRAMAT AC SERVO DRIVE TDM1.2-050-300-W1-000 INDRAMAT AC SERVO DRIVE TDM1.2-100-300-W1-220 INDRAMAT AC SERVO DRIVE TDM1.2-30-300-W1 INDRAMAT AC SERVO DRIVE TDM1.4-100-300-W1 INDRAMAT AC SERVO DRIVE TDM3.2-020-300-W0 INDRAMAT AC SERVO DRIVE TDM3.3-020-300-W0 INDRAMAT AC SERVO DRIVE TDM4.1-020-300-W0 INDRAMAT AC SERVO DRIVE

DDS02.1-A050-DA02-01-FW INDRAMAT AC SERVO DRIVE DDS02.1-A100-D INDRAMAT AC SERVO DRIVE DDS02.1-A150-DA02-01-FW INDRAMAT AC SERVO DRIVE DDS02.1-W100-DS01-02-FW INDRAMAT AMPLIFIER DDS02.1-W150-DS24-04-FW INDRAMAT AC SERVO DRIVE DDS02.2-A100-BE45-01-FW INDRAMAT AC SERVO DRIVE DDS02.2-W200-B INDRAMAT AC SERVO DRIVE DDS03.1-W030-R INDRAMAT AC SERVO DRIVE DDS03.1-W050-D INDRAMAT AC SERVO DRIVE

HCS02.1E-W0012-A-03-NNNN

R911298374,HCS02.1E-W0028-A-03-NNNN

R911298373 HCS02.1E-W0054-A-03-NNNN

R911299522,HCS02.1E-W0054-A-03-NNNV R911308416,HCS03.1E-W0070-A-05-NNNV  
R911308421,HCS03.1E-W0150-A-05-NNBV

R911326648,HCS03.1E-W0070-A-05-NPBV R911326649,HCS03.1E-W0100-A-05-NPBV

HDS02.2-W040N-HS12-01 INDRAMAT AC SERVO DRIVE HDS03.2-W075N-HS45-0 INDRAMAT AC SERVO DRIVE HDS03.2-W100N-HS45-01 INDRAMAT AC SERVO DRIVE HDS3.2-W100N-HS12 INDRAMAT AC SERVO DRIVE

HMS01.1N-W0020-A-07-NNNN、 HMS01.1N-W0036-A-07-NNNN HMS01.1N-W0054-A-07-NNNN、 HMS01.1N-W0070-A-07-NNNN HMS01.1N-W0110-A-07-NNNN、 HMS01.1N-W0150-A-07-NNNN HMD01.1N-W0012-A-07-NNNN、 HMD01.1N-W0020-A-07-NNNN、 REXROTH INDRAMAT KDA3.2-050-3-APO-V1 SERVO DRIVE REXROTH INDRAMAT KDA3.2-050-3-DPO-W1 SERVO DRIVE

REXROTH INDRAMAT KDA3.2-100-3-AOO-U1 SERVO DRIVE

REXROTH INDRAMAT KDA3.2-100-3-DPD-W1 SERVO DRIVE

REXROTH INDRAMAT KDA3.3-150-3-A01-W1 SERVO DRIVE

## 主轴驱动器

RAC2.1-150-380-A00-W1 INDRAMAT SPINDLE DRIVE RAC2.3-200-460-LPO-W1 INDRAMAT SPINDLE DRIVE RAC2.3-250-460-A01-W1 INDRAMAT SPINDLE DRIVE RAC3.5-150-460-A01-Z1-22 INDRAMAT SPINDLE DRIVE RAC3.5-200-460-A00-Z1-220 INDRAMAT SPINDLE DRIVE RAC3.5-200-460-L00-Z1-220 INDRAMAT SPINDLE DRIVE

CSB01.1N-AN-ENS-NNN-NN-S-NN-FW CSB01.1N-PB-ENS-NNN-NN-S-NN-FW CSB01.1N-SE-ENS-NNN-NN-S-NN-FW CSB01.1C-PB-ENS-NNN-NN-S-NN-FW

CDB01.1C-SE-ENS-ENS-NNN-NNN-NN-S-NN-FW CDB01.1C-SE-ENS-ENS-EN2-EN2-NN-S-NN-FW CDB01.1C-PB-NNN-NNN-NNN-NNN-NN-S-NN-FW CDB01.1C-PB-ENS-ENS-NNN-NNN-NN-S-NN-FW CSH01.1C-SE-ENS-EN2-NNN-NN-S-NN-FW

CSH01.1C-PB-ENS-EN2-NNN-NN-S-NN-FW

CSH01.1C-PL-ENS-NNN-MD1-NN-S-NN-FW

FWA-INDRV\*-MPH-03VRS-D5-1-SNC-NN FWA-INDRV\*-MPH-03VRS-D5-1-SNC-ML FWA-INDRV\*-MPD-03VRS-D5-1-NNN-NN FWA-INDRV\*-MPD-03VRS-D5-1-SNC-NN FWA-INDRV\*-MPB-03VRS-D5-1-NNN-NN

FWA-INDRV\*-MPB-03VRS-D5-1-SNC-NN

## 电机

MSK040C-0600-NN-S1-UP1-NNNN MSK070C-0150-NN-M1-UG0-NNNN MSK071E-0300-NN-M1-UG1-NNNN

MSK050B-0300-NN-M1-UG1-NNNN

MSK100B-0300-NN-M1-AG1-NNNN MSK070C-0300-NN-M1-UG0-NNNN

MAD130C-0200-SA-M2-FG0-05-N1 MAD100C-0200-SA-S2-FG0-35-N1 MAD130D-0200-SA-M2-FG0-05-N1

MAD100B-0100-SA-M2-AP0-05-N1

MAD130B-0200-SA-M2-FG0-05-N1

MAD100D-0200-SA-M2-FG0-05-N1

MKD041B-144-GG0-KN INDRAMAT AC SERVO MOTOR MKD-071B-035-GP1-KN INDRAMAT AC SERVO MOTOR MKD071B-061-GP-I-KN INDRAMAT AC SERVO MOTOR MKD090B-035-GP0-KN INDRAMAT AC SERVO MOTOR MKD090B-047-GP1-KN INDRAMAT AC SERVO MOTOR MKD112B-048-KGO-AN INDRAMAT AC SERVO MOTOR MDD071C-N-030-N2T-095PB1 INDRAMAT AC SERVO MOTOR MDD090C-N-030-N2L-110PAO INDRAMAT AC SERVO MOTOR MDD093A-N-040-N2L-110GA0 INDRAMAT AC SERVO MOTOR MDD093B-N-30-N2L-110PB2 INDRAMAT AC SERVO MOTOR MDD112B-

N-040-N2L-130PBO INDRAMAT AC SERVO MOTOR MDD112C-N-020-N2M-180GB2 INDRAMAT AC SERVO MOTOR MDD112D-L-015-N2L-130PBO INDRAMAT AC SERVO MOTOR MHD041B-144-PG1-UN INDRAMAT AC SERVO MOTOR MHD071-B-061-P-G1-UN INDRAMAT AC SERVO MOTOR MHD-090B-035-NG0-UN INDRAMAT AC SERVO MOTOR MHD093C-035 NTO BN INDRAMAT AC SERVO MOTOR MHD093C-058-NP0-BN INDRAMAT AC SERVO MOTOR MHD112B-024-PP1-AN INDRAMAT AC SERVO MOTOR MHD115C-024-NG0-RN INDRAMAT AC SERVO MOTOR MKE096B-047-KP1-KN INDRAMAT AC SERVO MOTOR

MAC063C-0-MS-4-C/095-B-0/WI512LV INDRAMAT AC SERVO MOTOR  
MAC063D-0-FS-1-C/095-B-1/-IO1000/S7 INDRAMAT AC SERVO MOTOR

MAC071A-O-ES-4-C/095-B-O/WI522LV/S0 INDRAMAT AC SERVO MOTOR  
MAC071B-0-TS-4-C/095-B-0/WI522LV/S1 INDRAMAT AC SERVO MOTOR  
MAC090B-0-JD-4-C/110-A-2/WI520LX/18 INDRAMAT AC SERVO MOTOR  
MAC093C-2-KS-4-C/110-A-0/WI519LV/S1 INDRAMAT AC SERVO MOTOR  
MAC112C-0-ED-1B/130-A-1/I1250/S005 INDRAMAT AC SERVO MOTOR

MAC090B-0-PD-3-C/110-A-0 INDRAMAT AC SERVO MOTOR MAC090B-0-PD-3-C/110-A-0//  
INDRAMAT AC SERVO MOTOR MAC090B-0-PD-3-C/110-B-0/S01 INDRAMAT AC SERVO  
MOTOR MAC-090B-0-PD-4-C/110-A-0/W155 INDRAMAT AC SERVO MOTOR  
MAC090B-0-PD-4-C/110-A-0/WI518LV/S1 INDRAMAT AC SERVO MOTOR  
MAC090-B-0-PD-4-C/110-A-0/WI520LV INDRAMAT AC SERVO MOTOR  
MAC090B-0-PD-4-C/130-A-0/WI520LVS11 INDRAMAT AC SERVO MOTOR

2AD100C-B050B1-AS01-B2N1 INDRAMAT SPINDLE MOTOR 2AD-100D-B050B1-AS01-B2N1 INDRAMAT  
SPINDLE MOTOR 2AD104D-B350B4-FS06-D2N1 INDRAMAT SPINDLE MOTOR 2AD-132C-  
B35-0-A1-BS-03/D2N1 INDRAMAT SPINDLE MOTOR 2AD132D-B050A1-BD0/3/S002 INDRAMAT SPINDLE  
MOTOR 2AD134B-B050A1-ES06-B2N1 INDRAMAT SPINDLE MOTOR

## 电源模块

TVD1.2-08-03 INDRAMAT POWER SUPPLY TVD1.3-15-03 INDRAMAT POWER SUPPLY TVM  
2.4-050-220/300-W1/115/220 INDRAMAT POWER?SUPPLY TVM1.2-05-220/300-W0 INDRAMAT POWER  
SUPPLY TVM1.2-50-220/300-W1 INDRAMAT POWER SUPPLY TVM2.1-50-220/300-W1-115/220  
INDRAMAT POWER?SUPPLY TVM2.2-050-220/300-W1/115/220 INDRAMAT POWER?SUPPLY  
TVM2.4-50-200/300-W1/115 INDRAMAT POWER SUPPLY

HMV01.1E-W0030-A-07-NNNN、HMV01.1E-W0075-A-07-NNNN、HMV01.1R-  
W0018-A-07-NNNN、HMV01.1R-W0045-A-07-NNNN、HMV01.1R-W0065-A-07-NNNN、HMV01.1R-  
W0120-A-07-NNNN。

## 控制模块

REXROTH INDRAMAT CLM-01.2 CONTROL MODULE REXROTH INDRAMAT CLM01.2-A CONTROL  
MODULE 2 AXIS MOK II REXROTH INDRAMAT CLM01.2-A-E 2 AXIS CONTROLLER REXROTH  
INDRAMAT CLM01.3-X-0-2-0 CONTROLLER REXROTH INDRAMAT CLM01.3-X-0-2-0-FW SERVO  
CONTROLLER

REXROTH INDRAMAT CLM01.4-N-E-2-B-FW,FWA-CLM1.4-LA1-01VRS-MS

CSB01.1C-SE-ENS-NNN-NN-S-NN-FW

FWA-INDRV\*-MPB-04VRS-D5-1-NNN-NN

CSB01.1C-PB-ENS-NNN-NN-S-NN-FW

FWA-INDRV\*-MPB-04VRS-D5-1-NNN-NN

电缆

R911305799 RKL4302/000,0 (RLS1101-INK0653-RLS0722) R911305801 RKL4308/000,0  
(RLS1201-INK0602-RLS0722) R911305802 RKL4307/000,0 (RLS1201-INK0650-RLS0721) R911305803  
RKL4306/000,0 (RLS1201-INK0650-RLS0722) R911305908 IKG4215/000,0 (INS0481-INK0604-RLS0723)