

BENTLY胀差传感器19047-02

产品名称	BENTLY胀差传感器19047-02
公司名称	南京六田电气有限公司
价格	1000.00/个
规格参数	品牌:BENTLY 型号:19047-02
公司地址	南京市兴苑路108号
联系电话	025-66021611 15295796971

产品详情

胀差/轴向位置模块3500/45-01-00

胀差/轴向位置模块3500/45-01-00

转速模块3500/50-01-00

转速模块3500/50-01-00-01

转速模块3500/50-01-00-01

转速模块3500/50-01-00-02

转速模块3500/50-01-01-00-00

转速模块3500/50-04-00

超速保护模块3500/53-01-00

温度监测器3500/61 (133819-02)

温度监测器3500/61 (163179-02)

温度监测器3500/61 (163179-03)

温度监测器3500/61-01-00 (163179-02&133819-02)

温度监测器3500/61-03-00

温度监测器3500/61-03-00

过程变量监测模块3500/62 (136294-01)

过程变量监测模块3500/62-03-00 (163179-03&136294-01)

监测模块3500/63-01-00

通讯网关模块3500/92-01-01

通讯网关模块3500/92-01-01-00

通讯网关模块3500/92-02-01-00

通讯网关模块3500/92-04-01-00

显示装置3500/93-01-00-00-00

显示装置3500/93-01-00-00-00

显示装置3500/93-02-02-02-00

显示装置3500/93-03-01-00

显示装置3500/93-03-01-00-00

显示装置3500/93-03-01-00-00

显示装置3500/93-07-01-02-00

监测模块3500-40-01-00

3500/53-03-01

3500/60-01-00

3500/61-01-00

3500/65-01-00

3500/92-01-00-00-00

3500/92-01-01-00

3500/92-02-01-00

3500/92-04-01-00

3500/92-04-01-01

3500/93-03-01-00-00

3500-01-01

37506-A-05-01

40113-02

41559-02

46000-01

72341-03-05

72341-10-05

72342-03-08

72342-03-09

72342-10-04

72342-10-05

72381-03-02-02

72381-10-02-02

72382-10-03-04

73242-11-09

7330854-040-24-05

74712-06-05-03-00

80917-01 82608-01

84152-01 84661-10

84661-20

84661-33

89410-01

9200-01-01-10-00

9200-01-05-01-00

9200-01-05-05-00

9200-01-05-10-00

9200-01-06-10-00

9200-01-08-11-02

9200-01-24-10-00

9200-03-24-10-00

9200-06-01-05-00

9200-06-01-10-00

9200-06-02-10-00

9200-06-05-05-00

9200-06-05-10-00

9200-06-06-02-00

9200-06-50-08-02

9571-45 (10米)

990-04-05-02-00

990-04-50-01-00

990-04-70-01-00

990-05-50-01-00

990-05-70-01-00

990-05-70-02-00

990-10-50-01-05

991-06-05-02-00

991-25-50-01-00

72790-03-03-13-13-00-01-04-0001

3500/92-04-01-00

330880-28-00-065-03-02

1701 FieldMonitor? 系列

探头传感器,330173-00-04-10-02-00,

探头传感器,330604-00-13-10-02-00,
探头传感器,330500-02-00,
探头传感器,330525-00,
探头传感器,330195-02-12-10-00,
探头传感器,330851-04-000-023-50-01-05,
探头传感器,330903-12-25-10-02-00,
探头传感器,330905-00-15-10-02-00,
探头传感器,9200-01-05-10-00,
探头传感器,21000-16-05-15-085-03-02,
探头传感器,21504-00-12-05-02,
探头传感器,21505-22-55-10-02,
探头传感器,31000-16-10-15-163-01-02,
探头传感器,26530-12-10-00-000-074-21-00-00,
延伸电缆,330130-040-00-00,
延伸电缆,330130-045-00-00,
延伸电缆,330130-040-01-00,
延伸电缆,330130-080-00-00,
延伸电缆,330130-080-01-00,
延伸电缆,330730-040-01-00,
监测模块,3500/53-03-00
监测模块,3500/92-01-01-00,
监测模块,3500/50-01-00-01,
监测模块,3500/22-01-01-00,
框架,3500/05-01-01-00-00-00,
框架,3300/05-25-00-00,延伸电缆,330730-080-00-00,
延伸电缆,330930-040-01-00,

监测模块,3300/03-01-00,

监测模块,3300/03-02-02,

监测模块,3300/12-02-20-00,

监测模块,3300/12-22-02,

监测模块,3300/16-12-01-01-00-00-00,

监测模块,3300/20-12-01-01-00-00,

监测模块,3500/15-02-02-00

监测模块,3500/20-01-02-00

监测模块,3500/25-01-01-00,

监测模块,3300/55-04-04-18-18-00-00-05-00,

监测模块,3300/50-01-01-00-00,

监测模块,3500/32-01-00,

监测模块,3500/33-01-00,

监测模块,3500/40-01-00,

监测模块,3500/42-01-00,

监测模块,3500/42-04-00

监测模块,3500/45-02-00

过程变量监测模块3500/62 (136294-01)

过程变量监测模块3500/62-03-00 (163179-03&136294-01)

过程变量监测模块3500/62 (136294-01)

过程变量监测模块3500/62-03-00 (163179-03&136294-01)

过程变量监测模块3500/62 (136294-01)

过程变量监测模块3500/62-03-00 (163179-03&136294-01)

本特利330系列探头传感器

探头传感器,330101-00-08-05-02-00,

探头传感器,330101-00-08-05-02-05,

探头传感器,330103-00-03-10-02-00,

探头传感器,330103-00-06-05-02-00,

探头传感器,330104-00-04-05-02-00,

探头传感器,330104-00-09-05-02-00,

探头传感器,330104-00-18-10-02-00,

探头传感器,330104-12-22-10-02-00,

探头传感器,330105-02-12-05-02-00,

探头传感器,330105-02-12-10-02-00,

探头传感器,330106-05-30-10-02-00,

探头传感器,330703-000-060-10-02-00,

探头传感器,330704-000-050-10-02-05,

探头传感器,330708-20-50-10-02-00,

探头传感器,330173-00-04-10-02-00,

探头传感器,330604-00-13-10-02-00,

探头传感器,330500-02-00,