

# Bussmann保险丝A30220407

产品名称	Bussmann保险丝A30220407
公司名称	深圳市创唯电子有限公司
价格	1.00/件
规格参数	描述:CONN BARRIER STRIP 4CIRC 0.437" 扩展描述:4 电路 0.437" ( 11.10mm ) 阻隔块 连接器, 螺钉, 带紧固板 湿气敏感性等级:湿气敏感性等级 ( MSL )
公司地址	深圳市宝安区西乡街道流塘路河东大厦B栋八层020号
联系电话	86-0755-27582171 13006692189

## 产品详情

Bussmann保险丝A30220407

产品概览

仓库零件编号A30220407-ND

制造商[Eaton](#)

制造商零件编号A30220407

[查询库存及价格](#)

描述CONN BARRIER STRIP 4CIRC 0.437"

扩展描述4 电路 0.437" ( 11.10mm ) 阻隔块 连接器, 螺钉, 带紧固板

对无铅要求的达标情况 /

对限制有害物质指令(RoHS)规范的达标情况含铅 / 不符合限制有害物质指令(RoHS)规范要求

湿气敏感性等级 ( MSL ) 1 ( 无限 )

Bussmann保险丝更多型号

A20820504 Cooper Bussmann

A20821004 Cooper Bussmann

A20822004 Cooper Bussmann

A219302 Cooper Bussmann

A219304 Cooper Bussmann

A219912 Cooper Bussmann

A301103 Cooper Bussmann

A301320 Cooper Bussmann

A302102 Cooper Bussmann

A30210307 Cooper Bussmann

A302106 Cooper Bussmann

A302203 Cooper Bussmann

A30220407 Cooper Bussmann

A302205L1 Cooper Bussmann

A30310407MT Cooper Bussmann

A304103 Cooper Bussmann

A30410707R46 Cooper Bussmann

A304210R46 Cooper Bussmann

A305303 Cooper Bussmann

A305304 Cooper Bussmann

A31030207 Cooper Bussmann

A319303 Cooper Bussmann

A31930307 Cooper Bussmann

A31930407 Cooper Bussmann

A31930607 Cooper Bussmann

A319314 Cooper Bussmann

A38740804 Cooper Bussmann

A400303 Cooper Bussmann

A40111600 Cooper Bussmann

A48130304 Cooper Bussmann

A48130804 Cooper Bussmann

A48131204 Cooper Bussmann

A484305 Cooper Bussmann

A495302CW Cooper Bussmann

AAO25 COOPER BUSSMANN

AAO32M50 Cooper Bussmann

ABC-1/2 Cooper Bussmann

ABC-1/4 Cooper Bussmann

ABC-1/4-R Cooper Bussmann

ABC-1/8-R Cooper Bussmann

ABC-10 Cooper Bussmann

ABC-10-R Cooper Bussmann

ABC-1-1/2 Cooper Bussmann

ABC-1-1/2-R Cooper Bussmann

ABC-1-1/4 Cooper Bussmann

ABC-12 Cooper Bussmann

ABC-12-R Cooper Bussmann

ABC-13-R Cooper Bussmann

ABC-15 Cooper Bussmann

ABC-15-R Cooper Bussmann

ABC-1-R Cooper Bussmann

ABC-20 Cooper Bussmann

ABC-20-R Cooper Bussmann

ABC-2-1/2 Cooper Bussmann

ABC-2-1/2-R Cooper Bussmann

ABC-25 Cooper Bussmann

ABC-25-R Cooper Bussmann

ABC-2-R COOPER BUSSMANN

ABC-3/4 Cooper Bussmann

ABC-3/4-R Cooper Bussmann

ABC-3/8 Cooper Bussmann

ABC-30 Cooper Bussmann

ABC-3-R Cooper Bussmann

ABC-4-R Cooper Bussmann

ABC-5-R COOPER BUSSMANN

ABC-6-R Cooper Bussmann

ABC-8-R Cooper Bussmann

ABC-V-1 Cooper Bussmann

ABC-V-1/4 Cooper Bussmann

ABC-V-10 Cooper Bussmann

ABC-V-10-R Cooper Bussmann

ABC-V-1-1/2 Cooper Bussmann

ABC-V-13 Cooper Bussmann

ABC-V-15 Cooper Bussmann

ABC-V-15-R Cooper Bussmann

ABC-V-20-R Cooper Bussmann

ABC-V-2-1/2 Cooper Bussmann

ABC-V-3 Cooper Bussmann

ABC-V-3/4 Cooper Bussmann

ABC-V-30 Cooper Bussmann

ABC-V-3-R Cooper Bussmann

ABC-V-4 Cooper Bussmann  
ABC-V-5 Cooper Bussmann  
ABC-V-6-R Cooper Bussmann  
ABC-V-7 Cooper Bussmann  
ABC-V-8 Cooper Bussmann  
ABS-10 Cooper Bussmann  
ACH-10 Cooper Bussmann  
ACK-150 Cooper Bussmann  
ACK-225 Cooper Bussmann  
ACK-250 Cooper Bussmann  
ACK-400 Cooper Bussmann  
AGA-1/10 Cooper Bussmann  
AGA-1/16 Cooper Bussmann  
AGA-1/2 Cooper Bussmann  
AGA-1/4 Cooper Bussmann  
AGA-10 COOPER BUSSMANN  
AGA-1-1/2 Cooper Bussmann  
AGA-15 Cooper Bussmann  
AGA-20 Cooper Bussmann  
AGA-2-1/2 Cooper Bussmann  
AGA-25 Cooper Bussmann  
AGA-3/4 Cooper Bussmann  
AGA-3/8 Cooper Bussmann  
AGA-30 Cooper Bussmann  
AGA-7-1/2 Cooper Bussmann  
AGA-V-1 Cooper Bussmann

AGA-V-1/8 Cooper Bussmann

AGA-V-10 Cooper Bussmann

AGA-V-15 Cooper Bussmann

AGA-V-2 Cooper Bussmann

AGA-V-3 Cooper Bussmann

AGA-V-5 Cooper Bussmann

AGA-V-6 Cooper Bussmann

AGA-V-7 Cooper Bussmann

AGC-1/10 Cooper Bussmann

AGC-1/10-R Cooper Bussmann

AGC-1/16 Cooper Bussmann

AGC-1/20 Cooper Bussmann

AGC-1/200 Cooper Bussmann

AGC-1/2-R COOPER BUSSMANN

AGC-1/32 Cooper Bussmann

AGC-1/4 Cooper Bussmann

AGC-1/8 Cooper Bussmann

AGC-1/8-R Cooper Bussmann

AGC-10 Cooper Bussmann

AGC-10A COOPER BUSSMANN

AGC-1-1/2 Cooper Bussmann

AGC-1-1/2-R Cooper Bussmann

AGC-1-1/4 Cooper Bussmann

AGC-1-1-2-R Cooper Bussmann

AGC-12 Cooper Bussmann

AGC-1-3/4 Cooper Bussmann

AGC-1-3/4-R Cooper Bussmann

AGC-15/100 Cooper Bussmann

AGC-15/100-R Cooper Bussmann

AGC-15-R Cooper Bussmann

AGC-1-6/10 Cooper Bussmann

AGC-1-6/10-R Cooper Bussmann

AGC-175/1000 Cooper Bussmann

AGC-175/1000-R Cooper Bussmann

AGC-1-8/10 Cooper Bussmann

AGC-1-8/10-R Cooper Bussmann

AGC-1-R Cooper Bussmann

AGC-2/10 Cooper Bussmann

AGC-2/10-R Cooper Bussmann

AGC-20-R Cooper Bussmann

AGC-2-1/2 COOPER BUSSMANN

AGC-2-1/2-R Cooper Bussmann

AGC-2-1/4 Cooper Bussmann

AGC-2-1/4-R Cooper Bussmann

AGC-25 Cooper Bussmann

AGC-25-R Cooper Bussmann

AGC-2-R Cooper Bussmann

AGC-3/10 Cooper Bussmann

AGC-3/10-R Cooper Bussmann

AGC-3/16 Cooper Bussmann

AGC-3/16-R Cooper Bussmann

AGC-3/4 Cooper Bussmann

AGC-3/4-R Cooper Bussmann

AGC-3/8 Cooper Bussmann

AGC-3/8-R Cooper Bussmann

AGC-30-R Cooper Bussmann

AGC-3-1/2 Cooper Bussmann

AGC-3-1/2-R Cooper Bussmann

AGC-3-10-R Cooper Bussmann

AGC-3-2/10 Cooper Bussmann

AGC-3-2/10-R Cooper Bussmann

AGC-35 Cooper Bussmann

AGC-3A COOPER BUSSMANN

AGC-3-R Cooper Bussmann

AGC-4/10 Cooper Bussmann

AGC-4/10-R Cooper Bussmann

AGC-40 Cooper Bussmann

AGC-40-R Cooper Bussmann

AGC-4-R Cooper Bussmann

AGC-5A COOPER BUSSMANN

AGC-5-R COOPER BUSSMANN

AGC-6/10 Cooper Bussmann

AGC-6-1/4 Cooper Bussmann

AGC-6-1/4-R Cooper Bussmann

AGC-6-R COOPER BUSSMANN

AGC-7-1/2 Cooper Bussmann

AGC-7-1/2-R Cooper Bussmann

AGC-8/10 Cooper Bussmann



AGC-8/10-R Cooper Bussmann

AGC-8-R COOPER BUSSMANN

AGC-9-R Cooper Bussmann

AGC-V-1/100 Cooper Bussmann

AGC-V-1/16 Cooper Bussmann

AGC-V-1/2 Cooper Bussmann

AGC-V-1/20 Cooper Bussmann

AGC-V-1/32 Cooper Bussmann

AGC-V-1/4 Cooper Bussmann

AGC-V-1/8 Cooper Bussmann

AGC-V-10 COOPER BUSSMANN

AGC-V-1-1/2 Cooper Bussmann

AGC-V-1-1/2-R Cooper Bussmann

AGC-V-1-1/4 Cooper Bussmann

AGC-V-15 Cooper Bussmann

AGC-V-1-6/10 Cooper Bussmann

AGC-V-1-8/10 Cooper Bussmann

AGC-V-2 Cooper Bussmann

AGC-V-2/10 Cooper Bussmann

AGC-V-20 Cooper Bussmann

AGC-V-2-1/2 Cooper Bussmann

AGC-V-2-1/4 Cooper Bussmann

AGC-V-25 Cooper Bussmann

AGC-V-3 Cooper Bussmann

AGC-V-3/10 Cooper Bussmann

AGC-V-3/16 Cooper Bussmann

AGC-V-3/4 Cooper Bussmann

AGC-V-3/8 Cooper Bussmann

AGC-V-3-1/2 Cooper Bussmann

AGC-V-3-2/10 Cooper Bussmann

AGC-V-4/10 Cooper Bussmann

AGC-V-5 Cooper Bussmann

AGC-V-6 Cooper Bussmann

AGC-V-6/10 Cooper Bussmann

AGC-V-6-1/4 Cooper Bussmann

AGC-V-7 Cooper Bussmann

AGC-V-7-1/2 Cooper Bussmann

AGC-V-8 Cooper Bussmann

AGC-V-8/10 Cooper Bussmann

AGC-V-9 Cooper Bussmann

AGU-10 Cooper Bussmann

AGU-15 Cooper Bussmann

AGU-20 Cooper Bussmann

AGU-25 Cooper Bussmann

AGU-30 Cooper Bussmann

AGU-35 Cooper Bussmann

AGU-40 COOPER BUSSMANN

AGU-50 Cooper Bussmann

AGU-60 Cooper Bussmann

AGW-10 Cooper Bussmann

AGW-1-1/2 Cooper Bussmann

AGW-15 Cooper Bussmann

AGW-20 Cooper Bussmann

AGW-2-1/2 Cooper Bussmann

AGW-25 Cooper Bussmann

AGW-30 Cooper Bussmann

AGW-7-1/2 Cooper Bussmann

AGX-1 1/2 COOPER BUSSMANN

AGX-1/100 Cooper Bussmann

AGX-1/2 Cooper Bussmann

AGX-1/200 Cooper Bussmann

AGX-1/4 Cooper Bussmann

AGX-1/8 Cooper Bussmann

AGX-10 Cooper Bussmann

AGX-1-1/2 Cooper Bussmann

AGX-1-1/4 COOPER BUSSMANN

AGX-15 Cooper Bussmann

AGX-2/10 Cooper Bussmann

AGX-25 Cooper Bussmann

AGX-2A COOPER BUSSMANN

AGX-3/4 Cooper Bussmann

AGX-3/8 Cooper Bussmann

AGX-30 Cooper Bussmann

AGX-4/10 Cooper Bussmann

AGX-50 Cooper Bussmann

AMG-150 Cooper Bussmann

AMG-250 Cooper Bussmann

ANL-100 Cooper Bussmann

ANL-150 Cooper Bussmann

ANL-175 Cooper Bussmann

ANL-200 Cooper Bussmann

ANL-225 Cooper Bussmann

ANL-250 Cooper Bussmann

ANL-275 Cooper Bussmann

ANL-300 Cooper Bussmann

ANL-35 Cooper Bussmann

ANL-400 Cooper Bussmann

ANL-500 Cooper Bussmann

ANL-60 Cooper Bussmann

ANL-600 Cooper Bussmann

ANL-675 Cooper Bussmann

ANL-80 Cooper Bussmann

ANN-125 Cooper Bussmann

ANN-250 Cooper Bussmann

ANN-35 Cooper Bussmann

ANN-400 Cooper Bussmann

ANN-50 Cooper Bussmann

ANN-60 Cooper Bussmann

ANN-700 Cooper Bussmann

ANN-80 Cooper Bussmann

ATC-15 COOPER BUSSMANN

ATC-30 COOPER BUSSMANN

ATC-35 Cooper Bussmann

ATC-7-1/2 Cooper Bussmann

ATM-10 Cooper Bussmann

ATM-15 Cooper Bussmann

ATM-25 Cooper Bussmann

ATM-7-1/2 Cooper Bussmann

B0810-2R5105-R COOPER BUSSMANN

B0820-2R5225-R Cooper Bussmann

B1010-2R5155-R COOPER BUSSMANN

B1020-2R5335-R Cooper Bussmann

B384904 Cooper Bussmann

B484302 Cooper Bussmann

B48430600 Cooper Bussmann

B484308 Cooper Bussmann

BA040A Cooper Bussmann

BA050A Cooper Bussmann

BA063A Cooper Bussmann

BA063M80A Cooper Bussmann

BAF-1/2 Cooper Bussmann

BAF-10 Cooper Bussmann

BAF-1-1/2 Cooper Bussmann

BAF-15 Cooper Bussmann

BAF20 Cooper Bussmann

BAF-20 Cooper Bussmann

BAF-2-1/2 Cooper Bussmann

BAF-25 Cooper Bussmann

BAF-30 Cooper Bussmann

BAF-6-1/4 Cooper Bussmann

BAN-10 Cooper Bussmann

BAN-12 Cooper Bussmann

BAN-15 Cooper Bussmann

BAN-20 Cooper Bussmann

BAN-25 Cooper Bussmann

BAN-30 Cooper Bussmann

BAO63RS COOPER BUSSMANN

BBS-1/2 COOPER BUSSMANN

BBS-1-1/2 Cooper Bussmann

BBS-15 Cooper Bussmann

BBS-1-6/10 Cooper Bussmann

BBS-2/10 Cooper Bussmann

BBS-20 Cooper Bussmann

BBS-30 Cooper Bussmann

BBS-6/10 Cooper Bussmann

BC6031B Cooper Bussmann

BC6031P Cooper Bussmann

BC6031S Cooper Bussmann

BC6032B Cooper Bussmann

BC6032PQ Cooper Bussmann

BC6032S COOPER BUSSMANN

BC6033B Cooper Bussmann

BC6033SQ Cooper Bussmann

BG3031S Cooper Bussmann

BH-0111 Cooper Bussmann

BH-0122 Cooper Bussmann

BK/15087 Cooper Bussmann

BK/1A1119-01 Cooper Bussmann

BK/1A1119-03-R Cooper Bussmann

BK/1A1119-05 Cooper Bussmann

BK/1A1119-09-R Cooper Bussmann

BK/1A1119-10-R Cooper Bussmann

BK/1A1120-02 Cooper Bussmann

BK/1A1120-05 Cooper Bussmann

BK/1A1120-06-R COOPER BUSSMANN

BK/1A1120-09 Cooper Bussmann

BK/1A1120-09-R Cooper Bussmann

BK/1A1120-10-R Cooper Bussmann

BK/1A1907-02-R Cooper Bussmann

BK/1A1907-03-R Cooper Bussmann

BK/1A1907-06 Cooper Bussmann

BK/1A1907-06-R Cooper Bussmann

BK/1A2294 Cooper Bussmann

BK/1A3322 Cooper Bussmann

BK/1A3399-01 Cooper Bussmann

BK/1A3399-04 Cooper Bussmann

BK/1A3399-04-R Cooper Bussmann

BK/1A3399-10 Cooper Bussmann

BK/1A3399-12 Cooper Bussmann

BK/1A3399-12-R Cooper Bussmann

BK/1A3400-09 Cooper Bussmann

BK/1A3400-09-R Cooper Bussmann

BK/1A3400-10 Cooper Bussmann  
BK/1A3400-11 Cooper Bussmann  
BK/1A4533-01 Cooper Bussmann  
BK/1A4533-01-R Cooper Bussmann  
BK/1A4533-06 Cooper Bussmann  
BK/1A4534-01 Cooper Bussmann  
BK/1A4534-01-R Cooper Bussmann  
BK/1A4534-06 Cooper Bussmann  
BK/1A5018-07 Cooper Bussmann  
BK/1A5018-10 Cooper Bussmann  
BK/1A5601 Cooper Bussmann  
BK/1A5602 Cooper Bussmann  
BK/5674-41 Cooper Bussmann  
BK/5674-41-R Cooper Bussmann  
BK/5681-15 COOPER BUSSMANN  
BK/5681-15-R Cooper Bussmann  
BK/5682-02 Cooper Bussmann  
BK/5682-41 Cooper Bussmann  
BK/5682-41-R Cooper Bussmann  
BK/5682-44 Cooper Bussmann  
BK/5956-16-R Cooper Bussmann  
BK/5956-20 Cooper Bussmann  
BK/70B-2A Cooper Bussmann  
BK/70C-3A Cooper Bussmann  
BK/70N-10A Cooper Bussmann  
BK/A-104 Cooper Bussmann



BK/ABC-1 Cooper Bussmann

BK/ABC-1/2 Cooper Bussmann

BK/ABC-1/2-R Cooper Bussmann

BK/ABC-1/4 Cooper Bussmann

BK/ABC-1/4-R Cooper Bussmann

BK/ABC-10 Cooper Bussmann

BK/ABC-10-R Cooper Bussmann