

西门子6SL3130-7TE31不启动专业维修

产品名称	西门子6SL3130-7TE31不启动专业维修
公司名称	上海龙锡机电设备中心
价格	900.00/台
规格参数	西门子维修:6SL3130-7TE3 专业维修:不启动 西门子产地:德国
公司地址	上海市松江区强业路951弄B205
联系电话	13621872316 13621872316

产品详情

6SL3130-7TE31-2AA3维修上海专业公司

名称型号简要描述S120电源模块6SL3130-7TE31-2AA0SINAMICS 120kw 电源模块S120电源模块6SL3130-7TE31-2AA1SINAMICS 120kw 电源模块S120电源模块6SL3130-7TE31-2AA3SINAMICS 120kw 电源模块S120电源模块6SL3130-7TE31-2AB0SINAMICS 120kw 电源模块S120电源模块6SL3130-1TE31-0AA0SINAMICS 100kw 电源模块S120电源模块6SL3130-7TE28-0AA0SINAMICS 80kw 电源模块S120电源模块6SL3130-7TE28-0AA1SINAMICS 80kw 电源模块S120电源模块6SL3130-7TE28-0AA3SINAMICS 80kw 电源模块S120电源模块6SL3130-7TE28-0AB0SINAMICS 80kw 电源模块S120电源模块6SL3130-7TE25-5AA0SINAMICS 55kw 电源模块S120电源模块6SL3130-7TE25-5AA1SINAMICS 55kw 电源模块S120电源模块6SL3130-7TE25-5AA3SINAMICS 55kw 电源模块S120电源模块6SL3130-7TE25-5AB0SINAMICS 55kw 电源模块S120电源模块6SL3130-1TE22-0AA0SINAMICS 40kw 电源模块S120电源模块6SL3130-6TE23-6AA3SINAMICS 36kw 电源模块S120电源模块6SL3130-6TE23-6AB0SINAMICS 36kw 电源模块S120电源模块6SL3130-7TE23-6AA0SINAMICS 36kw 电源模块S120电源模块6SL3130-7TE23-6AA1SINAMICS 36kw 电源模块S120电源模块6SL3130-7TE23-6AA3SINAMICS 36kw 电源模块S120电源模块6SL3130-7TE23-6AB0SINAMICS 36kw 电源模块 6SL3130-7TE31-2AA3维修上海专业公司S120电源模块6SL3130-1TE22-0AA0SINAMICS 20kw 电源模块S120电源模块6SL3130-6TE21-6AA3SINAMICS 16kw 电源模块S120电源模块6SL3130-6TE21-6AB0SINAMICS 16kw 电源模块S120电源模块6SL3130-7TE21-6AA0SINAMICS 16kw 电源模块S120电源模块6SL3130-7TE21-6AA1SINAMICS 16kw 电源模块S120电源模块6SL3130-7TE21-6AA3SINAMICS 16kw 电源模块S120电源模块6SL3130-7TE21-6AB0SINAMICS 16kw 电源模块S120电源模块6SL3130-6AE21-0AB0SINAMICS 10kw 电源模块S120电源模块6SL3130-6AE21-0AB1SINAMICS 10kw 电源模块S120电源模块6SL3130-6AE15-0AB0SINAMICS 5kw 电源模块S120电源模块6SL3130-6AE15-0AB1SINAMICS 5kw 电源模块 6SL3130-7TE31-2AA3维修上海专业公司S120驱动模块6SL3120-1TE32-0AA0SINAMICS 单轴200A驱动模块S120驱动模块6SL3120-1TE32-0AA3SINAMICS 单轴200A驱动模块S120驱动模块6SL3120-1TE32-0AA4SINAMICS 单轴200A驱动模块S120驱动模块6SL3120-1TE32-0AB0SINAMICS 单轴200A驱动模块S120驱动模块6SL3120-1TE31-3AA0SINAMICS 单轴132A驱动模块S120驱动模块6SL3120-1TE31-3AA3SINAMICS 单轴132A驱动模块S120驱动模块6SL3120-1TE31-3AB0SINAMICS 单轴132A驱动模块S120驱动模块6SL3120-1TE28-5AA0SINAMICS 单轴85A驱动模块S120驱动模块6SL3120-1

TE28-5AA1SINAMICS 单轴85A驱动模块S120驱动模块6SL3120-1TE28-5AA3SINAMICS 单轴85A驱动模块S120驱动模块6SL3120-1TE28-5AB0SINAMICS 单轴85A驱动模块S120驱动模块6SL3120-1TE26-0AA0SINAMICS 单轴60A驱动模块S120驱动模块6SL3120-1TE26-0AA1SINAMICS 单轴60A驱动模块S120驱动模块6SL3120-1TE26-0AA3SINAMICS 单轴60A驱动模块S120驱动模块6SL3120-1TE26-0AB0SINAMICS 单轴60A驱动模块S120驱动模块6SL3120-1TE24-5AA0SINAMICS 单轴45A驱动模块S120驱动模块6SL3120-1TE24-5AA1SINAMICS 单轴45A驱动模块S120驱动模块6SL3120-1TE24-5AA3SINAMICS 单轴45A驱动模块S120驱动模块6SL3120-1TE24-5AB0SINAMICS 单轴45A驱动模块S120驱动模块6SL3120-1TE23-0AA0SINAMICS 单轴30A驱动模块S120驱动模块6SL3120-1TE23-0AA1SINAMICS 单轴30A驱动模块S120驱动模块6SL3120-1TE23-0AA3SINAMICS 单轴30A驱动模块S120驱动模块6SL3120-1TE23-0AB0SINAMICS 单轴30A驱动模块S120驱动模块6SL3120-1TE21-8AA0SINAMICS 单轴18A驱动模块S120驱动模块6SL3120-1TE21-8AA1SINAMICS 单轴18A驱动模块S120驱动模块6SL3120-1TE21-8AA3SINAMICS 单轴18A驱动模块S120驱动模块6SL3120-1TE21-8AA4SINAMICS 单轴18A驱动模块S120驱动模块6SL3120-1TE21-8AB0SINAMICS 单轴18A驱动模块S120驱动模块6SL3120-1TE21-0AA0SINAMICS 单轴9A驱动模块S120驱动模块6SL3120-1TE21-0AA1SINAMICS 单轴9A驱动模块S120驱动模块6SL3120-1TE21-0AA3SINAMICS 单轴9A驱动模块S120驱动模块6SL3120-1TE21-0AA4SINAMICS 单轴9A驱动模块S120驱动模块6SL3120-1TE21-0AB0SINAMICS 单轴9A驱动模块S120驱动模块6SL3120-1TE15-0AA0SINAMICS 单轴5A驱动模块S120驱动模块6SL3120-1TE15-0AA3SINAMICS 单轴5A驱动模块S120驱动模块6SL3120-1TE15-0AA4SINAMICS 单轴5A驱动模块S120驱动模块6SL3120-1TE15-0AB0SINAMICS 单轴5A驱动模块S120驱动模块6SL3120-1TE13-0AA0SINAMICS 单轴3A驱动模块S120驱动模块6SL3120-1TE13-0AA3SINAMICS 单轴3A驱动模块S120驱动模块6SL3120-1TE13-0AA4SINAMICS 单轴3A驱动模块S120驱动模块6SL3120-1TE13-0AB0SINAMICS 单轴3A驱动模块S120驱动模块6SL3120-2TE21-8AA0SINAMICS 双轴18A驱动模块S120驱动模块6SL3120-2TE21-8AA3SINAMICS 双轴18A驱动模块S120驱动模块6SL3120-2TE21-8AB0SINAMICS 双轴18A驱动模块S120驱动模块6SL3120-2TE21-0AA0SINAMICS 双轴9A驱动模块S120驱动模块6SL3120-2TE21-0AA3SINAMICS 双轴9A驱动模块S120驱动模块6SL3120-2TE21-0AA4SINAMICS 双轴9A驱动模块S120驱动模块6SL3120-2TE21-0AB0SINAMICS 双轴9A驱动模块S120驱动模块6SL3120-2TE15-0AA0SINAMICS 双轴5A驱动模块S120驱动模块6SL3120-2TE15-0AA3SINAMICS 双轴5A驱动模块S120驱动模块6SL3120-2TE15-0AA4SINAMICS 双轴5A驱动模块S120驱动模块6SL3120-2TE15-0AB0SINAMICS 双轴5A驱动模块S120驱动模块6SL3120-2TE13-0AA0SINAMICS 双轴3A驱动模块S120驱动模块6SL3120-2TE13-0AA3SINAMICS 双轴3A驱动模块S120驱动模块6SL3120-2TE13-0AA4SINAMICS 双轴3A驱动模块S120驱动模块6SL3120-2TE13-0AB0SINAMICS 双轴3A驱动模块S120控制单元6SL3040-0MA00-0AA0西门子CU320控制单元S120控制单元6SL3040-0MA00-0AA1西门子CU320控制单元S120控制单元6SL3040-1MA00-0AA0西门子CU320-2DP控制单元S120控制单元6SL3040-1MA01-0AA0西门子CU320-2PN控制单元S120控制单元6SL3040-0LA00-0AA0西门子CU310DP控制单元S120控制单元6SL3040-0LA00-0AA1西门子CU310DP控制单元S120控制单元6SL3040-0LA01-0AA0西门子CU310PN控制单元S120控制单元6SL3040-0LA01-0AA1西门子CU310PN控制单元S120控制单元6SL3040-0JA00-0AA0西门子CU305DP控制单元S120控制单元6SL3040-0JA01-0AA0西门子CU305PN控制单元S120控制单元6SL3040-0JA02-0AA0西门子CU305CAN控制单元SIMOTION C6AU1230-1AA00-0AA0西门子C230运动控制器SIMOTION C6AU1230-2AA00-0AA0西门子C230-2运动控制模块SIMOTION C6AU1230-2AA01-0AA0西门子C230-2运动控制模块SIMOTION C6AU1240-1AA00-0AA0西门子C240运动模块SIMOTION C6AU1240-1AB00-0AA0西门子C240PN运动模块SIMOTION D6AU1410-0AA00-0AA0西门子D410DP运动模块SIMOTION D6AU1410-0AB00-0AA0西门子D410PN运动模块SIMOTION D6AU1425-0AA00-0AA0西门子D425运动模块SIMOTION D6AU1425-0AA00-0CA0西门子D425,MULTIAXES BUNDLE运动模块SIMOTION D6AU1425-2AA00-0AA0西门子D425-2DP运动模块SIMOTION D6AU1425-2AD00-0AA0西门子D425-2DP/PN运动模块SIMOTION D6AU1435-0AA00-0AA0西门子D435运动模块SIMOTION D6AU1435-0AA00-0AA1西门子D435运动模块SIMOTION D6AU1435-0AA00-0CA1西门子D435,MULTIAXES BUNDLE运动模块SIMOTION D6AU1435-2AA00-0AA0西门子D435-2DP运动模块SIMOTION D6AU1435-2AD00-0AA0西门子D435-2DP/PN运动模块SIMOTION D6AU1445-0AA00-0AA0西门子D445运动模块SIMOTION D6AU1445-0AA00-0AA1西门子D445-1运动模块SIMOTION D6AU1445-0AA00-0CA0西门子D445,MULTIAXES BUNDLE运动模块SIMOTION D6AU1445-0AA00-0CA1西门子D445-1,MULTIAXES BUNDLE运动模块SIMOTION P6AU1320-7AB55-3AF0西门子P350-3运动模块SIMOTION P6AU1350-3AK41-1BE2西门子P350-3运动模块SIMOTION P6AU1350-3AK41-2BE2西门子P350-3运动模块SIMOTION P6AU1350-3AK43-1BE2西门子P350-3运动模块SIMOTION P6AU1350-3AK43-2BE2西门子P350-3运动模块

