

通过二进制用户可配置端子发出的外部故障信息

??

??

??

??????????????

二进制数出功能“报警”必须设置到LOW（用户可分配功能），而

订货号	功率		额定输入电流		额定输出电流		外形尺寸 (FS)
	kW	hp	A	A	A	A	
MM430-750/3	6SE6430-2UD27-5CA 7.5	10	16	19	19	19	C
	0						
MM430-1100/3	6SE6430-2UD31-1CA 11	15	22.5	26	26	26	C
	0						
MM430-1500/3	6SE6430-2UD31-5CA 15	20	30.5	32	32	32	C
	0						
MM430-1850/3	6SE6430-2UD31-8DB 18.5	25	37.2	38	38	38	D
	0						
MM430-2200/3	6SE6430-2UD32-2DB 22	30	43.3	45	45	45	D
	0						
MM430-3000/3	6SE6430-2UD33-0DB 30	40	59.3	62	62	62	D
	0						
MM430-3700/3	6SE6430-2UD33-7EB 37	50	71.7	75	75	75	E
	0						
MM430-4500/3	6SE6430-2UD34-5EB 45	60	86.6	90	90	90	E
	0						
MM430-5500/3	6SE6430-2UD35-5FB055	75	103.6	110	110	110	F
MM430-7500/3	6SE6430-2UD37-5FB075	100	138.5	145	145	145	F
MM430-9000/3	6SE6430-2UD38-8FB090	120	168.5	178	178	178	F
MM430-110K/3	6SE6430-2UD41-1FB0110	150	204.5	205	205	205	FX
MM430-132K/3	6SE6430-2UD41-3FB0132	200	244.5	250	250	250	FX
MM430-160K/3	6SE6430-2UD41-6GB 160	250	296.4	302	302	302	GX
	0						
MM430-200K/3	6SE6430-2UD42-0GB 200	300	354	370	370	370	GX
	0						
MM430-250K/3	6SE6430-2UD42-5GB 250	350	442	477	477	477	GX
	0						

6SE6400-0BE00-0AA0 BOP-2
6SE6400-1PB00-0AA0 PROFIBUS模板
6SE6400-0PM00-0AA 柜门安
0 装组合
件
6SE6400-1DN00-0AA DeviceNet模板
0

