

6EP1 332-2BA00	单相220VAC输入，输出24VDC	3.8A	
6EP1 332-2BA10	单相120/220VAC输入，输出24VDC	2.5A	
6EP1 332-2BA20			
6EP1 333-2AA00	单相220VAC输入，输出24VDC	5A	工业可并联
6EP1 333-2AA01	单相120/230VAC输入，输出24VDC	5A	工业可并联
6EP1 333-2BA00	单相120VAC/220VAC输入，输出24VDC	5A	
6EP1 333-2BA01	单相120VAC/220VAC输入，输出24VDC	5A	
6EP1 333-2BA20			
6EP1 333-3BA00	单相120VAC/220to500VAC输入，输出24VDC	5A	
6EP1 334-2AA00	单相220VAC输入，输出24VDC	10A	工业可并联
6EP1 334-2AA01	单相120/220VAC输入，输出24VDC	10A	工业可并联
6EP1 334-2BA00	单相220VAC输入，输出24VDC	10A	
6EP1 334-2BA01	单相220VAC输入，输出24VDC	10A	
6EP1 334-2BA20			
6EP1 334-3BA00	单相120/220VACto500VAC输入，输出24VDC	10A	
6EP1 334-3BA10			
6EP1 336-2BA00	单相220VAC输入，输出24VDC	20A	
6EP1 336-2BA10	单相220VAC输入，输出24VDC	20A	
6EP1 336-3BA00	单相220VAC输入，输出24VDC	20A	工业可并联
6EP1 336-3BA10			
6EP1 337-3BA00	单相120/230,40A		
6EP1 434-2BA00	三相380VAC输入，输出24VDC	10A	工业可并联
6EP1 434-2BA10			
6EP1 436-2BA00	三相380VAC输入，输出24VDC	20A	工业可并联
	三相380VAC输入，输出24VDC	20A	工业可并联
6EP1 436-3BA00	三相380VAC输入，输出24VDC	20A	
	新型模块式电源		
6EP1 437-2BA00	三相380VAC输入，输出24VDC	30A	工业可并联
6EP1 437-2BA10	三相380VAC输入，输出24VDC	40A	工业可并联
6EP1 437-2BA20			
6EP1 437-3BA00	三相380VAC输入，输出24VDC	40A	工业可并联
6EP1 252-0AA00	单相230VAC输入，输出41.5V/1.3A		
6EP1 252-0AA01	单相230VAC输入，输出41.5V/2A		
6EP1 457-3BA00	三相380VAC输入，输出48VDC	20A	工业可并联

MATIC PDM PCS 7 V9.1

??? SIMATIC PCS 7 ?????????? SIMATIC PDM PCS 7 ?????????? SIMATIC PCS 7 ??????????????????

SIMATIC PDM Basic (包含 4 个 SIMATIC PDM 变量)

SIMATIC PDM Extended

SIMATIC PDM 集成在 STEP 7/PCS 7 中

SIMATIC PDM Routing

100 个 SIMATIC PDM 变量

SIMATIC PDM PCS 7 ?????? PDM Communication FOUNDATION Fieldbus ? SIMATIC PDM Server ??
SIMATIC PDM ?????10?100 ? 1000 ?????????????“?????”???????? SIMATIC PDM 1 Client ?????? 1 ????
SIMATIC PDM Server ???????

SIMATIC PDM PCS 7 Server V9.1

?? SIMATIC PDM Server ?????? SIMATIC PDM PCS 7 Server ??????? SIMATIC PDM PCS 7????????? SIMATIC
PCS 7 ?????????????? SIMATIC PCS 7 ?????????????????? SIMATIC PDM ?????????????????? (EDD)
????????????????? SIMATIC PDM PCS 7 Server ??????

SIMATIC PDM Server

SIMATIC PDM PCS 7 Server ?????? SIMATIC PDM Communication FOUNDATION Fieldbus? SIMATIC PDM
?????10?100 ? 1000 ?????? SIMATIC PDM 1Client ?????????????“?????”?????????????????SIMATIC PDM
????????? SIMATIC PDM 1 Client ??????????SIMATIC PDM ?????????????“?????”????“SIMATIC PDM 1 Client”?

SIMATIC PDM PCS 7FF V9.1

?? SIMATIC PDM Communication FOUNDATION Fieldbus ?????? SIMATIC PDM PCS 7 FF ??????? SIMATIC
PDM PCS 7????????? SIMATIC PCS 7 ?????????????????? FOUNDATION Fieldbus H1 ??????????????SIMATIC
PDM PCS 7 FF ???????