

ABB热式质量流量计 Sensyflow FMT200/FMT400/FMT500/FMT700

产品名称	ABB热式质量流量计 Sensyflow FMT200/FMT400/FMT500/FMT700
公司名称	北京域能汇通科技有限公司
价格	99999.00/个
规格参数	品牌:ABB 型号:FMT200/400 产地:德国
公司地址	北京市朝阳区立清路8号3-2205
联系电话	86-010-65911327-101 18614088757

产品详情

ABB热式气体质量流量计的Sensyflow系列热质量流量计符合所有工业及测试装置对气体测量的快速和精确性的要求。 Sensyflow流量计不需要额外的压力和温度补偿即可测量气体的质量流量或标况流量。 Sensyflow流量计具有精度高、响应时间短、量程比宽等特点，即使在极小的流量范围内也能够保证测量精度。

- 模块化设计优化了测量精度，降低了安装、运行及维护的成本
- 一台流量计可以存储多达四种气体的流量特征曲线
- 与同类产品相比，在响应时间及精度方面具有无可比拟的优势。

V14222 SENSYFLOW VT-S MASS FLOW METER FOR GASES(FLOW METER FOR MEASURING FLOW)FMT081 PIPE COMPONENT/WELD-ON ADAPTER FOR SENSYFLOW(FOR MFGONLY)V14222 SENSYFLOW VT-S MASS FLOW METER FOR GASES(FLOW METER FOR MEASURING FLOW)FMT081 PIPE COMPONENT/WELD-ON ADAPTER FOR SENSYFLOW(FOR MFGONLY)V14222 SENSYFLOW VT-S MASS FLOW METER FOR GASES(FLOW METER FOR MEASURING FLOW)FMT081 PIPE COMPONENT/WELD-ON ADAPTER FOR SENSYFLOWV14243 SENSYFLOW P SUPPLY-/EVALUATION UNIT(FLOW METER FOR MEASURING FLOW)7962638 SENSYFLOW FMT700-P THERMAL MASS FLOW METER SENSOR(FLOW METER FOR MEASURING FLOW)7962650 SENSYFLOW P MEAS SECTION 1 NW 200 FOR AMBINET AIR(FLOW METER FOR MEASURING FLOW)7962695 SENSYFLOW P TRANSDUCER CABLE 15 M LONG(FLOW METER FOR MEASURING FLOW)7962697 SENSYFLOW P INTERFACE CABLE (FLOW METER FOR MEASURING FLOW)SENSYFLOW P PROCESSOR UNIT 19 SNR.3232915 GY0782R (PARTS FOR EMISSION SYSTEMS) (FOR CAPTIVE USE)(REPAIR&RETURN)G1000_FMT700-P SENSOR SENSYFLOW SENSOR THERMAL MASS FLOW METER SENSOR(MD:14241-7962635)(S/N:2779074)(REPAIR&RETURN)G1000_FMT700-P SENSOR SENSYFLOW SENSOR THERMAL MASS FLOWMETER SENSOR(MD:14241-7962636)(S/N:31611052)(REPAIR&RETURN)G1000_FMT700-P SENSOR SENSYFLOW FMT700-9 FLOWMETER SENSOR(MD:14241-7962637)(SN:79626370000000000134)(REPAIR&RETURN)G1000_FMT700-P SENSOR

SENSYFLOW FMT700-9 THERMAL MASS FLOWMETER

SENSOR(MD:14241-7962637)(S/N:29310092)(REPAIR &RETURN)G1000_FMT700-P FMT700-P SENSOR
SENSYFLOW MASS FLOWMETER FOR GASES (MD:14241-7962635) (SL:2778991)

(REPAIR&RETURN)V14241-7962637 SENSYFLOW MASS FLOWMETER FOR GASES(SL NO:2467477)

(REPAIR&RETURN)V14243-111101 SENSYFLOW THERMAL MASS FLOWMETER FOR GASES(SL
NO:2461564)(REPAIR&RETURN)G1000_FMT700-P SENSYFLOW FMT700-P THERMAL MASS
FLOWMETRE SENSOR MD:14241-7962635SL:241063539X001V14243 SENSYFLOW P
SUPPLY-/EVALUATION UNIT(FLOW METER FOR MEASURING FLOW)7962637 SENSYFLOW FMT700-P
THERMAL MASS FLOWMETER SENSOR7962649 SENSYFLOW P MEAS SECTION 1, NW 150, FOR
AMBIENT AIRFILTER (ITEM AS PER INVOICE)7962695 SENSYFLOW P TRANSDUCER CABLE 15 M
LONG(REPAIR & RETURN)G1000_FMT700-P SENSYFLOW FMT700-P THERMAL MASS FLOWMETER
SENSOR MODEL:142417962637SL29810422(REPAIR & RETURN)G1000_FMT700-P SENSYFLOW FMT700-P
THERMAL MASSMETER SENSOR MODEL:14241-7962637 SL:33270132(REPAIR &
RETURN)G1000_FMT700-P SENSOR SENSYFLOW FMT700-P THERMAL MASSMETER SENSOR
MODEL:14241-7962637 SL:30210636(REPAIR & RETURN)G1000_FMT700-P SENSOR SENSYFLOW
FMT700-P THERMAL MASSMETER SENSOR MODEL:14211-2962637
SL:2728843(REPAIR&RETURN)14241-7962635 CP15A0182 SENSYFLOW SENSOR(SL
NO:2467489)(REPAIR&RETURN)14243-121101 CP15A0181 SENSYFLOW
INDICATOR(SLNO:2461568)(REPAIR & RETURN)V14224-1A11121210 SENSYFLOW IG MASS
FLOWMETER FOR GASES(SL NO:241999318/X016)(FOR MEASURING FLOW)(REPAIR &
RETURN)V14224-1A13121210 SENSYFLOW IG MASS FLOWMETER FOR GASES(SL
NO:241999318X034)(FOR MEASURING FLOW)(REPAIR&RETURN)V14224 1A11121210 SENSYFLOW MASS
FLOWMETER FOR GASES(SL NO:241999318/X010)(REPAIR&RETURN)V14224 1A11121210 SENSYFLOW
MASS FLOWMETER FOR GASES(SL NO:241999318/X014)(REPAIR&RETURN)V14224 1A11121210
SENSYFLOW MASS FLOWMETER FOR GASES(SL NO:241999318/X005)(FOC)V14224-6A12121210
SENSYFLOW IG MASS FLOWMETER FOR GASES(FLOWMETER FOR MEASURING FLOW)CABLE
SENSYFLOW L=15M EZ0360 (PARTS FOR EMISSION SYSTEMS) (FOR CAPTIVE USE)V14224 SENSYFLOW
IG MASS FLOWMETER FOR GASES(FLOWMETER FOR MEASURING FLOW)FMT081 PIPE
COMPONENT/WELD-ON ADAPTER FOR SENSYFLOW (FOR MFGONLY)V14224 SENSYFLOW IG MASS
FLOWMETER FOR GASES(FLOWMETER FOR MEASURING FLOW)FMT081 PIPE COMPONENT/WELD-
ON ADAPTER FOR SENSYFLOW (FOR MFGONLY)V14222 SENSYFLOW VT-S MASS FLOW METER FOR
GASES(FLOW METER FOR MEASURING FLOW)FMT081 PIPE COMPONENT/WELD-ON ADAPTER FOR
SENSYFLOW (FOR MFGONLY)7962634 SENSYFLOW FMT700-P THERMAL MASS FLOWMETER
SENSOR7962635 SENSYFLOW FMT700-P THERMAL MASS FLOWMETER SENSOR7962636 SENSYFLOW
FMT700-P THERMAL MASS FLOWMETER SENSOR7962648 SENSYFLOW P MEAS SECTION 1 NW 100 FOR
AMBIENT AIR FILTER

7962696 SENSYFLOW P TRANSDUCER CABLE 30 M LONG

7962660 SENSYFLOW P -AIR FILTER FILTER CONNECTING FLANGE RAPID 1 CLAMPING RING7962666
SENSYFLOW P INTAKE SECTION 10 X D 1 CONICAL INTERMEDIATE FLANGE 1 RAPID CLAMPING
RING7962678 SENSYFLOW P OUTLET SECTION 5 X D 1 CONICAL 1 INTERMEDIATE FLANGE 1 RAPID
CLAMPING RINGV14243 SENSYFLOW P SUPPLY-/EVALUATION UNIT(FLOW METER FOR MEASURING
FLOW)7962637 SENSYFLOW FMT700-P THERMAL MASS FLOWMETER SENSOR7962649 SENSYFLOW P
MEAS SECTION 1, NW 150, FOR AMBIENT AIRFILTER (ITEM AS PER INVOICE)7962695 SENSYFLOW P
TRANSDUCER CABLE7962697 SENSYFLOW P INTERFACE CABLE(1XCONNECTOR)(3M)V14243
SENSYFLOW P SUPPLY-/EVALUATION UNIT(FLOW METER FOR MEASURING FLOW)7962636

SENSYFLOW FMT700-P THERMAL MASS FLOWMETER SENSOR7962648 SENSYFLOW P MEAS SECTION 1 NW 100 FOR AMBIENT AIR FILTER ITEM AS PER INVOICE7962695 SENSYFLOW P TRANSDUCER CABLE7962666 SENSYFLOW P INTAKE SECTION 10 X D 1 CONICAL INTERMEDIATE FLANGE 1 RAPID CLAMPING RING7962678 SENSYFLOW P OUTLET SECTION 5 X D 1 CONICAL 1 INTERMEDIATE FLANGE 1 RAPID CLAMPING RING7962721 CLAMPING RING SENSYFLOW P-MEAS SYSTEMSENSYFLOW SENSOR 0-2400KG/H (PARTS FOR EMISSION SYSTEMS) (FOR CAPTIVE USE)V14243 SENSYFLOW P SUPPLY-/EVALUATION UNIT(FLOW METER FOR MEASURING FLOW)V14243 SENSYFLOW P SUPPLY-/EVALUATION UNIT(FLOW METER FOR MEASURING FLOW)V14243 SENSYFLOW P SUPPLY-/EVALUATION UNIT(FLOW METER FOR MEASURING FLOW)V14243 SENSYFLOW P SUPPLY-/EVALUATION UNIT(FLOW METER FOR MEASURING FLOW)7962634 SENSYFLOW FMT700-P THERMAL MASS FLOWMETER SENSOR7962635 SENSYFLOW FMT700-P THERMAL MASS FLOWMETER SENSOR7962636 SENSYFLOW FMT700-P THERMAL MASS FLOWMETER SENSOR7962646 SENSYFLOW P MEASURING SECTION 1,NW 50 FOR AMBIENT AIR FILTER(ITEM AS PER INVOICE)7962696 SENSYFLOW P TRANSDUCER CABLE 30 M LONG7962696 SENSYFLOW P TRANSDUCER CABLE 30 M LONG7962696 SENSYFLOW P TRANSDUCER CABLE 30 M LONG7962658 SENSYFLOW P-AIR FILTER(ITEM AS PER INVOICE)7962664 SENSYFLOW P- INTAKE SECTION 10 X D 1 CONICAL INTERMEDIATE FLANGE 1 CLAMPING RING7962676 SENSYFLOW P OUTLET SECTION 5XD 1 CONICAL INTERMEDIATE FLANGE 1 CLAMPING RING7962647 SENSYFLOW P MEAS.SECTION 1 NW 80 FOR AMBIENT AIR FILTER ITEM AS PER INVOICE7962659 SENSYFLOW P-AIR FILTER ITEM AS PER INVOICE7962665 SENSYFLOW P INTAKE SECTION 10XD 1 CONICAL INTERMEDIATE FLANGE 1 CLAMPING RING7962677 SENSYFLOW P OUTLET SECTION 5 X D 1 CONICAL INTERMEDIATE FLANGE 1 CLAMPING RING7962648 SENSYFLOW P MEAS SECTION 1 NW 100 FOR AMBIENT AIR FILTER ITEM AS PER INVOICE7962660 SENSYFLOW P -AIR FILTER ITEM AS PER INVOICE7962666 SENSYFLOW P INTAKE SECTION 10 X D 1 CONICAL INTERMEDIATE FLANGE 1 CLAMPING RING7962678 SENSYFLOW P OUTLET SECTION 5 X D 1 CONICAL INTERMEDIATE FLANGE 1 CLAMPING RING7962696 SENSYFLOW P TRANSDUCER CABLE 30M LONGV14224 SENSYFLOW IG MASS FLOWMETER FOR GASES(FLOWMETER FOR MEASURING FLOW)FMT081 PIPE COMPONENT/WELD-ON ADAPTER FOR SENSYFLOW (FOR MFGONLY)V14224 SENSYFLOW IG MASS FLOWMETER FOR GASES(FLOWMETER FOR MEASURING FLOW)FMT081 PIPE COMPONENT/WELD-ON ADAPTER FOR SENSYFLOW (FOR MFGONLY)V14224 SENSYFLOW IG MASS FLOWMETER FOR GASES(FLOWMETER FOR MEASURING FLOW)FMT081 PIPE COMPONENT/WELD-ON ADAPTER FOR SENSYFLOW (FOR MFGONLY)V14224 SENSYFLOW IG MASS FLOWMETER FOR GASES(FLOWMETER FOR MEASURING FLOW)FMT081 PIPE COMPONENT/WELD-ON ADAPTER FOR SENSYFLOW (FOR MFGONLY)V14224 SENSYFLOW IG MASS FLOWMETER FOR GASES(FLOWMETER FOR MEASURING FLOW)FMT081 PIPE COMPONENT/WELD-ON ADAPTER FOR SENSYFLOW (FOR MFGONLY)SENSYFLOW SENSOR 0-1200 KG/H EZ0346 29410102 (PARTS FOR EMISSION SYSTEMS) (FOR CAPTIVE USE)SENSYFLOW SENSOR 0-1200 KG/H EZ0346 35170444 (PARTS FOR EMISSION SYSTEMS) (FOR CAPTIVE USE)SENSYFLOW SENSOR 0-2400 KG/H EZ0347 33311576 (PARTS FOR EMISSION SYSTEMS) (FOR CAPTIVE USE)SENSYFLOW SENSOR 0-2400 KG/H EZ0347 33070075 (PARTS FOR EMISSION SYSTEMS) (FOR CAPTIVE USE)SENSYFLOW SENSOR 0-2400 KG/H EZ0347 33370192 (PARTS FOR EMISSION SYSTEMS) (FOR CAPTIVE USE)SENSYFLOW P PROCESSOR UNIT 19 GY0782 3333148 (PARTS FOR EMISSION SYSTEMS) (FOR CAPTIVE USE)SENSYFLOW P PROCESSOR UNIT 19 GY0782 3353214 (PARTS FOR EMISSION SYSTEMS) (FOR CAPTIVE USE)SENSYFLOW P PROCESSOR UNIT 19 GY0782 25831722 (PARTS FOR EMISSION SYSTEMS) (FOR CAPTIVE USE)SENSYFLOW P PROCESSOR UNIT 19 GY0782 3353215 (PARTS FOR EMISSION SYSTEMS) (FOR CAPTIVE USE)SENSYFLOW P AIR FILTER DN100 TCSPMMASTA.01A (PARTS FOR EMISSION SYSTEMS) (FOR CAPTVE USE)SENSYFLOW P AIR FILTER DN150 TCSPMMASTA.01A (PARTS FOR EMISSION SYSTEMS) (FOR CAPTVE USE)

GAUGE COMPLETE TYP SENSYFLOW 1924185 FMT700-P (S/NO.1924185) (PARTS FOR EMISSION SYSTEMS) (FOR CAPTIVE USE)

TM16AD000A.01 SENSYFLOW 1200KG/H (PARTS FOR EMISSION SYSTEMS) (FOR CAPTIVE USE)TM16AD000A.01 SENSYFLOW ACCESSORIES 1200KG/H 1200KG/H (PARTS FOR EMISSION SYSTEMS) (FOR CAPTIVE USE)TM16AD000A.01 SENSYFLOW 1200KG/H (PARTS FOR EMISSION SYTEMS) (FOR CAPTIVE USE)TM16AD001A.01 SENSYFLOW PLUG CONNECTOR, PROCESSOR UNIT 19 CESSORIES (PARTS FOR EMISSION SYTEMS) (FOR CAPTIVE USE)V14243 SENSYFLOW P SUPPLY-/EVALUATION UNIT(FLOW METER FOR MEASURING FLOW)7962634 SENSYFLOW FMT700-P THERMAL MASS FLOWMETER SENSOR NOMINAL DIAMETER DN50(FLOW METER FOR MEASURING FLOW)7962695 SENSYFLOW P (15 M)TRANSDUCER CABLE (FLOWMETER FOR MEASURING FLOW)7962646 SENSYFLOW P MEASURING SECTION 1,NW 50 FOR AMBIENT AIR7962664 SENSYFLOW P INTAKE SECTION 10XD 1 CONICAL, 1 INTERMEDIATE FLANGE 1 RAPID CLAMPING RING NOMINAL DIAMETER DN 507962676 SENSYFLOW P OUTLET SECTION 5XD 1 CONICAL, 1 INTERMEDIATE FLANGE 1 RAPID CLAMPING RING NOMINAL DIAMETER DN 50SENSYFLOW (PART OF KRATZER GAS STAND)V14243 SENSYFLOW P SUPPLY-/EVALUATION UNIT(FLOW METER FOR MEASURING FLOW)7962635 SENSYFLOW FMT700-P THERMAL MASS FLOWMETER SENSOR NOMINAL DIAMETER DN80(FLOW METER FOR MEASURING FLOW)7964109 SENSYFLOW P MEASURING SECTION 3 DN80(FLOW METER FORMEASURING FLOW)7962695 SENSYFLOW P (15 M)TRANSDUCER CABLE (FLOW METER FOR MEASURING FLOW)7962697 SENSYFLOW P INTERFACE CABLE(1XCONNECTOR)(3M)7962637 SENSYFLOW FMT700-P THERMAL MASS FLOWMETER SENSOR7964111 SENSYFLOW P MEASURING SECTION 3 DN150(FLOW METER FORMEASURING FLOW)(AIR MASS FLOW METER) SENSYFLOW SENSOR 0-1200KH/H 225 EZ0346 (SPARE PARTS FOR EMISSION SYSTEM) (CAPTIVE USE)CABLE SENSYFLOW L=15, (1 PCS) EZ0360 (SPARE PARTS FOR EMISSION SYSTEM) (CAPTIVE USE)ACCESSORIES SENSYFLOW O.F. 0-1200KH/H EZ0353 (SPARE PARTS FOR EMISSION SYSTEM) (CAPTIVE USE)SENSYFLOW P PROCESSOR UNIT 19 503 GY0782 (SPARE PARTS FOR EMISSION SYSTEM) (CAPTIVE USE)V14224 SENSYFLOW IG MASS FLOWMETER FOR GASES(FIOWMETER FOR MEASURING FLOW)FMT081 PIPE COMPONENT/WELD-ON ADAPTER FOR SENSYFLOW (FOR MFGONLY)V14224 SENSYFLOW IG MASS FLOWMETER FOR GASES(FIOWMETER FOR MEASURING FLOW)FMT081 PIPE COMPONENT/WELD-ON ADAPTER FOR SENSYFLOW (FOR MFGONLY)FMT081 PIPE COMPONENT/WELD-ON ADAPTER FOR SENSYFLOW (FOR MFGONLY)AIR MASS FLOW METER- SENSYFLOW ECO II - V 14252 0-750/MIN, 24V DC /4-20 mA GAS MASS FLOW METER- SENSYFLOW ECO II - V 14252 0-750/MIN, 24V DC /4-20 mA SENSYFLOW C.F. 0-400 KG/H EZ0350 (PARTS FOR EMISSION SYSTEM) (CAPTIVE USE)INSTRUMENT CABLE SENSYFLOW L=15 M EZ0360 (PARTS FOR EMISSION SYSTEM) (CAPTIVE USE)SENSYFLOW C.F. 0-400 KG/H EZ0350 (PARTS FOR EMISSION SYSTEM) (CAPTIVE USE)INSTRUMENT CABLE SENSYFLOW L=15M TCSPPPASTA.01A (PARTS FOR EMISSION SYSTEMS) (FOR CAPTIVE USE)ACCESSORIES SENSYFLOW O.F. 0-1200 KG/H- EZ0353 (SPARE PARTS OF EMISSION SYSTEM) (CAPTIVE USE)SENSYFLOW EVALUATION UNIT TC04LSENS.06 (SPARE PARTS FOR EMISSION SYSTEM) (CAPTIVE USE)SENSYFLOW P PROCESSOR UNIT 19 (PARTS FOR EMISSION SYSTEMS) (FOR CAPTIVE USE)SENSYFLOW P PROCESSOR UNIT 19(GY0782RPA) (PARTS FOR EMISSION SYSTEM) (FOR CAPTIVE USE)SENSYFLOW SENSOR (EZ0346) 0-1200KG/H (SPARE PARTS FOR EMISSION SYSTEM)CABLE SENSYFLOW L=15M (EZ0360) (SPARE PARTS FOR EMISSION SYSTEM)ACCESSORIES SENSYFLOW C.F. 0-1200 KG/H (EZ0354) (SPARE PARTS FOR EMISSION SYSTEM)SENSYFLOW P PROCESSOR UNIT 19 (GY0782) (SPARE PARTS FOR EMISSION SYSTEM)SENSYFLOW SENSOR 0-1200KG/H TCKALIBABB.01A (PARTS FOR EMISSION SYSTEMS) FOR CAPTIVE USESENSYFLOW P PROCESSOR UNIT 19 GY0782RPA (PARTS FOR EMISSION SYSTEMS) FOR CAPTIVE USEV14224 SENSYFLOW IG MASS FLOWMETER FOR GASES(FIOWMETER FOR MEASURING FLOW)FMT081 PIPE COMPONENT/WELD-ON ADAPTER FOR SENSYFLOW (FOR MFGONLY)7962847 SENSYFLOW IG T-PLUG FOR PROFIBUS DP IP 67(FOR MFG ONLY)7962848 SENSYFLOW IG PLUG-PIN M12 FOR PROFIBUS DP IP 67(FORMFG ONLY)7962849 SENSYFLOW IG PLUG-SOCKET M12 FOR PROFIBUS DP IP 67(FOR MFG ONLY)(REPAIR & RETURN)THERMAL MASS FLOWMETER-SENSYFLOW P CONSISTNS OF ITEM AS PER INVOICE(S/N:3012604,30110535,30110581)(RE-IMPORT AFTER CALIBRATION & REPAIR)AMFM CLEANING AND CALIBR S.N.2226004(AIR MASS FLOW METER TYPE:SENSYFLOW 0-1200KG/(RE-IMPORT AFTER CALIBRATION & REPAIR)AMFM CLEANING AND

CALIBR S.N.2547353(AIR MASS FLOW METER TYPE:SENSYFLOW 0-1200KG/(RE-IMPORT AFTER CALIBRATION & REPAIR)AMFM CLEANING AND CALIBR S.N.2689569 (AIR MASS FLOW METER TYPE:SENSYFLOW 0-1200KG(RE-IMPORT AFTER CALIBRATION & REPAIR)AMFM CLEANING AND CALIBR S.N.7962636 (AIR MASS FLOW METER TYPE:SENSYFLOW 0-1200KG