

# 混流泵供应商 金石泵业公司 雨水混流泵供应商

产品名称	混流泵供应商 金石泵业公司 雨水混流泵供应商
公司名称	泰安金石泵业有限公司
价格	面议
规格参数	
公司地址	山东省泰安市泰山区南关路12号
联系电话	13605386905

## 产品详情

### 混流泵

#### 深井潜水泵

首先看一下水泵此时运行的电流和平常运行时候的电流差别有多大。如果比平时运行时候小（基上就是平时电流的2、3），那么就有叶轮磨损、泵头最上面的止逆阀堵塞等问题。如果和平时电流一样大，混流泵供应商，那么就是管垫漏水、管子漏水、泵体漏水等问题。如果比平时运行的时候电流大，那么基上可以确定是易损件磨损的问题。另外补充一点，电缆如果破损的话，水量跟平时是一样大，移动式混流泵供应商，但是电流会变大。3相380V电机的电流一般是2.2A。以上原因只要是经常维修深井泵的修理人员就可以查出来。

### 混流泵

三) 密封装置是由填料函、水封圈、填料压盖和铅粉（或油浸）石棉盘根填料组成。其作用有：

- 1、启动时防止空气吸入泵内，起密封作用。
- 2、抽水时防止水从泵内过多的沿轴大量流出。

III. Sealing equipment is composed of stuffing box ,

water seal , packing gland , lead powder(or oil immersed)

asbestos

packing padding. Its use is as follows:

## 1. When

starting , stop the pump from sucking air and realize the sealing function.

## 2. When

drawing water , stop the water running out through the axle from pump.

使用与保养：Use And

Maintenance

1、经常检查轴承温度，轴承箱内应装70%的钙基黄油，不得过多或过少，轴承升温一般不得比周围超过35 ° C，轴承的极限温度不得超过75 ° C（用手摸感到烫手），若超过应停车检查原因予以消除。

Check the bearing temperature

regularly.The bearing box should be put 70% butter , 雨水混流泵供应商 , it can not be too much or

too little.The temperature rising of bearing can not be more than 35 ° C higher

than around temperature and the limiting temperature of bearing is 75 ° C , if the temperature is higher than 75 ° C , stop to check the reason and adjust it.

混流泵供应商-金石泵业公司-雨水混流泵供应商由泰安金石泵业有限公司提供。泰安金石泵业有限公司（[www.tajsby.cn](http://www.tajsby.cn)）为客户提供“水泵,泥浆泵,混流泵,轴流泵,渣浆泵”等业务，公司拥有“金石泵业”等品牌。专注于污水泵、杂质泵等行业，在山东泰安有较高知名度。欢迎来电垂询，联系人：刘经理。