

# 330180-91-00/9200-06-05-01-00/9200-06-05-05-00-00/BENTLY本特利

产品名称	330180-91-00/9200-06-05-01-00/9200-06-05-05-00-00/BENTLY本特利
公司名称	北京域能汇通科技有限公司
价格	5555.00/个
规格参数	品牌:本特利 型号:330180-91-00 产地:美国
公司地址	北京市朝阳区立清路8号3-2205
联系电话	86-010-65911327-101 18614088757

## 产品详情

330180-91-00/9200-06-05-01-00/9200-06-05-05-00-00/BENTLY本特利

美国本特利 (bently nevada) 公司的bently3500系统提供连续、在线监测功能，适用于机械保护应用。bently3500系统组成：3500/05 仪表框架；一或两个 3500/15 电源；3500/20 框架接口模块；一或两个3500/25 键相器模块；3500 框架组态软件；一个或多个 3500/32 继电器模块或3500/33 16通道继电器模块；一个或多个 3500/92 通讯网关模块；一个或多个 3500/XX 监测器模块，3500/42M 位移/速度加速度监测器；3500/40M位移监测器；3500/45 差胀/轴向位置监测器；3500/50 转速模块；3500/53 超速检测模块等。3500/XX 监测器模块可接来自bently3300系统的信号，bently3300系统即传感器系统，包括传感器探头，前置器，延伸电缆等。电涡流传感器探头330101，330102，330103，330104，330105，330106，330851，速度传感器和加速度传感器9200，330500等；前置器330180，330780等；延伸电缆330130，330780等。传感器通常安装于机器内部或表面，用于测量轴振动、瓦振、位移、转速、偏心、键相、转速、差胀等。另外还有1900系列，如1900/65，测试、模拟和校准仪器：如TK3-2 电涡流探头校准仪，RK 4 转子试验台等。

本特利3300传感器探头，型号：330101、330102、330103、330104、330105、330106、330180、330130、330780、330851、3500/42、3500/15、3500/20、3500/32。

美国本特利(Bently Nevada)传感器，本特利bently探头，bently延伸电缆，bently前置器，本特利(BENTLY)前置器，本特利bently仪表框架，本特利bently框架接口模块，本特利bently键相器模块，本特利bently监测模块，本特利bently显示装置，本特利bently通讯网关模块，本特利bently超速保护模块，本特利bently系统模块，本特利bently胀差/轴向位置模块，本特利bently转速模块，本特利bently温度监测器，本特利bently过程变量监测模块，本特利bently校验仪，本特利bently检测卡，本特利bently速度探头，本特利bently光电探头延长电缆，本特利bently趋近式探头，本特利bently变压器后板，本特利bently充电器，本特利bently轴位移探头，本特利bently测震探头，本特利bently继电器模块，本特利bently两芯电缆

美国BENTLY本特利传感器，美国BENTLY本特利电涡流探头，美国BENTLY本特利胀差传感器，美国BENTLY本特利电涡流轴位移传感器，美国BENTLY本特利探头传感器，美国BENTLY本特利加速度传感器，美国BENTLY本特利 延伸电缆，美国BENTLY本特利前置器等。

3301023300XL8mm探头，3/8-24UNF螺纹，铠装

部件号-AXX-BXX-CXX-DXX-EXX

本特利330102-00-13-90-02-00

本特利330102-00-20-10-02-05

本特利330102-00-40-10-02-00

本特利330102-00-51-10-02-05

本特利330102-00-52-10-02-00

本特利330102-00-60-10-02-00

本特利330102-00-68-05-02-00

本特利330102-00-68-05-02-05

本特利330102-00-80-10-02-00

本特利330102-05-25-10-02-00

本特利330102-20-52-10-02-05

本特利330102-36-80-10-02-05

3301033300XL8mm探头，M10×1螺纹，非铠装

本特利330103-00-22-05-02-00

本特利330103-00-04-10-01-00

本特利330103-01-07-50-02-00

本特利330103-00-06-10-02-05

本特利330103-00-05-05-02-00

本特利330103-10-20-05-02-00

本特利330103-10-20-10-02-00

本特利330103-12-20-50-02-00

本特利330103-13-20-10-02-00

本特利330103-15-23-05-02-00

本特利330103-15-23-05-02-05

本特利330103-19-25-05-02-05

3301043300XL8mm探头，M10×1螺纹，铠装

本特利330104-00-02-10-02-00

本特利330104-00-03-10-02-00

本特利330104-00-04-10-02-00

本特利330104-00-05-10-02-00

本特利330104-00-06-10-02-00

本特利330104-00-07-10-02-00

本特利330104-00-08-10-02-00

本特利330104-00-09-10-02-00

本特利330104-00-10-10-02-00

本特利330104-00-11-10-02-00

本特利330104-00-12-10-02-00

本特利330104-00-13-10-02-00

本特利330104-00-14-10-02-00

本特利330104-00-15-10-02-00

本特利330104-00-16-10-02-00

本特利330104-00-17-10-02-00

本特利330104-00-18-10-02-00

本特利330104-00-19-10-02-00

本特利探头传感器

330101,330102,330103,330104,330105,330104,330105,330106

探头传感器330101-00-08-05-02-00

探头传感器330101-00-08-05-02-05

探头传感器330103-00-03-10-02-00

探头传感器330103-00-06-05-02-00

探头传感器330103-10-20-10-02-00

探头传感器330104-00-04-05-02-00

探头传感器330104-00-09-05-02-00

探头传感器330104-00-18-10-02-00

探头传感器330104-12-22-10-02-00

探头传感器330105-02-12-05-02-00

探头传感器330105-02-12-10-02-00

探头传感器330106-05-30-10-02-00

探头传感器330703-000-060-10-02-00

探头传感器330704-000-050-10-02-05

探头传感器330708-20-50-10-02-00

探头传感器330173-00-04-10-02-00

探头传感器330604-00-13-10-02-00

探头传感器330500-02-00

探头传感器330525-00

探头传感器330195-02-12-10-00

探头传感器330851-04-000-023-50-01-05

探头传感器330903-12-25-10-02-00

探头传感器330905-00-15-10-02-00

探头传感器9200-01-05-10-00

探头传感器21000-16-05-15-085-03-02

探头传感器21504-00-12-05-02

探头传感器21505-22-55-10-02

探头传感器31000-16-10-15-163-01-02

探头传感器26530-12-10-00-000-074-21-00-00

探头传感器330104-00-02-10-02-00

探头传感器330104-00-03-10-02-00

探头传感器330104-00-04-10-02-00

探头传感器330104-00-05-10-02-00

探头传感器330104-00-06-10-02-00

探头传感器330104-00-07-10-02-00

探头传感器330104-00-08-10-02-00

探头传感器330104-00-09-10-02-00

探头传感器330104-00-10-10-02-00

探头传感器330104-00-11-10-02-00

探头传感器330104-00-12-10-02-00

探头传感器330104-00-13-10-02-00

探头传感器330104-00-14-10-02-00

探头传感器330104-00-15-10-02-00

探头传感器330104-00-16-10-02-00

探头传感器330104-00-17-10-02-00

探头传感器330104-00-19-10-02-00

常用型号如下

前置器330780-50-00

前置器330780-90-00

前置器330780-50-05

前置器330780-90-05

前置器330780-51-00

前置器330780-91-00

前置器330850-50-05

前置器330850-90-05

前置器330980-50-00

前置器330980-70-00

前置器330180-51-00

前置器330180-91-00

前置器330180-51-05

前置器330180-91-05

前置器330180-50-00

前置器330180-90-00

前置器330180-50-05

前置器330180-90-05

前置器330878-50-00

前置器330878-90-00

本特利延伸电缆

延伸电缆330130-040-00-00

延伸电缆330130-045-00-00

延伸电缆330130-040-01-00

延伸电缆330130-080-00-00

延伸电缆330130-080-01-00

延伸电缆330730-040-01-00

延伸电缆330730-080-00-00

延伸电缆330930-040-01-00

监测模块3300/03-01-00

监测模块3300/03-02-01

监测模块3300/03-03-00

监测模块3300/05-22-00-00

监测模块3300/12-02-22-01

监测模块3300/12-03-20-00

监测模块3300/14-01-02-00

双通道振动监测器3300/12-01-20-00

监测模块3300/16-11-01-03-00-00-01

双通道振动监测器3300/16-12-01-01-00-00-00

双通道振动监测器3300/16-12-01-01-00-00-01

双通道振动监测器3300/16-12-01-01-00-00-02

双通道振动监测器3300/16-13-01-00-00-00-00

双通道振动监测器3300/16-14-01-01-00-00-00

双通道振动监测器3300/16-15-01-01-00-00-00

双通道振动监测器3300/16-15-01-03-00-00-00

监测模块3300/20-12-01-00-00-00

监测模块3300/20-12-01-01-00-02-00

监测模块3300/20-12-01-03-00

监测模块3300/20-12-01-03-00-00

监测模块3300/20-12-01-03-00-01

监测模块3300/20-13-02-00-00-00

监测模块3300/20-13-02-01-00-00

监测模块3300/35-12-02-01-00-02

监测模块3300/35-15-10-02-00-00

监测模块3300/40-12-01-01-00-00

监测模块3300/40-13-01-00-00-00

监测模块3300/45-01-01-01-00

系统模块3300/46-04-02-01-00

系统模块3300/47-01-04-01-00

系统模块3300/48-04-02-00-00

监测模块3300/50-01-01-00-00

监测模块3300/50-02-01-00-00

监测模块3300/52-02-00-00

监测模块3300/53-03-02-\*\*-\*\*

Bently模块3300/55-03-01-15-15-00-00-01-00

Bently模块3300/55-03-04-15-15-00-00-05-00

Bently模块3300/65-14-01-00-00-01

仪表框架3500/05-01-01-00-00-00

仪表框架3500/05-01-02-00-00-00

仪表框架3500/05-01-02-00-01

仪表框架3500/05-02-04-00-00-00

电源模块3500/15-02-02-00

框架接口模块3500/20-01-01-00

框架接口模块3500/20-01-02-00

框架接口模块3500/20-02-02-00

框架接口模块3500/22-01-01-00

键相器模块3500/25-01-01-00

键相器模块3500/25-01-02-00

键相器模块3500/25-01-03-00

继电器模块3500/32-01-00

键相器模块3500/33-01-00

330105-02-12-10-02-00 本特利探头

330104-00-02-10-02-00

330104-00-03-10-02-00



330104-00-04-10-02-00

330104-00-05-10-02-00

330104-00-06-10-02-00

330104-00-07-10-02-00

330104-00-08-10-02-00

330104-00-09-10-02-00

330104-00-10-10-02-00

330104-00-11-10-02-00

330104-00-12-10-02-00

330104-00-13-10-02-00

330104-00-14-10-02-00

330104-00-15-10-02-00

330104-00-16-10-02-00

330104-00-17-10-02-00

330104-00-18-10-02-00

330104-00-19-10-02-00

3300XL8mm电涡流探头

3301013300XL8mm探头，3/8-24UNF螺纹，非铠装

本特利330101-00-14-10-02-00

本特利330101-00-08-10-02-05

本特利330101-00-08-10-02-00

本特利330101-00-30-05-02-00

本特利330101-00-30-10-02-00

本特利330101-00-40-05-02-00

本特利330101-23-37-10-02-00

本特利330101-29-52-05-02-00

本特利330101-30-59-10-02-05

本特利330101-38-59-05-12-00

本特利330101-36-56-05-02-00

本特利330101-41-72-05-02-00

本特利330101-49-80-05-02-00

140 模块 84145-01 1

141 电缆 84510-30 3

142 延长电缆 84661-16 13

143 VELOMITOR 84964-01 2

144 速度探头 9200-01-05-10-00 1

145 框架 3500/05-01-01-00-00-00 1

146 电源模块 3500/15-02-02-00 2

147 接口模块 3500/20-01-02-00 2

148 键相器模块 3500/25-01-01-00 2

149 继电器模块 3500/32-01-00 2

150 位移监测器 3500/42-01-00 2

151 3500/45-02-00 1

152 3500/92-01-01-00 1

153 探头传感器 330101-00-08-05-02-00

154 探头传感器 330101-00-08-05-02-05

本特利 ( Bently Nevada )

振动探头 330105-02-12-10-02-00

29715-194-40-10-05 sensor

130118-0050-02本特利

130419-0050-02

21000-16-10-00-040-03-02 sensor

21000-16-10-00-044-03-02

21000-16-10-00-065-03-02

21000-16-10-00-066-03-02

21000-16-10-00-105-03-02

21000-16-10-00-256-03-02

21508-02-12-10-02

24765-01-01

24765-02-00

31000-16-05-00-075-03-02

31000-16-05-00-080-03-02

31000-16-10-00-107-03-02

31000-16-10-00-118-03-02

31000-28-05-00-055-00-02

31000-28-05-00-062-00-02

330101-00-08-05-02-05

330101-00-12-10-02-00

330101-00-30-10-02-05

330101-00-52-10-02-05

330101-00-96-10-02-05

330103-00-02-05-01-00

330103-00-04-10-02-05

330103-00-04-50-11-00

330103-00-05-05-02-05

330103-00-05-10-02-00

330103-00-06-10-02-00

330103-00-06-50-02-00

330103-00-08-10-02-00

330103-00-10-10-02-00

330103-00-12-10-02-00

330103-00-13-10-02-00

330103-00-17-10-02-05

330103-00-18-10-02-00

330103-02-12-10-02-00

330103-05-10-05-02-00

330103-06-16-10-02-00

330103-06-19-10-02-00

330103-06-25-10-02-00

330103-08-14-10-02-00

330103-09-18-10-02-00

330103-10-20-05-02-00

330104-00-04-10-02-05

330104-00-04-50-02-05

330104-00-06-10-01-00

330104-00-06-50-02-00

330104-00-08-05-02-05

330104-00-10-10-11-00

330104-00-12-10-02-05

330104-00-14-50-02-00

330104-00-18-10-02-05

330104-01-08-05-01-05

330104-02-10-50-02-05

330104--02-12-50-02-00

330104--04-10-05-02-00

330104-04-18-50-02-05

330104-06-16-10-02-00

330104-09-15-05-02-00

330104-10-20-10-02-00

330105-02-12-05-02-00

330105-02-12-05-02-05

330105-02-12-10-02-00

330105-02-12-90-02-05

330106-05-30-05-02-00

330106-05-30-05-02-05

330106-05-30-10-02-00

330106-05-30-10-02-05

330173-00-06-10-02-05

330193-00-05-10-00

330703-000-040-50-11-00

330703-000-050-10-02-00

330703-000-060-10-02-00

330703-000-080-10-02-00

330703-000-100-10-02-00

330704-000-100-10-11-00

330704-000-060-10-02-00

330705-02-18-10-02-00

330705-02-18-90-02-05

330709-000-040-10-02-00

330709-000-060-90-02-00

330709-050-120-10-02-00

330710-000-060-10-02-00

330851-02-000-030-10-00-05

330851-02-000-050-10-00-05

330851-02-000-060-10-00-05

330851-02-000-070-90-00-05

330851-02-000-080-10-01-05

330851-06-000-070-50-00-05

330851-08-00-15-10-01-05

330876-03-10-00-00

330877-80-36-00

330878-90-00

330881-16-04-355-00-02

330881-28-04-050-00-02

330881-28-04-150-00-02

330881-28-04-220-00-02

330904-08-15-10-02-05

330904-05-14-05-02-00

330904-08-15-10-02-00

330905-00-10-10-02-00

330905-00-12-10-02-05

330905-00-13-05-02-05

330905-00-15-10-02-05

330905-00-25-05-02-05

330907-05-30-10-02-00

330910-00-12-10-02-00

41559-02

9200-01-01-10-00

9200-01-01-02-00

9200-01-02-10-00

9200-01-05-10-00

9200-06-01-10-00

9200-06-05-05-00

9200-06-05-10-00

990-04-50-01-00

990-04-70-01-00

990-05-50-01-00

990-05-70-01-01

990-05-70-02-00

991-25-50-01-00

330180-50-00

330180-51-00

330180-51-05

330180-90-00

330180-91-05

330400-02-05

330500-02-04

330780-50-00

330780-90-00

330850-50-05

CB2W100-32

330130-040-00-00

330130-040-00-05

330130-040-01-00

330130-040-01-05

330130-040-03-00

330130-040-13-00

330130-045-01-00

330130-045-01-05

330130-070-00-05

330130-075-00-05

330130-080-00-00

330130-080-01-00

330130-080-01-05

330130-080-02-00

330130-085-00-00

330130-085-01-05

330190--080-00-00

330730-040-01-00

330730-040-13-00

330730-080-00-00

330854--040-25-05

330930-040-00-00