

- 最大使用寿命

100,000 cycle

selection code chart

1. operation type

contact operation

code a

code b

open on rise

close on rise

2. electric rating

code r

code x

code d

7.5a, 250v ac

1a 以下 (cross bar contact)

8a, 12v dc

3. cap type

code f

code l

code s

code u

code a

4. bracket type

code a

code c

code d

code r

code n

--	--

5. terminal type

codea	codeb
codec	coded
codee	codesh
codesv	code.

6. top temperature in ° c

temperature range	-20 ° c to 100 ° c	101 ° c to 120 ° c	121 ° c to 150 ° c
differential	10 ° c	15 ° c	20 ° c

7. top temperature tolerance code

temperature range	-20 ° c to 100 ° c	101 ° c to 120 ° c	121 ° c to 150 ° c
	3 ° c		
differential	10 ° c	15 ° c	20 ° c

8. bottom temperature in ° c

temperature range	-20 ° c to 100 ° c	101 ° c to 120 ° c	121 ° c to 150 ° c
differential	10 ° c	15 ° c	20 ° c

9. bottom temperature tolerance code

temperature range	-20 ° c to 100 ° c	101 ° c to 120 ° c	121 ° c to 150 ° c
	3 ° c		
differential	10 ° c	15 ° c	20 ° c