

新款小低音炮、 高清音质小低音箱、 精美便携式小音箱

产品名称	新款小低音炮、 高清音质小低音箱、 精美便携式小音箱
公司名称	深圳市柏珂时代投资发展有限公司
价格	78.00/件
规格参数	品牌:MusicAngle 型号:JH-M03uk 类型:FM+U+Disk+SDSpeaker
公司地址	中国 广东 深圳市福田区 皇岗北路莲花彩电工业区赛格日立工业区2栋245室
联系电话	86 755 29228696 13682315740

产品详情

品牌	Music Angle	型号	JH-M03uk
类型	FM+U+Disk+SD Speaker		

music angel

功能说明 function explanation

1.这款迷你音箱可谓是经典和现代完美结合，音箱中的精品。

2.全新微型铝振膜扬声器，高音清澈，低音纯净，独特胡设计，令音质表现更出色。

3.新概念一体化立体声便携式移动音乐胡数码音箱，连接你的mp3.mp4.cd.dvd.ipod.iphone.gps.psp.手机.笔记本电

4.金属外壳,更显高贵时尚，与众不同，多种颜色，多种方案，给你更多选择.

5.电池，电脑usb，适配器dc-5v多种供电方式，让你随时随地聆听数码的魅力.

1.this mini audio box can be deemed as perfect combination of classic and modehm performace,and it is praised as masterwo

2.new mini aluminum vibration film loud speaker,which has clear alt and pure woof .the unique design makes tone performat

3.mini audio box with new concept integral stereo portable mobile music,connecting your mp3、 mp4,cd、 dvd、 ipod、 iph

4. metallic, shell shows noble and fashionable, out of ordinary, with many colours, several solutions; for your option.

5. several power supply manners including battery, computer usb, adaptor dc-5v allow you to enjoy the charm of digital products.

speaker 's functional parameter

输出功率: rms 4w (2w+2w) thd=10%

频率响应: 150-18000hz (± 3db)

信噪比: 80db

扬声器: 1.5英寸 (外径40mm) 防磁, 4欧姆

line in 接口: 配3.5mm 立体声插头

电源输入: 5v/1000ma 交流电源适配器, usb 电源转接线 (可选)

work rate of the output: rms 4w (2w +2 w) thd = 10%

frequency response :150-18000hz (± 3db)

snr: 80db

speaker: 1.5 inch (diameter 40mm) magnetically shielded, 4 ohm

line in the interface: the body with 3.5mm plug production

power input: 5v/1000ma ac power adapter, usb power adapter cable (optional)

操作说明 use explanation

内置锂电池, 当锂电池失效时, 可拆除锂电池, 转用 (aaa) 电池。

电池: 按正确极性装入4节 (aaa) 电池, 当指示灯变暗或闪烁, 或声音失真时, 请更换新电池。

充电: 使用usb 5v或dc-5v供电时并充电, 关机充电红色指示灯亮, 充满红色指示灯熄灭, 开机充电指示灯变粉

line in: 音频输入

dc-5v: 直流5v (0.4a-1a) 电源适配器, 可用usb电源

off/on: 开关置于off音响则停止播放音乐, 置于on则音频经功放输出

ant: fm天线孔, 使用fm时, 可用音频线插入此孔才能使用。

micro sd: 将tf卡或micro sd卡插入此孔。

pict

built-in lithium battery, when the lithium battery failure, removable lithium battery, switch (aaa) batteries.

battery: 4 into the correct polarity (aaa) batteries, when the lights dim or flicker, or the sound is distorted, replace the new batt

charge: using usb 5v or dc-5v power supply and charging time, charging off the red indicator light, full of red light is off, charg

line in: audio input

dc-5v: dc 5v (0.4a-1a) power adapter, usb power supply available

off / on: off switch will stop the music sound, placed by the audio amplifier output on

ant: fm antenna hole, the use of fm, the audio cable into the pore can be used.

micro sd: the tf card or micro sd card into the hole.