

FS4008-10-08-BV-C气体流量传感器

产品名称	FS4008-10-08-BV-C气体流量传感器
公司名称	广州汉川仪器仪表有限公司
价格	820.00/台
规格参数	品牌:汉川仪表/Siargo 型号:FS4008 工作电源:8~18Vdc,100m
公司地址	广州市番禺区石基镇市莲路石基村段1号5栋3楼
联系电话	020-31106086 15918757810

产品详情

比例型号：

FS4008系列气体流量传感器(Siargo)

FS4008-10-R1/4-BV-A，FS4008-20-R1/4-BV-A，FS4008-30-R1/4-BV-A，FS4008-40-R1/4-BV-A，FS4008-50-R1/4-BV-A,

FS4008-10-R1/4-BV-B，FS4008-20-R1/4-BV-B，FS4008-30-R1/4-BV-B，FS4008-40-R1/4-BV-B，FS4008-50-R1/4-BV-B,

FS4008-10-R1/4-BV-C，FS4008-20-R1/4-BV-C，FS4008-30-R1/4-BV-C，FS4008-40-R1/4-BV-C，FS4008-50-R1/4-BV-C,

FS4008-10-R1/4-BV-O，FS4008-20-R1/4-BV-O，FS4008-30-R1/4-BV-O，FS4008-40-R1/4-BV-O，FS4008-50-R1/4-BV-O,

FS4008-10-R1/4-BV-R，FS4008-20-R1/4-BV-R，FS4008-30-R1/4-BV-R，FS4008-40-R1/4-BV-R，FS4008-50-R1/4-BV-R,

FS4008-10-R1/4-BV-N，FS4008-20-R1/4-BV-N，FS4008-30-R1/4-BV-N，FS4008-40-R1/4-BV-N，FS4008-50-R1/4-BV-N,

1、

FS4008-10-R-V-A，FS4008-20-R-V-A，FS4008-30-R-V-A，FS4008-40-R-V-A，FS4008-50-R-V-A,

FS4008-10-R-V-B，FS4008-20-R-V-B，FS4008-30-R-V-B，FS4008-40-R-V-B，FS4008-50-R-V-B,

FS4008-10-R-V-C , FS4008-20-R-V-C , FS4008-30-R-V-C , FS4008-40-R-V-C , FS4008-50-R-V-C,
FS4008-10-R-V-O , FS4008-20-R-V-O , FS4008-30-R-V-O , FS4008-40-R-V-O , FS4008-50-R-V-O,
FS4008-10-R-V-R , FS4008-20-R-V-R , FS4008-30-R-V-R , FS4008-40-R-V-R , FS4008-50-R-V-R,
FS4008-10-R-V-N , FS4008-20-R-V-N , FS4008-30-R-V-N , FS4008-40-R-V-N , FS4008-50-R-V-N,

2、

FS4008-10-R-CV-A , FS4008-20-R-CV-A , FS4008-30-R-CV-A , FS4008-40-R-CV-A , FS4008-50-R-CV-A,
FS4008-10-R-CV-B , FS4008-20-R-CV-B , FS4008-30-R-CV-B , FS4008-40-R-CV-B , FS4008-50-R-CV-B,
FS4008-10-R-CV-C , FS4008-20-R-CV-C , FS4008-30-R-CV-C , FS4008-40-R-CV-C , FS4008-50-R-CV-C,
FS4008-10-R-CV-O , FS4008-20-R-CV-O , FS4008-30-R-CV-O , FS4008-40-R-CV-O , FS4008-50-R-CV-O,
FS4008-10-R-CV-R , FS4008-20-R-CV-R , FS4008-30-R-CV-R , FS4008-40-R-CV-R , FS4008-50-R-CV-R,
FS4008-10-R-CV-N , FS4008-20-R-CV-N , FS4008-30-R-CV-N , FS4008-40-R-CV-N , FS4008-50-R-CV-N,

3、

FS4008-10-R-BV-A , FS4008-20-R-BV-A , FS4008-30-R-BV-A , FS4008-40-R-BV-A , FS4008-50-R-BV-A,
FS4008-10-R-BV-B , FS4008-20-R-BV-B , FS4008-30-R-BV-B , FS4008-40-R-BV-B , FS4008-50-R-BV-B,
FS4008-10-R-BV-C , FS4008-20-R-BV-C , FS4008-30-R-BV-C , FS4008-40-R-BV-C , FS4008-50-R-BV-C,
FS4008-10-R-BV-O , FS4008-20-R-BV-O , FS4008-30-R-BV-O , FS4008-40-R-BV-O , FS4008-50-R-BV-O,
FS4008-10-R-BV-R , FS4008-20-R-BV-R , FS4008-30-R-BV-R , FS4008-40-R-BV-R , FS4008-50-R-BV-R,
FS4008-10-R-BV-N , FS4008-20-R-BV-N , FS4008-30-R-BV-N , FS4008-40-R-BV-N , FS4008-50-R-BV-N,

4、

FS4008-10-08-BV-A , FS4008-20-08-BV-A , FS4008-30-08-BV-A , FS4008-40-08-BV-A , FS4008-50-08-BV-A,
FS4008-10-08-BV-B , FS4008-20-08-BV-B , FS4008-30-08-BV-B , FS4008-40-08-BV-B , FS4008-50-08-BV-B,
FS4008-10-08-BV-C , FS4008-20-08-BV-C , FS4008-30-08-BV-C , FS4008-40-08-BV-C , FS4008-50-08-BV-C,
FS4008-10-08-BV-O , FS4008-20-08-BV-O , FS4008-30-08-BV-O , FS4008-40-08-BV-O , FS4008-50-08-BV-O,
FS4008-10-08-BV-R , FS4008-20-08-BV-R , FS4008-30-08-BV-R , FS4008-40-08-BV-R , FS4008-50-08-BV-R,
FS4008-10-08-BV-N , FS4008-20-08-BV-N , FS4008-30-08-BV-N , FS4008-40-08-BV-N , FS4008-50-08-BV-N,

